

User's Guide

**Notebook
Computer**

Preface

©Copyright 2002

All Rights Reserved.

Manual edition, May 2004

The information in this document is subject to change without prior notice in order to improve reliability, design and function and does not represent a commitment on the part of the manufacturer.

In no event will the manufacturer be liable for direct, indirect, special, incidental, or consequential damages arising out of the use or inability to use the product or documentation, even if advised of the possibility of such damages.

This document contains proprietary information protected by copyright. All rights are reserved. No part of this manual may be reproduced by any mechanical, electronic, or other means in any form without prior written permission of the manufacturer.

Trademarks

CardSoft is a trademark of SystemSoft Corporation. AutoCAD and Autoshade are trademarks of Autodesk, Inc. IBM, OS/2, and VGA are trademarks of International Business Machines Corp. Lotus, 1-2-3, and Symphony are trademarks of Lotus Development Corp. Windows, Word, MS-DOS, and Microsoft are trademarks of Microsoft Corp. VESA is a trademark of Video Electronics Standards Association.

Other product names mentioned herein are used for identification purposes only and may be trademarks and/or registered trademarks of their respective companies.

Limitation of Liability

While reasonable efforts have been made to ensure the accuracy of this manual, the manufacturer and distributor assume no liability resulting from errors or omissions in this manual,

or from the use of the information contained herein.

Notices

Federal Communications Commission Radio Frequency Interference Statement

NOTE: *This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and if not installed and used in accordance with the instruction manual may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:*

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio TV technician for help.

Notice:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Shielded interface cables and a non-shielded AC power cord must be used in order to comply with emission limits.

This equipment is to be used with power supply:

I/P: 100-240 Vac, 50-60Hz, 1.8A
O/P: 19Vdc, 3.42A
There is no internal power supply.

Canadian DOC Notice For Class B Computing Devices

This Class B digital apparatus meets all requirements of the Canadian Interference - Causing Equipment Regulations.

Cet appareil numérique de la classe B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

Safety Precautions

This section is designed to assist you in identifying potentially unsafe conditions while working with this product. Required safety features have been installed in the computer to protect you from injury. However, you should use good judgment to identify potential safety hazards:

1. Please read these safety instructions carefully.
2. Please keep this User's Manual for later reference.
3. Please disconnect this equipment from AC outlet before cleaning. Don't use liquid or sprayed detergent for cleaning. Use moisture sheet or cloth for cleaning.
4. For pluggable equipment, that the socket-outlet shall be installed near the equipment and shall be easily accessible.
5. Please keep this equipment from humidity.
6. Lay this equipment on a reliable surface when install. A drop or fall could cause injury.
7. Make sure to use the right voltage for the power source when connecting the equipment to the

power outlet.

8. Place the power cord in such a way that people can not setp on it. Do not place anything on top of the power cord.
9. All cautions and warnings on the equipment should be noted.
10. If the equipment is not use for a long time, disconnect the equipment from the main power outlet to avoid being damaged by transient overvoltage.
11. Never pour any liquid into the opening, this could cause fire or electrical shock.
12. Never open the equipment. For safety reason, the equipment should only be opened by a qualified service personnel.
13. If on the following situations arises, get the equipment checked by a service personnel:
 - a. The Power cord or plug is damaged.
 - b. Liquid has penetrated into the equipment.
 - c. The equipment has been exposed to moisture.
 - d. The equipment has not work well or you cannot get it work according to the user's manual.
 - e. The equipment has dropped and damaged.
 - f. If the equipment has obvious sign of breakage.
14. Do not leave this equipment in an environment unconditioned, storage temperature above 60°C (140°F), it may damage the equipment.
15. The unit can be operated at an ambient temperature of max. 35°C.
16. The sound pressure level at the operators position according to IEC 704-1: 1982 is equal or less than 70 dB(A).

17. Power Cord Requirements

The power cord set used with the AC adaptor must meet the requirements of the country where you use the AC adaptor, whether it is 100-120 or 200-240 Vac. The following information explains the requirements for power cord set selection.

- The cord set must be approved for the country in which it is used.
- The appliance coupler must have a configuration for mating with a CEE22/EN6032/IEC 320 appliance inlet.

A. For U.S. and Canada:

- The cord set must be UL Listed and CSA Certified.
- The minimum specifications for the flexible cord are No. 18 AWG.

B. For Japan:

- All components of the cord set must bear a “ T ” mark and registration number in accordance with the Japanese Dentori Law.
- The minimum specifications for the flexible cord are .75m m² conductors.

C. For Other Countries:

- The cord set fittings must bear the certification mark of the agency responsible for evaluation in a specific country.
- The flexible cord must be of a HAR (harmonized) type H05VV-F.
- The cord set must have a current capacity of a least 2.5 Amperes and voltage rating of 125 or 250 Vac.

18. When using your telephone equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury to persons. These precautions includes the following:

- 1. Do not use this product near water, for example, near a bathtub, washbowl, kitchen sink**

-
- or laundry tub, in a wet basement or near a swimming pool.
2. Avoid using a telephone (other than a cordless type) during an electrical storm. There may be a remote risk of electric shock from lightning.
 3. Do not use the telephone to report a gas leak in the vicinity of the leak.
 4. Use only the power cord indicated in this manual.
19. Do not use the AC adapter near open water or other liquids. Never spill liquid into the AC adapter.
 20. Laser Warning: Laser Class I Product Caution - Invisible laser radiation when open avoid exposure to beam.
 21. Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions. Never remove the battery pack while the power is on as this may result in data loss when the system loses power.

Wichtige Sicherheitshinweise

1. Bitte lesen Sie diese Hinweis sorgfältig durch.
2. Heben Sie diese Anleitung für den späteren Gebrauch auf.
3. Vor jedem Reinigen ist das Gerät vom Stromnetz zu trennen. Versenden Sie keine Flüssig- oder Aerosolreiniger. Am besten eignet sich ein angefeuchtetes Tuch zur Reinigung.
4. Die Netzanschlußsteckdose soll nahe dem Gerät angebracht und leicht zugänglich sein.
5. Das Gerät ist vor Feuchtigkeit zu schützen.
6. Bei der Aufstellung des Gerätes ist auf sicheren Stand zu achten. Ein Kippen oder Fallen

könnte Beschädigungen hervorrufen.

7. Beachten Sie beim Anschluß an das Stromnet die Anschlußwerte.
8. Verlegen Sie die Netzanschlußleitung so, daß niemand darüber fallen kann. Es sollte auch nichts auf der Leitun abgestellt werden.
9. Alle Hinweise und Warnungen, die sich am Gerät befinden, sind zu beachten.
10. Wird das Gerät üeinen längeren Zeitraum nicht benutzt, sollten Sie es vom Stromnetz trennen. Somit wird im Falle einer Überspannung eine Beschädigung vermieden.
11. Durch die Lüftungsöffnungen dürfen niemals Gegenstände oder Flüssigkeiten in das Gerät gelangen. Dies könne einen Brand bzw. Elektrischen Schlag auslösen.
12. Öffnen Sie niemals das Gerät. Das Gerät darf aus Gründen der elektrischen Sicherheit nur von autorisiertem Servicepersonal geöffnet werden.
13. Wenn folgende Situationen auftreten ist das Gerät vom Stromnetz zu trennen und von einer qualifizierten Servicestelle zu Überprüfung.:
 - a. Netzlabel oder Netzstecker sind beschädigt.
 - b. Flüssigkeit ist in das Gerät eingedrungen.
 - c. Das Gerät war Feuchtigkeit ausgesetzt.
 - d. Wenn das Gerät nicht der Bedienungsanleitung entsprechend funktioniert oder Sie mit Hilfe dieser Anleitung keine Verbesserung erzielen.
 - e. Das Gerät ist gefallen und/oder das Gehäuse ist beschädigt.
 - f. Wenn das Gerät deutliche Anzeichen eines Defektes aufweist.
14. **VORSICHT:** Explosionsgetahr bei unsachgemäßen Austausch der Batterie. Ersatz nur durch denselben oder einem vom Hersteller empfohlenem ähnlichen Typ. Entsorgung gebrauchter

Batterien nach Angaben des Herstellers.

- 15.** Dieses Schaltnetzteil kann bis zu einer Außentemperatur von maximal 35°C.
- 16.** Die Ausgangswerte dürfen nicht die auf dem Label angegebenen Werte überschreiten.
- 17.** Anforderungen an das Stromkabel
Das Kabel-Set, das an das Netzteil angeschlossen wird, muss den Anforderungen des Landes, in dem Sie das Netzteil einsetzen, genügen, je nachdem, ob die Netzspannung 100-120 oder 200-240V Wechselspannung beträgt.
- Das Kabel-Set muss für das Land, in dem es eingesetzt wird, zugelassen sein.
 - Der Gerätestecker des Kabels muss in eine CEE22/ EN603/ IEC 320 Buchse passen.
- A.** Für die USA und Kanada:
- Das Kabel-Set muss UL-gelistet und CSA zertifiziert sein.
 - Die Minimalanforderungen für das Kabel entsprechen No. 18 AWG.
- B.** Für Japan:
- Alle Teile des Kabel-Sets müssen entsprechend dem japanischen Dentori Law mit einem "T"-Symbol markiert sein
 - Die Minimalanforderungen für das Kabel sind .75m ² Leiter.
- C.** Für andere Länder:
- Die Zubehörteile des Kabel-Sets müssen das Prüfsiegel derjenigen Stelle, die in dem jeweiligen Land für die Sicherheitsprüfung zuständig ist, tragen.
 - Das Kabel muss vom HAR (harmonisierten) Typ H05VV-F sein.
 - Das Kabel-Set muss eine Stromkapazität von mindestens 2,5 Ampere haben und Spannungen von 125 oder 250 V Wechselstrom gestatten.

-
- 18.** Bei der Benutzung Ihres Telefongerätes sollten Sie immer die grundlegenden Sicherheitsmaßnahmen beachten, um das Risiko von Feuer, Stromschlägen und Verletzungen zu minimieren. Zu beachten sind u.a. folgende Punkte:
1. Benutzen Sie das Gerät nicht in der Nähe von Wasser, wie zum Beispiel Badewanne, Waschbecken, Spülbecken, Waschbottich, in feuchten Kellerräumen oder in der Nähe von Schwimmbecken.
 2. Benutzen Sie kein Telefon (ausgenommen schnurlose Modelle) während eines Gewitters. Es besteht das geringe Restrisiko eines Blitzschlages.
 3. Benutzen Sie das Telefon nicht um ein Gasleck zu melden, falls es sich in der Nähe des Lecks befindet.
 4. Benutzen Sie nur solch ein Stromkabel, wie in dieser Anleitung beschrieben.
- 19.** Benutzen Sie das Netzteil nicht in unmittelbarer Nähe zu Wasser oder anderen Flüssigkeiten. Gießen Sie nie Flüssigkeiten über das Netzteil.
- 20.** Achtung Laser: Laser Produkt der Klasse I. Achtung - Unsichtbarer Laserstrahl, vermeiden Sie Kontakt mit dem Strahl bei offenem Gehäuse.

Personal Inventory

This Notebook computer system is designed for years of productive and pleasurable computing. Use this section to keep notes about details of your purchase. Update this section when you add new options.

Date of Purchase:

Dealer's Name:

Phone:

Address:

E-Mail Address:

WWW Site:

Serial Number:

CPU Type:

Hard Disk Capacity:

Memory Capacity:

Optional Equipment:

Chapter 1

Introduction

WARNING:

There are more and more people spending large amounts of time in front of computer monitors now that scientists from many fields including anatomy, psychology, and occupational safety are involved in the study of ergonomically sound work environments.

A few tips to help you work effectively without a lot of physical discomfort:

- Purchase a chair with armrests and good back support. Don't slouch when sitting; keep your back straight.
- Try to place the LCD panel or external monitor so that there is little glare from the sun on the monitor.
- Walk around the room every hour.
- Every half hour look away from the computer screen for a few minutes.
- Place everything that you need to work within easy reach.

Welcome to the Notebook PC

Congratulations on your purchase of the Notebook PC. Your Notebook features the latest advances in portable computing technology. The Notebook's modular design provides maximum expandability without compromising portability. The high-performance CPU and enhanced IDE hard drive provides you with extra processing power for handling complex graphics and running large programs.

One PCMCIA slot gives you the ability to use standard PCMCIA cards, such as a LAN adapter or memory cards.

Getting to Know Your Computer

Opening the LCD Panel

At the front of the Notebook you will find a retaining latch on the display panel that locks the display in closed position when the Notebook is not in use.

1. Slide the display panel latch to the right until the display panel releases, and then raise the LCD screen.
2. At any time you can tilt the display toward or away from you to a comfortable viewing position.

CAUTION: To avoid damage to the display panel:

1. Try not to slam the display upon closing it.
 2. Try not to place any object on top when it is closed or open.
-

WARNING:

To shutdown the system in non-Windows (DOS mode, System POST, Setup Menu or Quick Boot Menu) based environment, enable the lid switch. This will prevent the system from damaged if it exceeds the temperature limit. Windows will control the lid switch in windows environment.

With the LCD screen open, you will see several features important for operating your Notebook computer.



Each of these features is briefly described below.

1. **LCD Cover Release Latch**

Slide this latch to the right to open the LCD cover.

2. **LCD Screen**

Your Notebook computer is equipped with a replaceable color Liquid Crystal Display (LCD) screen that supports up to 1024 x 768 or 1400 x 1050 x 16M LCD resolution utilizing a AGP BUS.

A built-in backlight allows you to comfortably view the screen even when ambient lighting is low.

3. **Internet Explorer Button**

Use this key to open the Internet Explorer.

4. **Outlook Express Button**

Use this key to open Microsoft's Outlook to send/receive your mail.

5. **System Status Indicator Panel**

The system status indicator panel keeps you informed of the computer's operating status.

	Indicates that the computer is accessing the hard disk drive.
	Indicates that the keyboard is in Num Lock mode.
	Indicates when the keyboard is in Caps Lock mode. In this mode, the keyboard produces uppercase text when you press a key. When you press the Caps Lock key again, the indicator goes off and the keyboard produces lowercase text.



Indicates when the keyboard is in Scroll Lock mode. Some applications will move information across the screen differently when Scroll Lock is on.

6. Power/Resume Button

Pressing this button for 1-2 seconds will turn on the system or pressing this button when the computer is in Suspend mode will resume normal operation. Pressing this button for 4-6 seconds will also turn off the system.

7. TouchPad

The TouchPad is hardware-compatible with the IBM PS/2 mouse and software-compatible with the Microsoft mouse.

8. TouchPad Buttons

The buttons below the TouchPad correspond to the left and right buttons on a standard mouse. The PS/2 compatible mouse will work with the Notebook PC's TouchPad simultaneously.


9. Scroll Button

Use this button to scroll up and down the scrolling bar.

10. The Built-in Microphone

The built-in microphone is located to the left of the TouchPad.

The Left Side



1. **Ventilation Opening**

Please don't block this opening during operation of the system.

2. **1394A**

A very fast external bus standard that supports data transfer rates of up to 400 Mbps (400 million bits per second).

Can be used to connect up to 63 external devices, also supports isochronous *data* -- delivering data at a guaranteed rate. This makes it ideal for devices that need to transfer high levels of data in real-time, such as video devices. Also supports both Plug-and-Play and hot plugging, and also provides power to peripheral devices.

3. **PCMCIA Socket Cover**

Open this cover to access the PCMCIA socket. The computer's PCMCIA socket lets you extend the capabilities of your computer by inserting PC cards.

4. **PCMCIA Socket Button**

The computer has one PCMCIA type II socket

5. **The LAN Port**

This jack provides a standard RJ-45 connection for integration with an existing network or a high-speed (DSL or cable) connection via a network cable.

6. **The Modem Port**

This jack is an internal 56K voice/fax/data modem. You will connect your computer to your phone line through this port.

7. **Microphone Jack**

Allows you to receive monophonic input from an external microphone. Use of an external microphone will disable the built-in microphone.

8. **Audio Line Out Jack**

You can plug an external speaker, headphone or connect the line out jack to an audio device such as a cassette recorder to record the notebook's audio output.

LED Indicators

These three LED indicators are separately program for the following functions: Power On, Suspend Mode and Battery Charge.

1. Power On


This indicator will lit when the notebook is powered On.

2. Battery Charge

This indicator will lit green when the battery is in charging status. When the indicator light turns off, it indicates the system is in full charge.

3. Suspend Mode

This indicator will lit when the notebook enter the suspend mode.




The Right Side



1. **The CD-ROM/DVD-ROM or DVD CD-RW Combo (Option)**
Your Notebook comes with a swappable 24X (or higher) 5.25" IDE CD-ROM or 8X DVD-ROM.
2. **DC IN Connector**
Plug the AC adapter into this connector.

The Rear



1. Ventilation Opening

Please don't block this opening during operation of the system.

2. Kensington Lock

Allows you to connect a special computer lock to secure your system.
You can purchase a lock at most computer retailers.

3. S-Video Port

Allows you to connect any S-Video ready television to your system. You can display output simultaneously on both the LCD and the television or toggle between the two screens.

4. Parallel Port

This port allows you to easily connect a parallel printer or plotter using this 25-pin bi-directional female port.

5. **External CRT Port**

This port allows you to easily connect an external VGA/SVGA display monitor into your Notebook using the 15-pin female connector.

6. **Infrared Data Port**

The Infrared Data Port allows your Notebook to become truly wireless.

You can use this port to transfer large amounts of data very quickly to any other machine (Notebook computers, printers, etc.), which is also equipped with an IrDA-compliant IR port.

This allows you to print documents without any inconvenient cable hookups.

7. **USB Ports**

Your computer includes two Universal Serial Bus (USB) port. USB is the latest development in Plug and Play technology.

It will eventually replace the need for separate connectors for external keyboards, serial ports, and parallel (printer) port.

The Bottom Panel



1. Battery

Your notebook comes equipped with a factory-installed battery pack module. After the battery runs down, the module can be removed and replaced with a charged battery.

2. **Hard Disk Drive**

Your computer includes a 2.5-inch IDE hard disk drive (9.5mm in height). The notebook PC's BIOS automatically detects IDE drive types.

3. **Battery Release Latch**

Lift up this latch to release the battery from its bay.

4. **Expansion Compartment**

This compartment will serve as an expansion to upgrade your RAM module.

5. **MiniPCI/Wireless LAN/Modem Combo Compartment (Option)**

This compartment can be used to extend the capabilities of your system by providing a connection with various extension card.

Getting Started

Chapter 2

Connecting to a Power Source

Connecting the AC Adapter

A universal AC adapter is provided to supply your computer with power and also charge the computer's battery pack.

The adapter's AC input voltage can range anywhere from 100 to 240 volts, covering the standard voltages available in almost every country.

The power cord for the AC adapter requires a three-hole grounded AC outlet. To connect the computer to an external power source:

1. Plug the AC adapter's connector into the DC-IN connector on the rear of the computer.
2. Connect the power cord to the AC adapter and then to a wall outlet.



CAUTION: The best kind of AC power source to connect your Notebook to is a UPS (Uninterruptible Power Supply). Lacking this, use a power strip with a built-in surge protector. Do not use inferior extension cords as this may result in damage to your Notebook. The Notebook comes with its own AC adapter. Do not use a different adapter to power the computer and other electrical devices.

Whenever possible, keep the AC adapter plugged into the Notebook and an electrical outlet to recharge the battery.

CAUTION: Never turn off or reset your Notebook while the hard disk is in use and the HDD status icon is lit; doing so can result in loss or destruction of your data. Always wait at least 5 seconds after turning off your Notebook before turning it back on; turning the power on and off in rapid succession can damage the Notebook's electrical circuitry.

Turning On Your Notebook Computer

Turn on your Notebook by pressing the power button. Hold the button down for a second or two and release. The Power-On Self Test (POST) runs automatically.

After the POST is completed, the computer reads the operating system from the hard disk drive into computer memory (this is commonly referred to as "booting" a computer). If your OS (Operating System such as Windows ME, Windows 2000.... etc) is installed, it should start automatically.

To turn the Notebook off, save your work and close all open applications, click on **Start**, then **Shut Down** and select **Shut down the computer** and click "**Yes**" or press the power button for 4-6 seconds.

Operating on Battery Power

Your computer comes with a rechargeable battery pack that lets you operate the computer without an external power source. When the battery pack is fully charged, you can operate the computer for approximately 2 hours under the following conditions:

- The battery pack initially has a full charge.


-
- No peripheral devices are installed.
 - The disk/CD-ROM drives run no more than 10% of the time.

NOTE: *Only use batteries that are approved by an authorized dealer. All batteries are not the same and therefore should not be treated as such. Using the wrong battery could cause serious damage to your computer and yourself through toxic emissions.*

Inserting and Removing the Battery Pack

The battery pack should already be inserted in your Notebook computer when you unpack it. If not inserted, follow these directions:


1. Turn over the notebook with the front of the unit facing you and place it on a solid, flat surface.
2. Angle the battery into the bay. The front edge of the battery should slide into the grooves in the system case.



3. Gently lower the battery into the bay and push it until it clicks securely in the bay.

To remove the battery pack:

1. Turn off the notebook, and disconnect the AC adapter. Close the LCD panel and turn it over and place it on a solid, flat surface.
2. Lift the release latch to release the battery from the bay. At this time the battery will now be angled slightly out of the bay.



3. Hold the battery at the finger grip and lift it out of the compartment.



Charging the Battery Pack

The installed battery pack charges automatically any time the computer is connected to the AC adapter and an external power source.

It is a good idea to occasionally discharge the battery pack fully to preserve its operating performance.

NOTE:

Step 1: Discharge the battery and recharge until it reach full charge capacity.

Step 2: A fully charge battery must be discharge to less then 95% capacity then recharge the battery.

Chapter 3

***Using the Notebook
Computer***

Adjusting the LCD Screen Display

The LCD screen display can be adjusted by the following key combinations.

KEYS	FUNCTIONS
[Fn] + [F7]	Decreases the brightness level.
[Fn] + [F8]	Increases the brightness level.
[Fn] + [F10]	Use this key combination to expand your video screen or reset to its original size.
[Fn] + [F12]	This key combination toggles the display between the LCD, CRT, simultaneous LCD/CRT, TV, simultaneous CRT/TV.

LCD Care

LCD screens are delicate devices that need careful handling. Please pay attention to the following precautions:

- When you are not using the computer, keep the LCD screen closed to protect it from dust.
- If you need to clean your LCD screen, use a soft tissue to gently wipe the LCD surface.
- Do not put your fingers or sharp objects directly on the surface and never spray cleaner directly onto the display.
- Do not press on, or store any objects on the cover when it is closed. Doing so may cause the LCD to break.

External CRT Display

You can hook up an external monitor through the 15-pin CRT connector. Three configurations are available:

- LCD only

-
- CRT only
 - Simultaneous display of the LCD screen and CRT monitor
 - TV only
 - Simultaneous display of the TV screen and CRT monitor

You can switch between these display configurations by pressing the key combination **[Fn] + [F12]**. For information on connecting an external display, please refer to Chapter Four.

A Tour of the Notebook's Keyboard

The Notebook's keyboard uses a standard QWERTY layout with the addition of special function keys and an embedded numeric keypad for number intensive data entry. Your keyboard supports Windows by incorporating the two Windows specific keys. With the two Windows keys you will be able to access and take advantage of many of the timesaving features of Windows software.

The function keys (F1-F12) on the top row of the keyboard, serve different purposes and carry out different tasks depending on the application you are running.

The cursor (arrow) keys (which are all located in the lower right corner of your keyboard) and the [PgUp], [PgDn], [Home] and [End] keys (which are located along the right edge of the keyboard) allow you to move the active cursor of the computer to various locations on the screen or within the document.

The embedded numeric keypad consists of 15 keys that make number intensive input more convenient. Like the [Num Lock] key, these keys are labeled in blue on the keycaps. Numeric assignments are located at the upper right of each key.

When the numeric keypad is engaged, the NumLock icon will appear in the System Window. The keypad is activated by pressing the [Fn] + [NumLk] key. If an external keyboard is connected, pressing the NumLock key on either the Notebook or external keyboard will enable/disable NumLock of both keyboards in unison.

To disable the Notebook numeric keypad while keeping the keypad on an external keyboard activated, use the [Fn] + [NumLk] hot key on the Notebook keyboard.



The Notebook's Hot Key Controls

KEYS	FUNCTION(S)
Power Button	Press this button once to power on or enter the suspend/resume mode. Press this button for more than 4 seconds to power off the system.
Internet Button	Open Internet WWW Home short-cut key
Email Button	Open Email Reader short-cut key

[Fn] + [F2]	This key combination turns on/off the volume.
[Fn] + [F3]	Decreases the speaker volume.
[Fn] + [F4]	Increases the speaker volume.
[Fn] + [F7]	Decreases the brightness level.
[Fn] + [F8]	Increases the brightness level.
[Fn] + [F10]	Use this key combination to expand your video screen or reset to its original size.
[Fn] + [F12]	This key combination toggles the display between the LCD, CRT, simultaneous LCD/CRT, TV, simultaneous CRT/TV.

The TouchPad

The touchpad is a rectangular electronic panel located just below your keyboard. You can use the static-sensitive panel of the touchpad and slit it to move the cursor. You can use the buttons below the touchpad as left and right mouse buttons.



TouchPad Precautions

The TouchPad is a pressure sensitive device. Please take note of the following precautions.

- Make sure the TouchPad does not come into contact with dirt, liquids or grease.
- Do not touch the TouchPad if your fingers are dirty.

-
- Do not rest heavy objects on the TouchPad or the TouchPad buttons.

You can use the TouchPad with Microsoft Windows as well as non-Windows applications.

Connecting an External Tracking Devices

The system will only enables you to use one tracking device whether it is an internal or external tracking device.

Data Storage and Retrieval

Data storage and retrieval are two of the most fundamental tasks you will perform when working with your computer. The Notebook is equipped with a hard disk drive (HDD). The HDD is removable allowing for easy upgrades.

The CD-ROM/DVD-ROM/Combo

Features of the CD-ROM/DVD-ROM/Combo Module

The features of the CD-ROM/DVD-ROM/Combo drive are listed below.

- The Audio Play feature allows you to play music CDs
- Front panel load/unload button
- Supports CD-DA, CD-ROM mode 1 and mode 2, Multi-Session Photo CD™, CD-I/Video CD (pcs.)
- Low power consumption
- 12.7mm height

Precautions for Handling CD-ROM/DVD-ROM/Combo Discs

- Always hold the disc by the edges, avoid touching the surface.
- Use a clean, dry, cloth to remove dust, smudges, or fingerprints. Wipe from the center outward.
- Do not write or place objects on the surface of the disc.
- Store discs in a cool dry place not to damage the disc.
- Do not use benzene, thinners, or cleaners with detergent. Only use CD-ROM/DVD-ROM cleaning kits.
- Do not bend or drop the discs.

Loading a Disc

To play a CD disc, follow the instructions listed below.

1. Push the CD-ROM/DVD-ROM/Combo eject button on the CD drive door. Gently pull the tray all the way out.
2. Carefully lift the CD-ROM/DVD-ROM/Combo by the edges and make sure the shiny surface is face down (the side with no writing on it). Carefully insert the CD-ROM onto the tray. Push the CD-ROM/DVD-ROM down gently so that it snaps onto the center ring.
3. Push the tray back into the drive.

To remove a disk, do the following:

1. Check the LED display and make sure that the computer is not accessing the CD-ROM/DVD-ROM drive.
2. Push the eject button and pull the tray all the way out.

-
- Carefully pick up the CD disk by the edges and – while pressing down on the center ring – remove the CD-ROM/DVD-ROM/Combo from the tray.

NOTE: *Do not insert any foreign objects into the disc tray. If you experience difficulty when ejecting the CD disk tray, stretch a paper clip (or use a pin or a thin metal rod) and insert it into the emergency eject hole located on the right side of the front panel. The CD disk tray should eject immediately. This procedure can also be used to remove a CD from the drive when the Notebook is powered off.*

PCMCIA Cards and Expansion Sockets

The Notebook features one PCMCIA expansion socket design to interface with one Type II card.

Inserting a PCMCIA Card

The computer will emit a medium tone followed by a high tone when a PC card is inserted. When you eject a card, the computer will emit a high tone followed by a medium tone. You can insert and remove a PC card whether the computer is turned **On** or **Off**.

Follow these instructions to insert a PCMCIA card:

- Hold the PCMCIA card with the arrow side up and the connector side toward the socket.
- Align the card connectors with the socket and carefully slide into the socket until it locks into place. The system will beep once to indicate that it has detected the PC card.

To remove a PC card push the eject button, the button will pop out, push the button again to eject the PCMCIA.

NOTE: *When inserting a Type II PC card, make sure the connector is inserted in the socket. Before ejecting a PC card, ensure that it is not being accessed by the System. For example, if the message “Write protect error writing Drive x” is displayed, the user has to change the write protect switch setting on the memory card. To change the switch setting, (a) eject the card, (b) change the switch setting, and (c) re-insert the card.*

CAUTION: Always disconnect all telephone lines from the wall outlet before servicing or disassembling this equipment. To reduce the risk of fire, use only No. 26 AWG or larger telecommunication line cord.

Power Saving Modes

This section contains information on the Notebook’s power system, including the AC Adapter, the battery system, recharging the battery, and tips for conserving battery power.

The power system is comprised of two parts, the AC Adapter and the battery system. The AC Adapter converts AC power from a wall outlet to the DC power required by the computer.

The Battery Power System

A fully charged pack will provide approximately 2 hours of battery life depending on your system configuration application it runs.

Before using the computer on battery power for the first time, check the battery status icon on the Windows Toolbar to make sure the battery is fully charged.

See Battery Status later in this section for a description and explanation of the Windows Battery icon. Charging the battery takes about 3 hours to charge when the system is in off state. If

possible, always charge the battery completely.

Removing the Battery Pack

To remove the battery pack from its compartment, please refer to Chapter Two, ***Inserting and Removing the Battery Pack***.

Preparing the Battery Pack for Use

Before using the battery pack for the first time, the Smart Battery IC within the battery pack should be calibrated in order to get accurate reporting of remaining battery life status.

To calibrate the battery pack follows the instructions below:

1. Insert the battery into the battery compartment and turn on the Notebook. If the battery is completely without power go to the next step.

Otherwise, let the battery run down until the battery low-low warning beeps are heard. The system will automatically enter Suspend mode.

2. Turn the Notebook off. Connect the AC adapter and let the battery fully recharge. When the battery charge indicator turns off, the battery is fully charged.
3. Turn On the notebook, let the battery run down until the battery is in low-low state and you hear a warning beeps. The system will automatically enter the Suspend mode. You can now connect the AC adapter.
4. The battery pack is now calibrated properly.

In general, using the battery until the low-low battery-warning indicator appears and fully recharges the battery each time (full discharge/charge cycle) will ensure the accurate reporting of the battery gauge status.

Automatic Battery Pack Charging Function

You can automatically charge the battery pack by using the AC Adapter. The charge time is about three hours when the Notebook power is turned off. The following table summarizes the charging modes:

Charge Mode	Charge Time
Fast	3 hours with the system off or in Suspend mode. The temperature must be 25°C or below room temperature.
Pre-Charge	A pre-charge is supplied to the Li-Ion battery pack.

Battery Status

Windows 98/ME/2000/XP has an applet in the Control Panel that will display an icon in the Windows taskbar indicating when the Notebook is running on battery power or is attached to the AC adapter.

This applet also displays a meter that indicates how much charge is remaining in the battery.

Battery Low Warning

When the pack initially reaches the “Battery Low” state approximately 10 ~ 15 minutes of the usable battery life is left.

You will hear an audible beep signal every 1.5 seconds alerting you to the “Battery Low” status. When the battery power reaches the “Battery Low Low” status the beeping sound will accelerate.

Your battery now has 1 ~ 2 minutes of battery charge remaining. You must save your data or connect AC power immediately; otherwise, you may lose your data.

Sound	Meaning
Continuous beeping every 1.5 seconds	Battery Low: Indicates that there is 7 to 10 minutes charge remaining.
Beeping accelerates	Battery Low Low: Indicates that there is 1 to 2 minutes of battery charge remaining. Save your work and turn off the Notebook, or connect the AC adapter.

When there is only one minute of battery charge remaining, the Notebook will suspend to the HDD and power off. You should connect AC power and resume to save your work.

Small Battery for the Real Time Clock

There is a small built-in battery pack that supplies power to the system in order to maintain certain system information while the power is off. If the Notebook is left without a power source for long period of time, this battery will be exhausted and system information will be lost.

WARNING:

Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions. Never remove the battery pack while the power is on as this may result in data loss when the system loses power.

Resetting the System

After installing a software application package, you may be prompted to reset the system to load the changed operating environment. To reset the system, or “reboot,” press the **[Ctrl] + [Alt] + [Delete]** keys simultaneously. This is known as “warm boot.” This key combination acts as “software” reset switch when you encounter hardware or software problems, which lock up the

Notebook.

If this key combination does not shut down the Notebook, you can reset the Notebook by using the Notebook's power button. Should the Notebook lock up for some reason, pressing this button powers the Notebook off.

Adjusting the Brightness

To adjust the brightness on the LCD screen, press and hold down the **[Fn]** key in the lower left hand corner of the keyboard and press the **[F7]** key to reduce the brightness or **[F8]** to increase the brightness.

Chapter 4

Desktop Operation

Your notebook is capable of providing you with efficient and productive mobile computing, it also has the speed and capacity to service as a desktop system.

This chapter discusses those functions of your notebook that are typical of desktop systems.

Audio

The Multimedia Sound System

The Notebook's built-in audio capabilities allow you to take advantage of a wide range of education and entertainment multimedia software. The Notebook is equipped with two internal stereo speakers, a microphone, and input audio ports for external audio units.

An external microphone can be connected to the microphone jack. External speakers or headphones can be connected to the Notebook's audio-out jack.

External audio devices can be connected to the Line in jack. All audio features are software controlled. The Notebook's multimedia sound system includes the following features:

- Supports Windows Sound System compatibility
- Full Duplex operation
- Dynamic filtering reduces noise and distortion rate
- 16-bit digitized audio playback
- A built-in microphone for convenient recording
- Two built-in stereo speakers
- Digitized audio recording through the Notebook's built-in microphone or any external source

Audio Volume Control

The Notebook is equipped with hot-key volume controls: Pressing the **[Fn] + [F3]** hot-key combination decreases the audio output volume, press the **[Fn] + [F4]** hot-key combination increases the audio output volume.

Audio Software

Your notebook comes equipped with an integrated sound system capable of providing you with quality audio sound through the built-in speakers or through external speakers connected via the system ports.

Sound Recording

Your system allows you to record sounds and store them as files using the microphone via the microphone jack on the rear of the notebook computer. Check the Windows Help and Support Center in Windows for information on using the various elements in sound recording.

NOTE: *For a high-quality sound, click on the "Volume Control" at the lower right end of your screen. From the Volume Control windows, click on the "Advanced" tab, click and select the "Microphone Boost" item.*

Playing Sound Files

Your notebook can play audio files stored in MIDI, WAVE or MP3 file format. Check the Help and Support Center in Windows for information on the functions of the Media Player.

External Speakers and Microphone

The sound system is capable in providing high-quality sound to external speakers and receiving and processing sounds from an external microphone or external sound source.


Connecting Peripheral Devices

To expand your computing capabilities, you can add a variety of external devices to your computer. You may, for example, want to add a mouse, modem, or a printer.

The computer is equipped with several interface ports, including an enhanced parallel (printer) port, a serial port, and USB ports. These are provided as a means of connecting peripheral devices to the computer.

Connect peripheral devices to the computer's interface ports as shown below:





Chapter 5

***Running BIOS
Setup***

Introduction

The BIOS (Basic Input and Output System) Setup program is a menu driven utility that enables you to make changes to the system configuration and tailor your system to reflect installed hardware or alter system performance. When the notebook computer is turned back on, the system is configured with the values stored in CMOS.

Navigating through BIOS Setup

The Setup program has been designed to make it as easy to use as possible. If you accidentally make a setting and don't know which one to switch back to, the Setup program has a hot key that allows you to return to the previous value.

Accessing the BIOS Setup Program

To access the BIOS Setup program, press the Del key after the notebook computer has run through its POST.

Item Specific Help

On the right side of the Setup screen is an area labeled Item Specific Help. This area will list navigation key shortcuts and information that is specific for the item that you are currently editing.

The Menu Bar

The top of the screen has a menu bar with the following selections:

Standard CMOS Setup

Set the time and date. Configure disk drives.

Advanced CMOS Setup

Configure basic system performance parameters.

Peripheral Setup

Configure I/O support for the Notebook computer.

To access the menu bar items, press the ↑ up or ↓ down arrow key on the keyboard until the desired item is highlighted.

The Legend Bar

At the bottom of the Setup screen you will notice a legend bar. The keys in the legend bar allow you to navigate through the various setup menus.

The following table lists the keys found in the legend bar with their corresponding alternates and functions.


Legend Key	Function
Esc	Jumps to the Exit menu or returns to the Main menu from a submenu.
↑ or ↓	Moves the cursor up and down between fields.
PgUp/PgDn	Set to modify the field selected.
F2/F3	Set the color (8 colors) of the BIOS Setup screen.
F10	Save and Exit.
Enter	Will select a sub menu or show a range of options for a field.

Save Changes and Exit the Setup Program

Refer to the "Save Settings and Exit" section of this chapter for detailed information on saving changes and exiting the setup program.

The Standard CMOS Setup

When the Setup program is accessed, the following screen appears:



Date/Time


The current values for each category are displayed. Enter new values through the keyboard.

Pri Master, Sec Master

Select one of these hard disk drive icons to configure the hard disk drive named in the option.

The Advanced CMOS Setup

When the Setup program is accessed, the following screen appears:



Quick Boot

Set this option to Enabled to instruct AMIBIOS to boot quickly when the computer is powered on.

- **The settings are Disabled or Enabled (default value).**

1st Boot Device

This option sets the type of device for the first boot drives that the AMIBIOS attempts to boot from after AMIBIOS POST completes.

- **The settings are Disabled, HDD (default value), CD/DVD and USB FDD.**

2nd Boot Device

This option sets the type of device for the second boot drives that AMIBIOS attempts to boot from after AMIBIOS POST completes.

- **The settings are Disabled, HDD, CD/DVD (default value) and USB FDD.**

3rd Boot Device

This option sets the type of device for the third boot drives that the AMIBIOS attempts to boot from after AMIBIOS POST completes.

- **The settings are Disabled, HDD, CD-ROM and USB FDD (default value).**

TouchPad Support

Set this option to enabled or disabled the touchpad. The default setting is Enabled.

Password Check

This option enables password checking every time the system boots or when you run AMIBIOS Setup. If Always is chosen, a user password prompt appears every time the computer is turned on. If Setup is chosen, the password prompt appears if AMIBIOS is executed.

Share Memory Size

This field shows the share memory size available.

- **The settings are 16M/32M/64MB (default value)**

Graphic Win Size

This field shows the graphic win size available.

- **The settings are 64M (default value)/128M/256M**

USB Keyboard/Mouse/FDD Legacy Support

Set this option to Enabled to enable support for older keyboards and mouse devices if the USB Function option is set to Enabled.

- **The settings are Enabled or Disabled.**

The Peripheral Setup

AMIBIOS SETUP - PERIPHERAL SETUP (C)2000 American Megatrends, Inc. All Rights Reserved		
TV Display Type	NTSC	Available Options: PAL ▶ NTSC
TV PAL Display Type	N/A	
IEEE1394 Device	Enabled	
IR Port Support	Enabled	
IR Mode Select	FIR	
OnBoard Parallel Port	Enabled	
Parallel Port Mode	ECP	
ESC: Exit ↑↓:Sel PgUp/PgDn: Modify F2/F3:Color		

TV Display Type

This field allows you to choose the television display option when using the TV out port.

-
- **The settings are PAL, NTSC (default value).**

TV PAL Display Type

This field allows you to choose the television PAL system type.

- **The settings are PAL (default value), PAL-M, PAL-N.**

IEEE 1394 Device

This option specifies the IEEE 1394 device in your system.

- **The settings are Disabled or Enabled (default value)**

IR Port Support

This option specifies the IR port address for the IR Port.

- **The settings are Disabled or Enabled (default value).**

IR Mode Select

This option specifies the infrared transmission method.

- **The settings are SIR or FIR (default value).**

OnBoard Parallel Port

This option specifies the base I/O port address of the parallel port on the motherboard.

- **The settings are Enabled (default value) or Disabled.**

Parallel Port Mode

This option specifies the parallel port mode.

- **The settings are Normal, Bi-dir, EPP or ECP (default value).**

Change Supervisor Password

This field allows you to set the Supervisor password. To set the Supervisor password, highlight this field and press the [Enter] key. The following dialog box appears:

Enter new supervisor password:

Auto Configuration with Optimal Settings

The optimal default settings are best-case values that should optimize system performance. To set the configuration, highlight this field and press the [Enter] key. The following dialog box appears:

Load high performance settings [Y/N] ?

Battery Calibration

This option helps execute the calibration of the system battery.

Execute Battery Calibration [Y/N] ?

Save Settings and Exit

This option saves your selections and exit the Setup program.

Save current settings and exit [Y/N] ?

Exit Without Saving

This option should only be used if you do not want to save the changes you have made to the Setup program.

Quit without saving [Y/N] ?

Chapter 6

*The Software
Utilities Disks*

USER'S INFO: There are two separate procedures on how to install the driver: **AutoRun installation** and **Manual installation**.

AutoRun Installation

- Follow the step-by-step procedures on the CD-ROM/DVD-ROM to execute the “AutoRun” application by selecting the topic of “Driver Installation”.
- To re-run the “AutoRun” installation, please refer to the procedures on the “Manual Installation” for a more detailed explanation.



NOTE:

If you encounter this message when executing the Auto Run in Windows 2000, please perform the following procedures:

Click on the “Start” – “Setting” – “Control Panel” – “System” – “Advanced” tab – “Performance” tab – “Change” tab – reduce the maximum Virtual Memory setting to 200MB.

Installing VGA Display Drivers for Win98/2K/ME/XP

This section describes the operation and installation of VGA display software drivers supplied on the Driver Utility CD-ROM that is shipped with your computer.

-
1. Insert the CD-ROM Driver into your CD-ROM/DVD-ROM drive.
 2. Click “Start” and Select “Run”.
 3. Type the following:
D:\Driver\VGA\Win2K&XP\Setup.exe or D:\Driver\VGA\Win98&ME\Setup.exe (If D is not your CD-ROM/DVD-ROM drive, substitute D with the correct drive letter).
 4. Click on “Setup” to begin the Installation Wizard.
 5. Follow the Wizard’s on-screen instructions to complete the installation.
 6. Restart the system.

Intalling the Audio Driver for Win98/2K/Me/XP

To install the audio driver you must first remove the currently installed driver.

1. Insert the CD-ROM Driver into your CD-ROM/DVD-ROM drive.
2. Click “Start” and Select “Run”.
3. Type the following: D:\Driver\Audio\Setup.exe (If D is not your CD-ROM/DVD-ROM drive, substitute D with the correct drive letter).
4. Click on “Setup” to begin the Installation Wizard.
5. Follow the Wizard’s on-screen instructions to complete the installation.
6. Restart the system.

Intalling the IR Driver for Win98/2K/Me/XP

To install the audio driver you must first remove the currently installed driver.

1. Insert the CD-ROM Driver into your CD-ROM/DVD-ROM drive.
2. Click “Start” and Select “Run”.
3. Type the following: D:\Driver\IR\Setup.exe (If D is not your CD-ROM/DVD-ROM drive, substitute D with the correct drive letter).
4. Click on “Setup” to begin the Installation Wizard.
5. Follow the Wizard’s on-screen instructions to complete the installation.
6. Restart the system.

Intalling the LAN Driver for Win98/2K/Me/XP

To install the LAN driver you must first remove the currently installed driver.

1. Insert the CD-ROM Driver into your CD-ROM/DVD-ROM drive.
2. Click “Start” and Select “Run”.
3. Type the following: D:\Driver\LAN\Setup.exe (If D is not your CD-ROM/DVD-ROM drive, substitute D with the correct drive letter).
4. Click on “Setup” to begin the Installation Wizard.
5. Follow the Wizard’s on-screen instructions to complete the installation.

-
6. Restart the system.

Installing the TouchPad Driver for Win98/2K/Me/XP

To install the touchpad driver you must first remove the currently installed driver.

1. Insert the CD-ROM Driver into your CD-ROM/DVD-ROM drive.
2. Click “Start” and Select “Run”.
3. Type the following:
D:\Driver\Touchpad\Win2K&XP\Setup.exe or D:\Driver\Touchpad\Win98&ME\Setup.exe (If D is not your CD-ROM/DVD-ROM drive, substitute D with the correct drive letter).
4. Click on “Setup” to begin the Installation Wizard.
5. Follow the Wizard’s on-screen instructions to complete the installation.
6. Restart the system.

Installing the USB20 Driver for Win2K/XP

To install the USB20 driver you must first remove the currently installed driver.

1. Insert the CD-ROM Driver into your CD-ROM/DVD-ROM drive.
2. Click “Start” and Select “Run”.
3. Type the following:
D:\Driver\USB20\USB20.exe (If D is not your CD-ROM/DVD-ROM drive, substitute D with the correct drive letter).

-
4. Click on “USB20” to begin the Installation Wizard.
 5. Follow the Wizard’s on-screen instructions to complete the installation.
 6. Restart the system.

Installing the Hotkey Driver for Win98 only

To install the Hotkey driver you must first remove the currently installed driver.

7. Insert the CD-ROM Driver into your CD-ROM/DVD-ROM drive.
8. Click “Start” and Select “Run”.
9. Type the following:
D:\Driver\Hotkey\Win98\Setup.exe (If D is not your CD-ROM/DVD-ROM drive, substitute D with the correct drive letter).
10. Click on “Setup” to begin the Installation Wizard.
11. Follow the Wizard’s on-screen instructions to complete the installation.
12. Restart the system.

Installing the MiniPCI Modem Driver for Win98/ME/2K/XP

Please follow these instructions to install the Modem driver:

1. Insert the CD-ROM Driver into your CD-ROM/DVD-ROM drive.
2. Click “Start” and Select “Run”.

-
3. Type the following:
D:\Driver\MiniPCI\PREWELL\Modem\Win2KXP\Setup.exe or
D:\Driver\MiniPCI\PREWELL\Modem\Win98\Setup.exe
D:\Driver\MiniPCI\PREWELL\Modem\WinME\Setup.exe
(If D is not your CD-ROM/DVD-ROM drive, substitute D with the correct drive letter).
 4. Click on “Setup” to begin the Installation Wizard.
 5. Follow the Wizard’s on-screen instructions to complete the installation.
 6. Restart the system.

Installing the MiniPCI Combo Card Driver for Win2K/XP

Please follow these instructions to install the Modem driver:

1. Insert the CD-ROM Driver into your CD-ROM/DVD-ROM drive.
2. Click “Start” and Select “Run”.
3. Type the following:
D:\Driver\MiniPCI>Actiontec\Modem\Win2KXP\Setup.exe (If D is not your CD-ROM/DVD-ROM drive, substitute D with the correct drive letter).
4. Click on “Setup” to begin the Installation Wizard.
5. Follow the Wizard’s on-screen instructions to complete the installation.
6. Restart the system.

Please follow these instructions to install the Wireless LAN driver:

-
1. From Start, click on the "My Computer" icon and click the "View System Information".
 2. Click on the "Hardware" tab from the "System Properties" dialog window.
 3. Click the "Device Manager" button.
 4. Double click on the "Other Devices" , double click the " Network Controller " and click on the "Driver" tab.
 5. Click the "Update Driver" tab and select the "Install from a list or specific location (Advanced)" item and click "Next".
 6. Select the "Include this location in the search" item and click on the "Browse" button and specify for the designate location of your CD driver
D:\Driver\MiniPCI\Actiontec\LAN\WinXP or
D:\Driver\MiniPCI\Actiontec\LAN\Win2K to proceed with the installation.

Manual Installation

To install the driver manually, follow the step-by-step procedures described on each individual section for a more clear installation.

Installing the CardBus Driver for WinXP

Please follow these instructions to install the cardbus driver:

1. From Start, click on the "My Computer" icon and click the "View System Information".
2. Click on the "Hardware" tab from the "System Properties" dialog window.

-
3. Click the "Device Manager" button.
 4. Double click on the "PCMCIA adapters" , double click the "Generic CardBus Controller" and click on the "Driver" tab.
 5. Click the "Update Driver" tab and select the "Install from a list or specific location (Advanced)" item and click "Next".
 6. Select the "Include this location in the search" item and click on the "Browse" button and specify for the designate location of your CD driver d:\Driver\Cardbus\WinXP to proceed with the installation.

Installing the CardBus Driver for Win2K

Please follow these instructions to install the cardbus driver:

1. From your screen, click on the "My Computer" icon and use your mouse or touchpad right button to select the "Properties" item.
2. Click on the "Hardware" tab from the "System Properties" dialog window.
3. Double click to enter the "Device Manager" window.
4. Click on the "PCMCIA adapters",select the "Generic CardBus Controller" and click on the "Driver" tab.
5. Click the "Driver" tab then click the "Update Driver" item.
6. Select the "Search for a suitable driver for my device (recommended)" item and click "Next".

-
7. Click "Browse" button and specify for the designate location of your CD driver D:\Driver\Cardbus\Win2K to proceed with the installation.

Installing the CardBus Driver for WinME

Please follow these instructions to install the cardbus driver:


1. From your screen, click on the "My Computer" icon and use your mouse or touchpad right button to select the "Properties" item.
2. Click on the "Device Manager" tab from the "System Properties" dialog window.
3. Click on the "PCMCIA socket", double click the "Generic CardBus Controller" and click on the "Driver" tab.
4. Click the "Update Driver" tab and select the "Specify the location of the driver (Advanced)" item and click on the "Next" tab.
5. Select the "Specify a location" item
6. Click "Browse" button and specify for the designate location of your CD driver D:\Driver\Cardbus\WinME.

VGA Utilities

After you have restarted Windows, open the "Control Panel" and double click on the "Display" icon. From the "Display Properties" window, select the "Settings" tab and click on the "Advanced" tab to enter the "SiS 650_651_M650_740 Properties" window.


You will notice three new entries have been made in the Display Properties window:

Display Mode Setting, Video Setting, and Gamma Correction.



Driver Mode Setting

The SiS's driver allows three simultaneous outputs to LCD, LCD/CRT and CRT. Before proceeding, be sure the monitor is connected to the computer.



Driver Mode

This define the two status of Single, Mirror and Multi Monitor (when an external monitor is

connected to your notebook computer).

- When the "Single" is selected, the display can only be seen on the notebook computer LCD panel or external monitor.
- When the "Mirror" is selected, you can toggle between the LCD and CRT display. Both the LCD and CRT screen display the same image.

Display Combination

This applies to the display that you prefer to use. The options are VGA1 and LCD2.

REMINDER: The "Auto" tab will serve as additional function of the "Mirror" and "VGA1" respectively by removing the ✓ check mark under the "Display Combination" selection field.

- Select "VGA1" if you want the picture to only display on the monitor screen.
- Select "LCD2" if you want the picture to only display on the notebook computer screen.

NOTE: *Use the [Fn] + [F12] hot keys to toggle between the LCD and external monitor display. If you prefer to use only one display in operating your system, press the [Fn] + [F12] hot keys will shut down the LCD display, external monitor display or both at this random order.*

Single

This function will only show one single display whether it be on your notebook computer or external monitor.

Mirror (Simultaneous Display)

This function supports two asynchronous simultaneous display paths with the features of LCD, LCD/CRT or CRT).

1. Click on the “Control Panel” and double click on the “Display” icon. Click on the “Settings” tab to enter the “Display Properties” window. Click on the “Advanced” button.
2. From the “SiS 650_651_M650_740 Properties” window, click on the “Display Modes” tab. Select the "VGA1" or "LCD2" tab by clicking on the button to enable and connect the video display to the external CRT screen.
3. Click on the “Apply” tab and you will be ask to keep the new setting. The notebook computer and external monitor/TV screen will now simultaneously display the same image.

Multi-Monitor

"Multi-Monitor" is only applicable when the function of "Dual View" is being access. This function will only be available if an external monitor is connected to your notebook computer.

Use this to achieve a large desktop display on a small size screen. To do this:

- Adjust the screen resolution by increasing the desktop area in the “Display Area”.
- Use your touch pad or mouse cursor to point at any area of the screen to move the window screen to a larger view.

To achieve the “Dual View” function, follow the procedures below:


4. Click on the “Control Panel” and double click on the “Display” icon.
5. Click on the “Settings” tab to enter the “Display Properties” window.
6. Use the cursor to click on the Monitor “2” screen on the sub-screen of the “Display Properties” window.



7. A message is shown on your screen to ask you whether to enable the monitor that you have chosen.
8. Click “Yes” to accept the change. Click the “Apply” tab to run the function and restart the computer.
9. After the system has restarted, your notebook computer LCD screen and the external monitor screen are connected with each other. From the LCD display, open the “Display Properties” and use the cursor to drag it to the right thus moving the image to the external monitor screen.


Video Setting

From the "Setting", you can also adjust the video of your display to overlay, contrast or brightness.



Gamma Correction

You can adjust the right color for your window screen by moving the “Brightness” adjustment window to increase or decrease the right resolution for your screen display.



Troubleshooting

Chapter 7

This chapter describes locating and solving problems that you may encounter while using your computer.

Locating a Problem

Problems with your computer can be caused by something as minor as an unplugged power cord – or as major as a damaged hard disk. The information in this chapter is designed to help you find and solve minor problems. If you try all the suggested solutions and you still have a problem, make a list of what steps you have taken to correct the problem and contact your dealer.

Successful troubleshooting is the result of careful observation, deductive reasoning, and an organized approach to solving the problem.

The problems that you will encounter can be divided into two basic categories: hardware problems and software problems. Hardware problems can be further divided into electrical and mechanical problems. You will know you have a hardware problem if the screen is dark, the computer cannot read the disk drives, or you get an error message during the Power-On Self Test (POST).

Software errors can occur at several levels. The ROM BIOS and the operating system can give you a large number of error messages. On top of this, each application software package has its own set of error messages. It is important to determine whether the software error message you are getting is from the application or the operating system. Once you know this, you can look in the respective manual for a solution to the problem.

Checking Cables and Connections

Start by performing a careful visual inspection of the exterior of the computer. If no LEDs are illuminated, make sure that your computer and its peripherals are getting power and

communicating with each other properly.

To check the power cables, and connections:

1. If you have been using battery power, connect the Notebook to an external power source and make sure that the battery has a charge.
2. If you are using the Notebook with the AC adapter, check the power outlet, the power cord, and any power switches that may affect your computer.
 - Check the wall outlet or power strip with an item that you know is functioning properly. A lamp or radio is a convenient item for checking the power. You may also need to check the fuses and breakers in your electric box.
 - If the outlet is controlled by a wall switch, make sure that the switch is on.
 - If the outlet is controlled by a dimmer switch, use a different outlet.
 - If your computer is plugged into a power strip with an On/Off switch, make sure the switch is on.
3. With the computer's power switched off, check all cable connections. If the computer is connected to any peripheral devices, look for loose or disconnected cables.

If the computer is too close to a wall, a cable connection may be loose or the cables may be crimped.

NOTE: *Do not substitute cables for different devices (other than the manufacturer recommended cables) even if they look exactly alike. The wiring inside the cable may be different.*

4. When you are certain that you have power available and all connections are good, turn the computer on again. If the computer still does not start, you may have a hardware problem.

The Power-On Self Test

The Power-On Self Test (POST) runs every time you turn on or reset the Notebook. The POST checks memory, the main system board, the display, the keyboard, the disk drives, and other installed options.

A few seconds after you turn on your computer, a copyright message appears on your display screen. A memory test message appears next; as the test continues, memory size increases until all installed memory is tested. Normally, the only test routine visible on the screen will be the memory test.

Two classifications of malfunctions can be detected during the POST:

- Error messages that indicate a failure with either the hardware, the software, or the *Basic Input/Output System* (BIOS). These *critical malfunctions* prevent the computer from operating at all or could cause incorrect and apparent results. An example of a critical error is microprocessor malfunction.
- Messages that furnish important information on the power-on and boot processes (such as memory status). These *non-critical malfunctions* are those that cause incorrect results that may not be readily apparent. An example of a non-critical error would be a memory chip failure.

In general, if the POST detects a system board failure (a critical error), the computer halts and generates a series of beeps. If failure is detected in an area other than the system board (such as the display, keyboard, or an adapter card) an error message is displayed on the screen and testing is stopped. It is important to remember that the POST does not test all areas of the computer, only those that allow it to be operational enough to run diagnostic programs.

If your system does not successfully complete the POST, but displays a blank screen, emits a series of beeps, or displays an error code, consult your dealer.

General Hardware Problems

A few common hardware problems and suggested solutions are presented in the table below:

Problem: **Failure in the installation of the Audio driver.**

Solution: Be sure to first remove the current audio device from your system. Please follow the instruction on the installation of audio driver.

Problem: **The display screen is dark**

Solution: Make sure that the computer is not in Suspend mode. Check the Brightness controls for the screen. If the controls are turned too far down, the screen will be dark.

Problem: **An incorrect date and time are displayed.**

Solution: Correct the date and time using the DOS DATE and TIME commands or the options in the Setup Utility. If the date and time become incorrect after a short time, your CMOS battery may be depleted. Contact your dealer to change the battery.

Problem: **The message: "Invalid system disk, Replace the disk, and then press any key" appears during boot.**

Solution: Check and make sure that you do not have a non-bootable floppy diskette inserted in your floppy drive. If your USB FDD is empty, you may not have an operating system installed on your drive. Contact technical support for assistance.

Problem: **You hear irregular beeps during operation of the Notebook and the system**

halts.

Solution: The problem is beyond the scope of this manual. Contact technical support.

Problem: **An unidentified message is displayed.**

Solution: Reboot the computer and run the BIOS system setup. Confirm the Setup parameters. If the same message is displayed after booting up again, contact technical support for assistance.

Problem: **The system cannot access the CD-ROM/DVD-ROM drive.**

Solution: Check that a CD is properly inserted in the drive. Make sure that you are using the correct program for that kind of CD. For example, the system cannot read a data CD using an audio program.

Problem: **You cannot operate the printer.**

Solution: Check the printer cable connection. Ensure that the printer power switch is turned on. Confirm that the printer is on-line.

Problem: **You can't save data to disk.**

Solution: Ensure that the disk has been formatted. Consult your operating system manual for information on formatting floppy diskettes.

Problem: **The diskette is write-protected.**

Solution: Eject the diskette, remove the write protection, and try again.

Problem: **The diskette is full.**

Solution: Try using another diskette or free up some space on the diskette. The disk drive is not operating. Contact your dealer for support.

Problem: **You cannot use the mouse.**

- Check the cable connection.
- Check the mouse with another application to see if there is a software incompatibility problem.
- If possible, check the mouse with another computer to see if it works. If it doesn't operate on a different system, the mouse might be broken.

Contacting Your Dealer

If you still have a problem after reading the preceding sections, the next step is to contact your dealer. Your dealer can determine if the problem is something that requires the computer to be taken to the shop. Before you call your dealer, however, prepare the following information:

- How is your computer configured? Your dealer needs to know what peripheral devices you are using.
- What messages, if any, are on the screen?
- What software were you running at the time?
- What have you done already to try to solve the problem? If you have overlooked a step, your dealer may be able to solve the problem over the phone.

*Upgrading your
System*

Chapter 8

Upgrading your Memory

Refer to the following instructions and illustration for information on upgrading your notebook's memory.



1. Turn off the computer and disconnect the AC adapter and all peripherals.
2. Turn the notebook over so that the rear ports are facing you and locate the memory module compartment.

-
3. Remove the screws that secure the RAM module compartment cover and set it aside in a safe place.
 4. Remove the compartment cover and then angling it up and out.
 5. If you need to install a higher capacity module, gently push the edge clips on both sides to release the module. Angle the card slightly upward and gently slide it from its edge connector slot. Store the card in the anti-static bag that contains your new module(s).
 6. To install the new memory card, hold the card with its gold edge connector toward the edge connector slot of the compartment. To help you orient the cards, the edge connector has been made with two unequal-length sections. You will only be able to insert the card in one direction.
 7. Insert the edge connector into the slot. The gold edge connector of the card should not be visible when the card is fully inserted.
 8. Press the card downward where you should hear an audible click as the latches of the connector secure the card in place.
 9. Once the module is properly seated, you can replace the cover on this compartment.
 10. Replace and tighten the screw.

The Easy to Upgrade HDD Module

The hard drive in your notebook computer is made to be easily swapped out for upgrading. You should back up your hard drive before attempting to change the hard drive.

WARNING:


Make sure that before you install a new drive, all the files in your system should be backed up.

To upgrade your Hard Drive

1. Power down the system completely. Turn the system over with the front of the unit facing you.
2. Remove the three screws that secure the compartment cover and set them in a safe place.
3. Slide the HDD cover away from the compartment.



4. The drive is attached to a special bracket that secures it to the notebook computer. There are 4 screws hold the bracket. Remove the screws and set them in a safe place.
5. Push the HDD slightly in the direction of the arrow as shown in the illustration to release it from the pins of the drive.
6. Gently hold the grip of the HDD, lift it up to release from its compartment.



7. To install the new HDD, you will need to align the tabs on the drive bracket with the slots on the bay. Press down gently on the drive bracket until it engages with the system. Do not force the drive into place this can bend the pins on the hard drive.
8. Slide the compartment cover into place and be sure the screw holes on the cover align completely with the screw holes in the case.
9. Secure the cover with the three screws.

Upgrading your System CPU

Refer to the following instructions and illustration for information on upgrading your notebook's CPU

1. Turn off the computer and disconnect the AC adapter and all peripherals. From the rear side of your notebook, use your index finger to lift up the hinge cover attached to the LCD screen.




2. Bend your LCD screen into 90 degree angle then carefully lift up the hinge cover.



-
3. Remove the screen that is attached to the keyboard in order to remove the heatsink on top of the CPU.



4. Remove all the screws attached to the heatsink.
5. Before removing the screws, there are certain measures to followed in removing the heatsink



6. To remove the heatsink, first loosen the screw carefully.

-
7. After loosening one screw, be certain that the next to be loosen should be the screw on its adjacent side as shown on the illustration.



Be sure to loosen all the screws first before removing it totally to release the heatsink. Failure to do so will cause a major damage to the heatsink.

8. Now you can totally remove all the screws also in that order when you first loosen the screw.



Specification

Appendix A

Detailed Notebook Specifications

General

CPU

- Intel Mobile P4-M Northwood series 2.0GHz/2.2GHz/2.4GHz CPU, 512KB L2 cache on die
- 478 pin socket

Memory

- 2 expandable memory slot up to 2GB with 1GB technology
- 128/256MB memory options
- Two 200 pin DDR SO DIMM type memory slots
- 2.5V DDR SDRAM module
- Supports 133 MHz DDR DRAM

Core Logic

- North bridge SiS651, South bridge 962
- 4X AGP bus interface
- Supports host bus at 100 or 133MHz
- AGP v2.0 compliant
- 3.3V PCI version 2.2 compliance
- ACPI v2.0

- USB 2.0 compatible

Mass Storage

➤ ***HDD***

- Support enhanced IDE (PIO mode 4) and bus master (Ultra DMA 33/66/100 mode)
- Easily upgradable 2.5" 9.5mm HDD

➤ ***Module Bay***

- Supports CD-ROM/DVD-ROM/Combo Drive; 5.25" 12.7mm height
- Fast IDE and ATAPI interface CD-ROM/DVD-ROM/Combo Drive

➤ ***PCMCIA Sockets***

- 1 Type II, support CardBus

Pointing Devices

- Synaptics TouchPad
- Support four way scrolling feature

Keyboard

- US/Europe, DOS/V keyboard for Japan, full size keyboard alike pitch
- 300 mm keyboard with key stroke 3.0mm
- Twelve function keys and Windows Function key
- Internal keyboard works a standard 101/102 desktop keyboard
- 2 short-cut keys: WWW & eMail

Audio

-
- Dual full-duplex Direct Sound Channels
 - Hardware SoundBlaster Pro for real-mode DOS legacy compatibility
 - 18-bit ADC & DAC resolution
 - Support SPDIF out
 - AC'97 2.2 & PC2001 compliant

I/O Ports

- One parallel port supported EPP/ECP (25-pin female D-connector)
- One S-video TV out port for TV
- One DC input port for External AC adapter (2-pin DC jack)
- One Type II PCMCIA card socket
- One video port for external analog VGA monitor (15-pin female D-connector)
- USB 2.0 port x 2
- MIC-in, headphone jack w/ adaptor for 5.1 channel SP/DIP support
- RJ-11 jack for Fax/Modem
- RJ-45 jack for LAN
- IEEE 1394 mini-jack

Video System

Display

- 14.1 SXGA, 15.0" SXGA+/XGA TFT

Electrical

AC Adapter

- External universal type AC adapter, output maximum 65W

Smart Battery

- 8 x 103450 Li-Ion battery pack @53W
- User interchangeable
- Removable and rechargeable
- Charge modes - 3.5 hours to full charge when system is off or in suspend mode
- More than 2.0 hours of battery life time under Ziff-Davis Inc. BatteryMark 3.0 Test with Intel 478 pin Northwood 2.0GHz CPU and 14.0" TFT LCD installed at 25°C

Dimensions

- Weight: 3.9Kg (5.5 lbs) with 14.1" display panel, battery and DVD-ROM drive installed
- Size: 326.0mm (W) x 258.0mm (D) x 32mm (H) or 12.83" (W) x 10.17" (D) x 0.99" (H)

Operating Environment

Temperature

- Operating: 5°C ~ 35°C
- Storage: -20°C ~ 60°C

Humidity

- Operating: 30% ~ 90% (non-condensing)

-
- Non-operating: 10% ~ 90% (non-condensing)

Altitude

- Operating: -200 to 10,000 feet above sea level
- Non-operating: -200 to 30,000 feet above sea level.

Options

- Li-Ion battery pack
- Factory option: Fax/Modem miniPCI card, 802.11b wireless LAN + modem combo miniPCI card
- Factory option: K/B with dual-pointing touch pad four way scrolling
- Memory Extension card
- Module bay: CD-ROM/DVD-ROM/Combo (DVD-ROM+CD-RW) Drive

Accessories

- User's manual (option)
- Driver CD title
- AC adapter
- Power cord
- Battery pack

Software Specifications

System Software

- System BIOS: AMI BIOS
- Supported Operating Systems
 - Optional Windows 98SE
 - Optional Windows XP or above version
 - Optional Windows ME or above version
 - Optional Windows 2000 or above version
- Standard Software Drivers
 - VGA driver
 - Audio driver
 - TouchPad driver
 - IR driver (optional)
 - Modem driver
 - LAN driver
 - CardBus driver
 - USB20 driver
 - Hotkey driver (For Win98 only)