


# Communications Cards







# **Communications Cards**





# ISDN NB Card

Interface	NuBus
Processor	Motorola 68000 microprocessor operating at 10 MHz
Memory	512K of RAM, expandable to 1 MB
Rate Adaption Data Speeds	<ul><li>V.110 at 600, 1200, 2400, 3600, 4800, 7200, 9600, 14400, and 19200 bps</li><li>V.120 determined by the remote computer's terminal adapter, which also must use the V.120 protocol</li></ul>
Compatibility	AT&T 5ESS and Northern Telecom DMS-100 ISDN switches



Specifications	ISDN NB Card - 2
External Connectors	RJ-45 for basic rate (2B+D) four-wire S-interface according to CCITT I.430 specification RJ-11 connector for support of standard DTMF telephone
Miscellaneous	Built-in support for PS2 circuit power at the ISDN S-reference point





# Serial NB Card

Interface	NuBus
Processor	Motorola 68000 microprocessor operating at 10 MHz
Memory	512K of RAM, expandable to 1 MB
Data Transfer Speed	19.2 Kbps 64 Kbps (DMA-backed ports)
Power Dissipation	10 W
External Connector	DB-62





Specifications

# Coax/Twinax Card

Interface	NuBus
Processor	Motorola 68000 microprocessor operating at 10 MHz
Memory	512K of RAM, expandable to 1 MB
Application Programming Interface	Apple 3270 API
Coax Support	Category A






### **Power Dissipation** 10 W

**External Connectors** 

BNC (coax interface) DB-15 (twinax interface)











### Troubleshooting

# General

The Symptom Charts included in this chapter will help you diagnose specific symptoms related to your product. Because cures are listed on the charts in the order of most likely solution, try the first cure first. Verify whether or not the product continues to exhibit the symptom. If the symptom persists, try the next cure. (Note: If you have replaced a module, reinstall the original module before you proceed to the next cure.)

For additional assistance, contact Apple Technical Support.



# Symptom Charts

### **ISDN NB Card**

- I/O error occurs when you use MacISDN Config to verify hardware and software
- 1 Reinstall MacISDN software.
- 2 Verify hardware installation.
- 3 Restore ISDN NB Card to factory configuration. Disconnect external power supply (if connected). Shut down computer, wait a few seconds, then switch on computer.





### Serial NB Card

1

1

Self-test status LED stays red after power-up

- Switch off computer and reseat card.
- 2 Replace Serial NB Card.

- MacDFT icon missing from Control Panel
- Switch off computer and reseat card.
- 2 Replace Serial NB Card.

