

IBM ThinkPad 365E - withdrawn

IBM® ThinkPad®: >= 365E 10.4" dual scan		ThinkPad 365 strengths: ⇨ Entry-priced notebook ⇨ Extensive software preload ⇨ Infrared port ⇨ Optional Port Replicator with battery charger and palm rest
Processor Processor upgrade Memory cache Diskette drive CD-ROM	IBM 5x86c™ 100/33 MHz (Cyrix) / integrated math coprocessor None 16 KB in 5x86c (write back) / no L2 cache Internal 3.5" 1.44 MB (not removeable) None (can not upgrade)	
Price Type - model Preload (see side) Disk - capacity Disk - ms / interface Available date Withdrawn date	2625-W9A Windows 95 540 MB 13 ms / EIDE / PIO Mode 3 May 1996 October 1996	
Display - diagonal size Display - type Display - colors Display - contrast	10.4" Dual scan VGA color / 640 x 480 256 simultaneous colors 30 to 1	WINDOWS 95 PRELOAD - Microsoft Windows 95 - Online Users Guide - Diskette Factory - PC Card Director 1.4 1. Triton™ CoSession™ Host 2. Puma TranXit™ 3. NetFinity for Windows 4. CompuServ™ for Windows
Graphics - controller Graphics - memory Graphics - external Graph - arch/data path	Chips and Technologies™ 65545 1 MB DRAM External SVGA to 1024 x 768 w/ 256 colors up to 70 Hz VL-Bus 2.0 local bus / 32 bit / Simultaneous LCD and CRT / 180 degree tilt	
Memory - std / max Memory - upgrade	8 MB / 24 MB 70 ns / non-parity / 3.3 volt / fast page 1 socket for one JEDEC 72 pin SO DIMM of 4 or 16 MB	
Keyboard / # of keys Keyboard slope Pointing Ext keyboard support	Full size alp/num / 85 (8 Fn key functions) Yes (legs pop out) TrackPoint III™ Yes (with option cable or Port Replicator)	Liftable (pop-up) keyboard to access and remove battery (and upgrade memory and disk); diskette drive is not removable
Dimensions (cubic in) Weight (with battery) Battery - type Battery - life Charge time - on / off	11.7 x 8.3 x 2.0" (194 cubic inches) 5.9 pounds NiMH / non-intelligent 2.5 hours 6 hrs / 2 hrs	
Architecture Docking Station Port replicator PCMCIA™ 2.1 slots Serial / parallel ports Other features	ISA (audio, PCMCIA, diskette, serial, parallel, 100 pin external expansion) VL-Bus 2.0 / 32 bit / 25 MHz (graphics, disk) None Port Replicator and Charger (with built-in battery charger and palm rest) 2 Type I or 2 Type II or 1 Type III One 9 pin; 16550A / one (IEEE P1284, EPP, ECP, bidirectional) APM-aware BIOS / Universal AC adapter (35 watts) / Phoenix™ BIOS	
MPEG decoder Data/fax modem Audio support Audio in/out jacks Infrared ports	None None None None Infrared port in back / IrDA 1.0 compatible / up to 115 Kbps	
Security	Power-on password / Supervisor password / Locking device keyhole (Kensington™ MicroSaver™ cable lock) / keyboard lock (requires Kensington)	
Preinstalled software Warranty	Windows 95 with utilities and applications (listed to right) 1 year - ThinkPad EasyServ (optional Overnight Repair Option) or carry-in	
<p>The Port Replicator and Charger provide cable management, a battery charger for an optional second battery, a palm rest when installed on the system, and has complete port replication.</p> <p>The Port Replicator can charge a battery whether or not a ThinkPad is connected to it. When the ThinkPad is attached to the Port Replicator, it will attempt to recharge the battery in ThinkPad first (if there is one) before charging the battery in the Port Replicator.</p> <p>Port Replicator and Charger connectors:</p> <ul style="list-style-type: none"> - Serial (RS-232, 9 pin) - Parallel (EPP, ECP, 25 pin) - External display (15 pin) - Keyboard - Mouse - Diskette drive (26 pin) - Game with MIDI support (15 pin) - Audio in (3.5 mm) - Audio out (3.5 mm) - DC input connector - Spare battery connector (to charge 2nd battery) 	<p>Options for ThinkPad 365:</p> <ul style="list-style-type: none"> - 4 MB SO DIMM 3.3v non-parity 72 pin 92G7287 - 16 MB SO DIMM 3.3v non-parity 72 pin 92G7293 - 810 MB EIDE HDD 13 ms Mode 4 42H4012 - 1.08 GB EIDE HDD 13 ms Mode 4 69H7956 - Port Replicator and Charger (old) 38H6303 <li style="padding-left: 100px;">replaced by 75H7529 - NiMH Battery Pack 38H6304 - 35 watt AC Adapter - 2 pin 85G6719 <p>Setup is entered by Ctrl + Alt + F11 from any full-screen DOS prompt</p> <ul style="list-style-type: none"> Fn + F2 = Battery guage Fn + F3 = Standby Fn + F4 = Suspend Fn + F7 = LCD/CRT/Simultaneous Fn + F8 = Reverse video Fn + F11 = Power mgmt Fn + F12 = Hibernation PgUp = Speaker enable PgDn = Speaker disable <p>System enters hibernation mode when keyboard is lifted up</p> <p>Disk is not removable (like 755/760 systems), but it can be upgraded via a screwdriver</p>	<p>FEATURES OF 365 MODELS</p> <ul style="list-style-type: none"> Product Map LED indicator panel Plug and Play 1.0a Non-disruptive battery exchange Doze, standby, suspend, safe suspend, and hibernation modes US EPA Energy Star compliant Personalized nameplate in indentation Personalization screen at startup International Warranty Service 24 hour / 7 day telephone, bulletin board, fax, electronic, and Internet (http://www.pc.ibm.com) support IBM and dealer warranty/service Online Housecall (remote diagnostics)

ThinkPad EasyServ™: customer calls IBM HelpCenter, courier service picks up ThinkPad at any location, IBM repairs and mails back (no shipping charges, most shipping is overnight, 3 business day average turnaround).

All trademarks are the property of their respective owners
 No warranties are expressed or implied in this summary
 (365E) Compiled by Roger Dodson, IBM. October 1996