

NEC Versa® FXi Notebook Computer

VERSA FXi



U S E R ' S G U I D E

NEC

Proprietary Notice and Liability Disclaimer

The information disclosed in this document, including all designs and related materials, is the valuable property of NEC Computers Inc. (hereinafter “NECC”) and/or its licensors. NECC and/or its licensors, as appropriate, reserve all patent, copyright and other proprietary rights to this document, including all design, manufacturing, reproduction, use, and sales rights thereto, except to the extent said rights are expressly granted to others.

The NECC product(s) discussed in this document are warranted in accordance with the terms of the Warranty Statement accompanying each product. However, actual performance of each such product is dependent upon factors such as system configuration, customer data, and operator control. Since implementation by customers of each product may vary, the suitability of specific product configurations and applications must be determined by the customer and is not warranted by NECC.

To allow for design and specification improvements, the information in this document is subject to change at any time, without notice. Reproduction of this document or portions thereof without prior written approval of NECC is prohibited.

As an ENERGY STAR partner, NEC Computers Inc. has determined that this product meets the ENERGY STAR guidelines for energy efficiency.

NEC is a registered trademark, Versa is a U.S. registered trademark, VersaGlide is a trademark, and UltraCare is a U.S. registered service mark of NEC Corporation, and/or one or more of its subsidiaries, used under license.

ENERGY STAR is a U.S. registered mark.

All other product, brand, or trade names used in this publication are the trademarks or registered trademarks of their respective trademark owners.

Second Printing — June 2000

Copyright 2000
NEC Computers Inc.
15 Business Park Way
Sacramento, CA 95828
All Rights Reserved

Contents

Using This Guide

| | |
|------------------------|----|
| Text Setup..... | x |
| Related Documents..... | xi |

1 Introducing Your NEC Versa

| | |
|--|------|
| Before You Begin..... | 1-2 |
| About Your NEC Versa FXi Notebook..... | 1-3 |
| Around the Front of the System..... | 1-4 |
| LCD Panel..... | 1-4 |
| Base Unit..... | 1-5 |
| Power Button..... | 1-8 |
| Keyboard Panel..... | 1-8 |
| Front Features..... | 1-11 |
| Around the Back of the System..... | 1-12 |
| Around the Left Side of the System..... | 1-13 |
| Around the Right Side of the System..... | 1-14 |
| Around the Bottom of the System..... | 1-15 |

2 Getting Started

| | |
|--|------|
| NEC VersaGlide..... | 2-2 |
| Making VersaGlide Adjustments..... | 2-3 |
| VersaGlide Tips..... | 2-3 |
| Power Sources for Your NEC Versa..... | 2-3 |
| AC Adapter..... | 2-4 |
| Connecting the AC Adapter..... | 2-4 |
| Powering On Your System..... | 2-6 |
| Main Battery Pack..... | 2-6 |
| Determining Battery Status..... | 2-7 |
| Low Battery Status..... | 2-7 |
| Returning the Battery to its Normal State..... | 2-7 |
| Extending Battery Life..... | 2-8 |
| Battery Handling..... | 2-8 |
| Replacing the Battery..... | 2-8 |
| Charging the Battery..... | 2-10 |
| Battery Precautions..... | 2-11 |
| Precautions for Recharging the Battery..... | 2-11 |
| System Batteries..... | 2-12 |
| Main Battery..... | 2-12 |
| CMOS Battery..... | 2-12 |
| Bridge Battery..... | 2-12 |
| Optional Batteries..... | 2-12 |
| System Care..... | 2-13 |
| Precautions for System Use..... | 2-13 |
| Storage Requirements..... | 2-14 |
| Routine Cleaning..... | 2-14 |

3 Using the BIOS Setup Utility

| | |
|---|------|
| Introducing BIOS Setup | 3-2 |
| Entering BIOS Setup | 3-2 |
| Pausing the Screen..... | 3-2 |
| BIOS Setup Main Menu | 3-3 |
| Looking at Screens | 3-4 |
| Using Keys | 3-5 |
| Checking/Setting System Parameters | 3-5 |
| Resetting System Parameters..... | 3-6 |
| Standard CMOS Setup | 3-6 |
| Advanced CMOS Setup | 3-7 |
| System Security Setup..... | 3-7 |
| Password Protection | 3-8 |
| Establishing Passwords | 3-8 |
| Hard Disk Drive Passwords..... | 3-9 |
| Establishing Hard Disk Drive Passwords..... | 3-9 |
| Changing Hard Disk Drive Passwords | 3-10 |
| Using Hard Disk Drive Password Protection | 3-10 |
| Moving the Hard Disk Drive..... | 3-10 |
| Power Management Setup..... | 3-11 |
| Boot Device Setup..... | 3-14 |
| Peripheral Setup | 3-15 |
| Other BIOS Setup Options | 3-16 |
| Managing System Power..... | 3-16 |
| Windows 2000 Power Options Properties..... | 3-17 |
| Windows 2000 Power Schemes | 3-17 |
| Windows 2000 Alarms | 3-18 |
| Windows 2000 Power Meter..... | 3-19 |
| Windows 2000 Advanced..... | 3-19 |
| Windows 2000 Hibernate | 3-20 |
| Windows 98 Power Management Properties..... | 3-20 |
| Windows 98 Power Schemes | 3-21 |
| Windows 98 Alarms | 3-22 |
| Windows 98 Power Meter | 3-22 |
| Windows 98 Advanced..... | 3-23 |
| Windows 98 Hibernate | 3-23 |
| Windows 2000/98 Power Management States | 3-24 |
| Recognizing the Windows 2000/98 Power Management States | 3-24 |
| Updating the BIOS | 3-25 |
| Obtaining the BIOS Update..... | 3-25 |
| Preparing the BIOS Update Diskette..... | 3-25 |
| Identifying the Switch Settings..... | 3-26 |
| Enabling the BIOS Flash Switch..... | 3-27 |
| Performing the BIOS Update | 3-29 |

4 Using the Operating System and Utilities

| | |
|---|------|
| Windows Introduction | 4-2 |
| Windows 2000..... | 4-2 |
| Desktop Icons | 4-2 |
| Taskbar Icons | 4-3 |
| Windows 98 Second Edition | 4-3 |
| Desktop Icons | 4-3 |
| Taskbar Icons | 4-5 |
| NEC Utilities | 4-6 |
| NEC Customize Utility..... | 4-6 |
| NEC Customize Utility Screen..... | 4-6 |
| Using the NEC Customize Utility | 4-6 |
| HDPREPEZ Utility | 4-7 |
| Using the HDPREPEZ Utility | 4-7 |
| SpeedStep Applet | 4-7 |
| Application and Driver CD..... | 4-8 |
| Launching the Application and Driver CD with Windows 2000 | 4-8 |
| Launching the Application and Driver CD with Windows 98 | 4-8 |
| Application and Driver CD Dialog Box | 4-9 |
| Installing the A&D CD Software | 4-9 |
| NEC Info Center..... | 4-9 |
| Installing the NEC Info Center..... | 4-9 |
| Uninstalling the NEC Info Center | 4-10 |
| Partition Magic | 4-10 |
| Product Recovery CD..... | 4-11 |
| Guidelines for Using the Product Recovery CD..... | 4-11 |
| Product Recovery CD Options | 4-11 |
| Full Disk Drive Restore..... | 4-12 |
| Partition Only Restore | 4-14 |

5 Using the System Drives and Bays

| | |
|--|------|
| External Floppy Diskette Drive | 5-2 |
| Connecting the External Floppy Diskette Drive..... | 5-3 |
| Disconnecting the External Floppy Diskette Drive | 5-4 |
| External 24X CD-ROM Drive..... | 5-4 |
| Using the CD-ROM Drive with your NEC Versa | 5-7 |
| Using the CD-ROM Drive as a Stand-Alone CD Player..... | 5-9 |
| Disconnecting the CD-ROM Drive | 5-9 |
| CD Care..... | 5-10 |
| External Drive Connect Utility | 5-11 |
| Using the External Drive Connect Utility | 5-11 |
| External CD Read/Write Drive..... | 5-12 |
| Hard Disk Drive..... | 5-13 |
| Memory Modules | 5-13 |

6 Communicating with Your NEC Versa

| | |
|--|------|
| PC Cards..... | 6-2 |
| Type II Cards..... | 6-2 |
| Type II Extended Cards..... | 6-2 |
| Type III Cards | 6-2 |
| Communication Cards | 6-2 |
| Storage Cards | 6-3 |
| Other Cards..... | 6-3 |
| PC Card Slots | 6-3 |
| Inserting a PC Card | 6-4 |
| Removing a PC Card..... | 6-4 |
| Mini-PCI LAN..... | 6-5 |
| Connecting the Mini-PCI LAN | 6-5 |
| Internal Modem | 6-6 |
| Connecting the Internal Modem | 6-6 |
| Installing the Online Modem Guide | 6-7 |
| Internet Connections..... | 6-7 |
| Accessing the Internet | 6-8 |
| Sending and Receiving Email..... | 6-8 |
| Modifying the Internet and Email Shortcut Keys | 6-8 |
| IR Port | 6-9 |
| Enabling/Disabling the IR Port in Windows 2000 | 6-10 |
| Enabling/Disabling the IR Port Windows 98 | 6-10 |
| Using the IR Port..... | 6-10 |

7 Traveling Tips

| | |
|------------------------------|-----|
| Preparing for Travel..... | 7-2 |
| Packing for Travel | 7-2 |
| Using Power Connections..... | 7-3 |
| Getting Through Customs..... | 7-3 |
| Using Your Modem..... | 7-4 |

8 Using Peripheral Devices

| | |
|--------------------------------------|-----|
| External Monitor | 8-2 |
| Parallel Devices | 8-3 |
| Disconnecting a Parallel Device..... | 8-4 |
| External Audio Options | 8-4 |
| USB Devices | 8-5 |

9 Using Multimedia

| | |
|--------------------------------------|-----|
| Audio..... | 9-2 |
| Recording | 9-2 |
| Microphone | 9-3 |
| Mixing | 9-3 |
| Playing Back..... | 9-3 |
| Using Headphones..... | 9-4 |
| Using the Built-In Speakers..... | 9-4 |
| Using External Stereo Speakers | 9-4 |

| | |
|--|------|
| MIDI Files | 9-4 |
| Video | 9-4 |
| Using Digital Video Files | 9-4 |
| Using Animation Files | 9-5 |
| Multimedia Applications | 9-5 |
| 10 Solving System Problems | |
| Problem Checklist | 10-2 |
| Start-Up Problems | 10-3 |
| Post Error Messages | 10-4 |
| Beep Codes | 10-6 |
| If You Need Assistance | 10-7 |
| 11 Getting Service and Support | |
| Service and Support Contact Information | 11-2 |
| NECC Web Site | 11-3 |
| NECC FTP Site | 11-3 |
| NECC Support Services | 11-4 |
| Email/Fax to Support Services | 11-4 |
| A Setting Up a Healthy Work Environment | |
| Making Your Computer Work for You | A-2 |
| Arrange Your Equipment | A-3 |
| Adjust Your Chair | A-3 |
| Adjust Your Input Devices | A-3 |
| Adjust Your Screen or Monitor | A-4 |
| Vary Your Workday | A-5 |
| Pre-Existing Conditions and Psychosocial Factors | A-5 |
| B Specifications | |
| System Components | B-2 |
| Memory Map | B-8 |
| Interrupt Controllers | B-9 |
| C Frequently Asked Questions | |
| External Mouse | C-2 |
| Display | C-2 |
| PC Cards | C-3 |
| Diskette Drive | C-4 |
| Bootting | C-6 |
| Power Management | C-6 |
| Miscellaneous | C-8 |
| Glossary | |
| Index | |
| Regulatory Statements | |

Using This Guide

The *NEC Versa® FXi User's Guide* gives you the information you need to maximize the use of your NEC Versa notebook computer. Read this guide to familiarize yourself with the NEC Versa and its features. For specific information see

- Chapter 1, “Introducing Your NEC Versa,” to acquaint yourself with system hardware.
- Chapter 2, “Getting Started,” for instructions on how to connect, power on, and care for your system.
- Chapter 3, “Using the BIOS Setup Utility,” for details about modifying system parameters and managing system power.
- Chapter 4, “Using the Operating System and Utilities,” for an understanding of your Windows operating system. You’ll also learn how to use the system utilities and and CDs for loading applications, drivers, and the NEC Info Center.
- Chapter 5, “Using the System Drives and Bays,” to master procedures for connecting the external floppy disk drive, connecting the external CD-ROM drive, and installing memory modules.
- Chapter 6, “Communicating with Your NEC Versa,” for essential information about using PC cards and other communication features of the system.
- Chapter 7, “Traveling Tips,” for a variety of checklists to help you to prepare your notebook computer for getting through customs and using your modem when you are on the road.
- Chapter 8, “Using Peripheral Devices,” to master procedures for connecting external devices like an external monitor, headphones, a printer, or speakers.
- Chapter 9, “Using Multimedia,” for steps on integrating video and sound clips into impressive presentations.
- Chapter 10, “Solving System Problems,” for simple solutions to common problems that may arise while operating your notebook.
- Chapter 11, “Getting Service and Support,” for information about getting help when you need it from NEC Computers Inc. (NECC).
- Appendix A, “Setting Up a Healthy Work Environment,” for guidelines that help promote a healthy work setting.
- Appendix B, “Specifications,” to review NEC Versa system specifications.

-
- Appendix C, “Frequently Asked Questions,” (FAQs) for a look at questions that users commonly ask and the answers to those questions.

Text Setup

To make this guide as easy to use as possible, text is set up as follows.

- Warnings, cautions, and notes have the following format:

 **WARNING** Warnings alert you to situations that could result in serious personal injury or loss of life.

 **CAUTION** Cautions indicate situations that can damage the system hardware or software.

Note Notes give particularly important information about whatever is being described.

- Names of keys are printed as they appear on the keyboard, for example, **Ctrl**, **Alt**, or **Enter**.
- Text that you must type or keys that you must press are presented in bold type. For example, type **dir** and press **Enter**.

Related Documents

See the following documents for additional information on your NEC Versa notebook computer:

- The *NEC Versa FXi Quick Setup* sheet helps get your system up and running.
- The *NEC Versa FXi Quick Reference* card provides an easy-to-carry reference to LED meanings, controls, function key combinations, and NECC help numbers. (The quick reference card does not ship with some systems purchased outside of the United States and Canada.)
- The *NEC Info Center* is a fully navigational, pdf document containing multimedia elements, a full search capability, and all of the information about your NEC Versa that you find in this printed user's guide, and more.

1

Introducing Your NEC Versa

- Before You Begin
- About Your NEC Versa FXi Notebook
- Around the Front of the System
- Around the Back of the System
- Around the Left Side of the System
- Around the Right Side of the System
- Around the Bottom of the System

Before You Begin



WARNING Prolonged or improper use of a computer workstation may pose a risk of serious injury. To reduce your risk of injury, set up and use your computer in the manner described in Appendix A, “Setting Up a Healthy Work Environment.”

After completing the steps in the Quick Setup sheet that comes with your computer, your NEC Versa FXi notebook computer is ready to go! To get started, do the following:

- Read Appendix A, “Setting Up a Healthy Work Environment,” for guidelines that help you use your computer productively and safely. Information includes how to set up and use your computer to reduce your risk of developing nerve, muscle, or tendon disorders.
- Take the online Tour to get acquainted with the NEC Versa’s information resources. The Tour is part of the NEC Info Center. Use the Application and Driver CD that ships with your NEC Versa FXi system to install the NEC Info Center.

Read through this guide to familiarize yourself with the NEC Versa.

About Your NEC Versa FXi Notebook

The NEC Versa FXi notebook computer offers you a portable system filled with exciting resources for home, business, or travel. Standard features include a powerful Intel® Pentium III 600-MHz with SpeedStep™ microprocessor or a 500-MHz Celeron microprocessor that works together with the latest Peripheral Component Interconnect (PCI) architecture.

In addition, your system provides a high-performance hard disk drive, an external floppy disk drive, an external CD-ROM drive, and PC card support. As a multimedia system, your NEC Versa also provides the tools needed to create and present impressive images using video clips and sound.

NEC Versa FXi notebook computer



To get comfortable with your notebook, read the following sections and take a tour around your system!

Around the Front of the System

The NEC Versa is compact with features on every side. First, look at the front of the NEC Versa. The following sections describe front features, beginning with the liquid crystal display (LCD) panel.

LCD Panel

Your NEC Versa FXi comes with a 12.1-inch color Thin Film Transistor (TFT), Extended Graphics Array (XGA) or SuperVideo Graphics Array (SVGA) panel that you can adjust for a comfortable viewing position. To adjust the viewing angle, gently tilt the LCD panel into position.


To adjust the LCD panel brightness press the **Fn-F8** and **Fn-F9** functions keys. For more details about using the system's function keys, see the topic later in this chapter, "Keyboard Panel."

Base Unit

The base unit of your NEC Versa offers the following features which are described after the figure.

⚠ CAUTION After extended use, the surface of the base unit, below the keyboard, may become hot to the touch.

LCD panel and base unit




A – Keyboard
B – Stereo Speakers
C – LCD Panel
D – Email/Internet Keys

E – Power Button
F – Operating Status LEDs
G – NEC VersaGlide

- Keyboard — 83 keys with the standard QWERTY-key layout. (Models purchased outside of the U.S. and Canada ship with country-specific keyboard layouts.)
- Stereo Speakers — Provide stereo sound for your multimedia presentations or listening pleasure. The built-in sound system also supports 3D sound, which simulates the latest surround-sound technology.
- LCD Panel — Provides a high-resolution display for sharp, effective visuals on your NEC Versa.

- **Email Shortcut Key** — Launches your dial-up networking connection (if not connected to a LAN) and Outlook Express. For details about configuring your Internet Connection and modifying the shortcut keys, see Chapter 6, “Communicating with Your NEC Versa.”
- **Internet Shortcut Key** — Launches your dial-up networking connection (if not connected to a LAN) and Microsoft Internet Explorer. For details about configuring your Internet Connection and modifying the shortcut keys, see Chapter 6, “Communicating with Your NEC Versa.”

Email/Internet keys



A – Email Shortcut Key


B – Internet Shortcut Key

- **Power Button** — Slide the Power button to the right to power on, power off, and to resume from Standby mode.

For more information about the Power button, see the following topic, “Power Button.”

- Operating Status LEDs — Keeps you informed of your NEC Versa's current operating status. See the following figure and list for each icon's meaning.

Operating status LEDs



A – Hard Disk Drive
B – Caps Lock

C – Scroll Lock
D – Num Lock

- Hard Disk Drive — lights when the NEC Versa writes data to or retrieves data from the internal hard disk drive.
 - Caps Lock — lights when Caps Lock is in effect.
 - Scroll Lock — lights when Scroll Lock is in effect.
 - Num Lock — lights when Num Lock mode is active.
- NEC VersaGlide — The NEC VersaGlide works like a standard computer mouse. Simply move your fingertip over the VersaGlide to control the position of the mouse pointer. Use the selection buttons below the VersaGlide to select menu items. VersaGlide settings and features are described in detail in Chapter 2.

Power Button

The Power button is a “smart” switch, meaning that it recognizes when the system is in Standby mode. If in Standby mode, you cannot power off until you slide the Power button to the right to resume operation. (The BIOS parameter “System Switch” must be set to “Sleep.”)

Put the unit in Standby mode when you need to be away from your system for a short period of time and want to return to where you left off. Standby mode shuts down all devices in the system while retaining data and system status. Go to Start, Shut Down, Standby to put your system into Standby mode.


Use the Power button in the following ways:

- Slide the Power button to the right to power on.
- Slide the Power button to the right to resume from Standby mode and proceed with normal operation.
- Hold the Power button in place for 4 or more seconds to power off the system (power override). Only use this option if you cannot power off your system using Start, Shut Down.

Keyboard Panel

The NEC Versa keyboard offers the following features, which are described after the figure.

Keyboard



A – Function Keys
B – Numeric Keys
C – Windows® keys

D – Cursor Control Keys
E – Control Keys

-
- **Function keys** — Twelve function keys, **F1** through **F12**, are available on the NEC Versa keyboard. These keys work together with the **Fn** key to activate special functions. Several keys are preprogrammed with dual functions and some are printed in blue on the key.

Function keys are application-driven. See the specific application's user guide for information about how each function key works within the application you are using.

The following function key combinations are preprogrammed for the NEC Versa FXi computer.

Fn-F3 — toggles between three video modes; LCD, CRT, or both (LCD and CRT).

Fn-F6 — sets the beeper volume to low, medium, high, or mute.

Fn-F7 — No function when Windows configured for Advanced Configuration Power Interface (ACPI) mode.

Fn-F8 — increases the LCD panel brightness.

Fn-F9 — decreases the LCD panel brightness.

Fn-F10 — increases the system speaker volume.

Fn-F11 — decreases the system speaker volume.

Fn-ScrLk — toggles the Num lock function.

Fn-Pause — break

Fn-Left Win — right Windows key

- **Numeric keypad** — Pressing NumLk on the keyboard activates the numeric keypad numbers and functions printed in blue on the keys.

The keypad lets you type numbers and mathematical operands (+, -) as you would on a calculator. The keypad is ideal for entering long lists of numbers.

When you press NumLk again, the keys revert to their normal functions as typewriter keys.

- **Cursor Control keys** — Cursor control keys let you position the cursor on the screen where you want. On the screen, the cursor is a blinking underline, block, or vertical line depending on the application. The cursor indicates where the next text typed is inserted.

-
- Windows keys — In Windows use the following two keys to facilitate your work.



Quick access to shortcut menus



Displays the Start menu

- Control keys — **Ctrl**, **Alt**, **Fn**, and **Shift** are controls used in conjunction with other keys to change their functions. To use control keys, press and hold the Control key while pressing another key. For example, “press **Ctrl c**” means to hold down the **Ctrl** key and type the letter c. How the key combination works depends on the application you are running.
- Typewriter keys — The typewriter keys (also called alphanumeric keys) are used to enter text and characters. Keys with blue printing on them behave differently when combined with control keys or the **Fn** key.

Front Features

The front features of your NEC Versa are described after the figure.

Features on the front of the system



A – Power Status LED
B – Battery Charging LED
C – Microphone

D – IR Port
E – Headphone Jack/External Speakers
F – External Microphone Jack

- **Power Status LED** — This LED lights to indicate the following:
 - Lights green when the system power is on.
 - Blinks green when the system is in Standby mode.
 - Lights yellow (blinks when in Standby mode) to indicate that battery power is at 8% capacity or less.
 - Lights amber (blinks when in Standby mode) to indicate that battery power is at 3% capacity or less.
- **Battery Charging LED** — lights to indicate battery charging activity.
 - Lights amber when the primary battery is charging. Blinks amber to indicate an error. The primary battery is installed in the battery bay.
 - Lights green when the secondary battery is charging. Blinks green to indicate an error. The secondary (optional) battery is connected to the bottom of the system.

-
- **Microphone** — A strategically positioned built-in microphone allows you to record monophonic sound directly into your notebook computer. See Chapter 9, “Using Multimedia,” for details about recording.
 - **IR Port** — Use this infrared (IR) port to transfer files between your NEC Versa and an IR-equipped desktop or notebook computer or to print to an IR-capable printer.
-


Note Your NEC Versa FXi ships with the IR port disabled. For detailed instructions on how to enable the IR port, see Chapter 6, “Communicating with Your NEC Versa.”

- **Headphone Jack/External Speakers** — Lets you connect external headphones or speakers to your NEC Versa. Plugging in headphones disables the built-in system speakers.
- **External Microphone (MIC)** — Allows you to connect an external microphone for monophonic recording or amplification through the unit. Plugging in an external microphone disables the built-in microphone.

Around the Back of the System

The back of your NEC Versa offers the following features, which are described after the figure.

Features on the back of the system



A – External Monitor Port
B – Vents

C – Battery Bay

- **External Monitor (Video) Port** — Use this 15-pin port to attach an external monitor to your NEC Versa. You can run the LCD display and the external monitor simultaneously or run either alone.
- **Vents** — Allow your system to cool properly and maintain a safe operating temperature.



CAUTION


Always keep the vents unobstructed to allow proper system cooling.

- **Battery Bay** — Contains the system's standard Lithium-Ion (Li-Ion) main battery or an optional Extra Life Li-Ion battery.

Around the Left Side of the System

The left side of your NEC Versa offers the following features, which are described after the figure.

Left side features



A – RJ-11 Jack
B – AC Power Port
C – LAN Cable Jack


D – Floppy Diskette Drive/Parallel Port
E – PC Card Slots

- **RJ-11 Jack** — Connects the internal modem to an analog telephone line.
- **AC Power Port** — Attaches the NEC Versa to a DC power source, such as the AC adapter or the optional DC auto adapter.
- **LAN Cable Jack** — Connects the optional LAN adapter cable that ships with your system (if your system equipped with a LAN cable jack), to your system and to a local area network (LAN). (Not available in all systems.)
- **External Floppy Diskette Drive/Parallel Port** — Connects the external floppy diskette drive or an external parallel device using the cables that ship with your system.
- **PC card slots** — Provide two slots for inserting two Type II PC cards or one Type III PC card.

Around the Right Side of the System

The right side of the NEC Versa offers the features, which are described after the figure.

Right side features



A – USB Ports
B – CD/DVD Port


C – USB Port
D – Kensington Lock

- **USB Ports** — The Universal Serial Bus (USB) ports allows you to connect up to 127 USB-equipped peripheral devices (printers, monitors, scanners, etc.) to your NEC Versa.
- **CD/DVD Port** — Connects the external CD-ROM drive, the optional CD/RW (CD Read/Write) or DVD drives.
- **Kensington Lock** — Provides added security by installing an optional Kensington Lock.

Around the Bottom of the System

The bottom of the NEC Versa offers the following features, which are described after the figure.

Bottom features



A – Memory Module Bay
B – Battery Release Latch
C – System Feet

D – Main Battery
E – Vents
F – Maximum Life Battery Connector

- Memory Module Bay — Stores the system’s memory modules.
- Battery Bay Release Latch — Releases and removes the system’s main battery.
- System Feet — Heightens the system to allow proper ventilation.
- Main Battery — Supplies power when the system is not connected to an AC power source.
- Vents — Allow your system to cool properly and maintain a safe operating temperature.



CAUTION Always keep the vents unobstructed to allow proper system cooling.

- Maximum Life Battery Connector — Attaches the optional Maximum Life Battery to your system.

2

Getting Started


- NEC VersaGlide
- Power Sources for Your NEC Versa
- AC Adapter
- Main Battery Pack
- System Batteries
- System Care

NEC VersaGlide

Your NEC Versa FXi notebook computer is equipped with the latest in touchpad technology! The NEC VersaGlide is an easy way to control the cursor with your finger. Lightly glide your finger across the NEC VersaGlide and the cursor follows. The NEC VersaGlide provides standard mouse functionality, plus more. VersaGlide features include the:

- **Single tap** to the touchpad, equivalent to a single click of the primary mouse button.
- **Double tap** to the touchpad, equivalent to a double click of the primary mouse button.
- **Click and hold**, then **drag** your finger across the VersaGlide touchpad, equivalent to a click and drag of the primary mouse button.
- **Slide** your finger along the right side of the touchpad to scroll your document or screen.

VersaGlide features



A – Touchpad
B – Left (Primary) Button

C – Right Button

Try all of the features and decide which you prefer. If you find the double tap or any of the other features difficult to use, go to the next section for general directions about adjusting the touchpad properties.

Making VersaGlide Adjustments

The NEC VersaGlide offers a number of options that let you customize how it functions. The options let you control the cursor speed, select button orientation, enable or disable tapping, define auto jumps, enable easy-scrolling, and configure gestures to initiate selected functions by tapping in a designated area of the touchpad.

To access these options, locate the Control Panel and double click the mouse icon. Use the context-sensitive help to learn more about each option. Select the option, then press **F1** to access the context sensitive help.

VersaGlide Tips

Follow these basic ergonomic tips while working:

- Use a light touch on the VersaGlide surface.
- Set up the NEC Versa with your keyboard and VersaGlide at a comfortable height. Keep your forearms parallel to the floor. Your wrists should be relaxed and straight.
- While using the keyboard and VersaGlide, keep your shoulders and arms as relaxed as possible.
- Take regular breaks from the computer to rest your eyes. Perform stretching exercises to relax your fingers, hands, wrists, forearms, and shoulders.

See Appendix A, “Setting Up a Healthy Work Environment,” for more information.

Power Sources for Your NEC Versa

The NEC Versa can be powered using three different sources, making it a truly portable system.

Operate your NEC Versa just about anywhere using one of the following power sources:

- the AC adapter connected to an electrical wall outlet (using AC power)
- the battery pack or an optional second battery pack
- the optional Auto adapter. (For details about its use, refer to the accessory sheet that ships with the option.)

Read the following sections for specific information about using the NEC power sources.

AC Adapter

Use the AC adapter and power cable that came with your NEC Versa to run your computer on alternating current (AC) power, or to recharge the battery pack. Use the AC adapter whenever a wall outlet is nearby.

Keep the adapter connected whenever possible. The AC adapter charges the battery when it is connected, whether the NEC Versa is powered on or off.

AC Adapter



A – AC Adapter
B – Adapter Cable

C – Power Cable

! WARNING Do not attempt to disassemble the AC adapter. The AC adapter has no user-replaceable or serviceable parts inside. Dangerous voltage in the AC adapter can cause serious personal injury or death. The AC adapter is intended for use with a computer and must meet EN609050 standards.

Connecting the AC Adapter

Note The AC power cable type that your system uses depends on the country where you are using it. Contact the local dealer to purchase the correct power cable.

Connect the AC adapter as follows:

1. Connect the AC adapter cable to the power port on the left side of your NEC Versa.

-
2. Plug one end of the AC power cable into the AC adapter and the other end into a properly grounded 120- or 240-volt, 50 or 60-Hz wall outlet.

Connecting the AC Adapter



A – Adapter Cable
B – AC Power Port

C – AC Adapter
D – Power Cable

⚠ CAUTION Do not cover or place objects on the AC adapter. Keeping the adapter clear of objects lets the adapter cool properly during use.

Only use the AC adapter that comes with your NEC Versa FXi. Although other adapters look similar, using them can damage your system.

Powering On Your System

Power on the system as follows:


1. Locate the latch on the front of the LCD panel, slide it to the right, and raise the panel.
2. Locate the Power button and slide it to the right to turn on system power. For additional information about Power control buttons and power LEDs, refer to Chapter 1, “Introducing the NEC Versa.”

Note When powering on your NEC Versa running the Windows 2000 operating system, you may encounter a warning message suggesting that a problem exists with the hibernation file on your system. The warning message is inaccurate. To disable this message, simply enable hibernate support. See the section “Windows 2000 Hibernate,” in Chapter 3, for details about enabling hibernate support.

Main Battery Pack

The NEC Versa comes with a rechargeable Lithium-Ion (Li-Ion) battery pack that’s easy to install and remove.

Standard Lithium-Ion Battery



A – Battery Connectors

B – Alignment Grooves

! WARNING To prevent accidental battery ignition or explosion, adhere to the following:

- Keep the battery away from extreme heat.
 - Keep metal objects away from the battery connectors to prevent a short circuit.
 - Make sure the battery is properly installed in the battery bay.
 - Read the precautions printed on the battery.
-

Determining Battery Status

Your NEC Versa system provides tools to help you keep track of the main (and an optional) battery's power level. If your system is configured (default setting) to display the power icon on the taskbar, an electrical plug appears when the system is connected to an AC power source or a battery icon appears when the system is not connected to an AC power source.

Use the system's power meter to determine battery status. Access the system's power meter in the following ways:

- Move the cursor over the power icon on the taskbar to display the remaining battery power for the system's main battery.
- Right click the power icon on the taskbar to open the power meter or to adjust power properties.
- Double click the power icon on the taskbar to display the remaining power for both the main and optional (if attached) battery.
- Go to Start, Settings, Control Panel, and double click the Power Management icon and select the Power Meter tab.

Low Battery Status

When battery power is low (8% or less), the power LED lights yellow. When battery power is very low (3% or less) the power LED flashes amber. When your system is in a low battery status, do one of the following:

- Power off the system, remove the battery pack and replace it with a fully charged battery.
- Leave the battery pack in the system and connect your NEC Versa to the AC adapter and a wall outlet. If you connect the system to AC power and keep the system within standard operating temperatures, the battery recharges in approximately 2–3 hours whether or not you use your system.

Returning the Battery to its Normal State

To return the battery to its normal state, try the following:

- remove and then reinstall the battery
- reinstall the battery in your NEC Versa and fully recharge the battery (to 100%).

Extending Battery Life

While on the road, it is important to be aware of the simple things you can do to extend the life of the system's main battery. One way is to keep the brightness setting low. Use the **Fn-F8** and **Fn-F9** function keys to control the brightness.

Battery Handling

Keep the following in mind when removing or replacing a battery.

- Use only the battery designed for your system in the NEC Versa. Mixing other manufacturers' batteries, or using a combination of very old and new batteries can deteriorate battery and equipment performance.
- Turn off power to the system after use. Keeping system power on can degrade battery performance and shorten battery life.
- Clean the battery connectors with a dry cloth when they get dirty.
- Keep the battery out of the reach of children.

Replacing the Battery

The following symptoms indicate that battery life is nearing an end. Replace batteries that display these symptoms.

- Shorter work times.
- Discoloration, warping.
- Hot to the touch.
- Strange odor.

Replace the battery pack installed in your NEC Versa system as follows.

Note Use the batteries in the NEC Versa computer for which they are designed. Installing another manufacturer's battery, or using a combination of very old and new batteries can deteriorate battery and equipment performance.

1. Save your files, exit Windows and turn off system power.
2. Close the LCD panel and turn over the system.

3. Slide the battery release latch toward the right side of the system and hold firmly.

Locating the Battery bay release latch




A – Lithium-Ion Battery

B – Battery Release Latch

4. Continue to hold the battery release latch as you slide the battery out of the system.

Removing the battery




A – Battery Bay Connectors

B – Battery Bay Release Latch

C – Standard Lithium-Ion Battery

5. Insert the new battery as follows:
 - Locate the alignment groove on the edge of the battery.
 - Locate the alignment groove inside the battery bay.
 - Align the grooves on the battery with the grooves in the bay.
 - Slide the battery into the bay until securely locked into place.

Inserting the battery pack



A – Battery Bay Connectors
B – Battery Bay Release Latch

C – Alignment Grooves
D – Standard Lithium-Ion Battery

6. Turn over the system.

Charging the Battery

Charge the main (primary) battery and secondary (optional) battery by simply connecting your NEC Versa FXi system to an AC power source. To monitor the charging activity, observe the battery charging LED on the front of the system. The battery charging LED lights as follows:

- Lights amber when the primary battery is charging.
- Blinks amber if the primary battery encounters an error while charging.
- Lights green when the secondary battery is charging.
- Blinks green if the secondary battery encounters an error while charging.

Battery Precautions

To prevent accidental battery ignition, rupture, or explosion, adhere to the following precautions.



WARNING There is a danger of explosion if the battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.

To avoid personal injury and property damage, read these battery precautions on handling, charging, and disposing Li-Ion batteries.

- Keep the battery away from heat sources including direct sunlight, open fires, microwave ovens, and high-voltage containers. Temperatures over 140° F (60°C) may cause damage.
- Do not drop or impact the battery.
- Do not disassemble the battery.
- Do not solder the battery.
- Do not puncture the battery.
- Do not use a battery that appears damaged or deformed, has any rust on its casing, is discolored, overheats, or emits a foul odor.
- Keep the battery dry and away from water.
- Keep metal objects away from battery connectors. Metal objects in contact with the connectors can cause a short circuit and damage.

If the battery leaks:

- If the battery leaks onto skin or clothing, wash the area immediately with clean water. Battery fluid can cause a skin rash and damage fabric.
- If battery fluid gets into eyes, DO NOT rub; rinse with clear water immediately and consult a doctor.
- Take extra precautions to keep a leaking battery away from fire. There is a danger of ignition or explosion.

Precautions for Recharging the Battery

Adhere to the following precautions when recharging the primary or secondary battery.

- Charge the battery for the specified charge time only.
- During charging, keep the environmental temperature between 32°F and 104°F (0°C to 40°C).

System Batteries

Your NEC Versa is equipped with a main, Lithium-Ion battery and two backup batteries that help to prevent data loss. In addition, your system provides the option to attach a second Lithium-Ion battery to the connector on the bottom of the system, extending battery life when you are away from an AC power source.

Main Battery

The standard Lithium-Ion (Li-Ion) battery provides the main power source in your NEC Versa FXi computer. See Appendix B for a list of battery specifications. In addition to this battery, the CMOS battery and bridge battery also provide system power.

CMOS Battery

This lithium battery provides battery backup and prevents data loss in the system's complementary metal oxide semiconductor (CMOS) RAM. This memory area contains information on the system's configuration, for example date, time, drives, and memory. The CMOS battery charges when your NEC Versa is connected to AC power. The CMOS battery may discharge completely if the NEC Versa notebook remains unused for approximately two months.

Bridge Battery

The bridge battery saves your system status in Standby mode giving you time to install a fully charged battery or connect to AC power when your battery charge becomes low.

The bridge battery should be replaced only by an authorized NECC technician.

 **CAUTION** Connect your NEC Versa system to AC power for a full 24 hours before using it on battery power for the first time. Doing so insures that the bridge battery is fully charged and that no data is lost during a battery change.

Optional Batteries

Your NEC Versa FXi system allows you to install an optional Extra Life Lithium-Ion battery in the main battery bay. In addition, your system is equipped with a battery connector on the bottom of the system, that enables you to attach an optional, Maximum Life Lithium-Ion battery. Attaching a second fully charged battery increases battery life while you are away from an AC power source.

System Care

The NEC Versa is a durable, dependable system built for extensive use and travel. Follow these guidelines to maintain the condition and performance of your computer.



CAUTION Immediately turn off and unplug the NEC Versa under the following conditions:

- The power cord is damaged or frayed.
 - Liquid spills on or into the NEC Versa.
 - Someone drops the system or damages the casing.
-

Precautions for System Use

Follow these precautions when using your NEC Versa FXi computer and AC adapter.

- Avoid dropping or bumping the computer or the AC adapter.
- Do not stack heavy objects on the computer, the AC adapter, or the battery packs.
- Avoid moving the NEC Versa during system operation, especially while the hard disk, diskette drive, or CD-ROM drive is being accessed.
- When using the AC adapter, make sure the power source falls within the system's compatible range of 100-240 volts and 50 or 60-Hz, AC. Never use the AC adapter if the voltage falls outside of this range. (Watch for this when traveling to other countries.)
- Turn computer power off before attaching or removing non-plug and play devices.
- Do not push any foreign objects into the NEC Versa bays, connectors, and slots.
- Do not set the computer on top of a magnetized area. Doing so can destroy the data on your hard disk drive. (Some airline tray tables are magnetic.)
- Avoid using the computer or AC adapter for extended periods in direct sunlight.
- Do not use the system in humid or dusty environments.
- Turn computer power off before cleaning it.
- Avoid exposing the NEC Versa or AC adapter to extreme changes in temperature or humidity. If it is unavoidable, allow your NEC Versa to adjust to room temperature before use.
- When cleaning the system, use a soft, clean, dry cloth. Avoid wiping the display surface with abrasive material, including rough fabric. Do not use a cleaning solution; this may damage the notebook's plastic.
- If the AC adapter becomes extremely hot, unplug the adapter and let it cool.
- Keep the AC adapter away from the IR ports.

Storage Requirements

Store the computer and AC adapter in an environment that meets the following conditions:



CAUTION If the temperature of the NEC Versa suddenly rises or falls (for example, when you move the system from a cold place to a warm place), vapor condenses inside the system. Turning on the system under this condition can damage the internal system components.

Before turning on the system, wait until the system's internal temperature equalizes with the new environment and any internal moisture evaporates.

- Maintain storage temperatures between -4°F and 104°F (-20°C and 40°C).
- Keep the storage area free from vibration and magnetic fields.
- Keep the system and its components away from organic solvents or corrosive gases.
- Avoid leaving the system and its components in direct sunlight or near heat sources.

Routine Cleaning

Clean or dust your system as follows:



CAUTION Never use harsh solutions, household cleaners, or spray cleaners that contain caustic materials on the NEC Versa computer.

These cleaners are usually high in alkalinity which is measured in pH. Using these cleaners can cause the plastic surface to crack or discolor.

- LCD screen — Carefully wipe the LCD screen with a soft cloth or a screen wipe designed for that purpose. Special screen wipes are available through your local computer dealer.
- System case — NECC recommends that you carefully wipe the case with a slightly damp, almost dry cloth.

3

Using the BIOS Setup Utility

- Introducing BIOS Setup
- Entering BIOS Setup
- Checking/Setting System Parameters
- Managing System Power
- Updating the BIOS

Introducing BIOS Setup

Your NEC Versa FXi computer comes with a hardware program called BIOS Setup that allows you to view and set system parameters. BIOS Setup also allows you to set password features that protect your system from unauthorized use.

Use BIOS Setup to:

- set the current time and date
- customize your operating system to reflect your computer hardware
- secure your system with a password
- balance your performance needs with power conservation.

Entering BIOS Setup

Access the BIOS utility at power-on. Just press **F2** when the following prompt appears.

Press <F2> to enter Setup.

When you press **F2** to enter BIOS Setup, the system interrupts the Power-On Self-Test (POST) and displays the current CMOS RAM settings.

If the system detects an error during POST, it prompts you with a double beep and a message: “Press <F1> to resume.” If you press **F1**, the system enters BIOS Setup automatically. If you want to fix the error, carefully read the error message that appears above the prompt (taking notes if you want), and press **F2**. You will see this message if your CMOS battery becomes fully discharged.

Pausing the Screen

To pause the screen during POST to view the BIOS revision number and other POST messages, press and hold the Insert key while using the Power button to power on the system. The message “<Ins> pressed, Press **F1** to run setup” appears. Press **F1** to enter BIOS Setup. To pause the screen without entering the BIOS setup, simply press the Pause key during POST. Once paused, press any key to continue.

BIOS Setup Main Menu

After you press **F2**, the system displays the BIOS Setup Main Menu screen, similar to the following.

BIOS Setup Main Menu

| |
|---|
| <p>AMIBIOS HIFLEX SETUP UTILITY (C)1999 American Megatrends, Inc. All Rights Reserved</p> |
| <p>BIOS Revision XXXXXXXX</p> <p>Standard CMOS Setup Advanced CMOS Setup System Security Setup Power Management Setup Boot Device Setup Peripheral Setup Change Language Setting Refresh Battery Auto Configuration with Defaults Save Settings and Exit Exit Without Saving</p> |
| <p>Advanced CMOS setup for configuring system options ESC: Exit ↑↓: Sel F3/F4: Color F10: Save & Exit</p> |

Use the up and down arrow keys (located on the lower right corner of the keyboard) to toggle through the BIOS Setup menu items.

Looking at Screens

BIOS setup screens have three areas as shown next.

Advanced CMOS Setup

| AMIBIOS SETUP – ADVANCED CMOS SETUP (C)1999 American Megatrends, Inc. All Rights Reserved | |
|--|--|
| LCD Panel View Expansion ON Internal Mouse ENABLED | Item-specific help text appears here. |
| ESC: Exit ↑↓: Select PgUp/PgDn: Modify F3/F4: Color | |

- **Parameters** — The left side of the screen. This area lists parameters and their current settings.
- **Available Options and Help** — The right side of the screen. This area lists alternate settings and Help text for each parameter.
- **Key Legend** — The bottom right corner of the screen. These lines display the keys that move the cursor and select parameters.

Options that are grayed out are not available for the current selection.

Using Keys

The following table lists the BIOS Setup keys and their functions.

BIOS Setup Key Functions

| Key | Function |
|---------------------|---|
| ↑ ↓ | Moves the cursor between the displayed parameters. |
| Fn-PgUp/ Fn-PgDn | Toggles through the current parameter settings. |
| Tab | For some parameter settings, moves the cursor between the subfields. Also moves the cursor to the next line or selection. For example, for System Time, Tab moves the cursor from hour to minute to second. |
| ESC | Exits the current screen and returns to the Main Menu screen. From the Main Menu screen, displays the prompt, "Quit without saving." |
| F3/F4 | Changes the screen color. |
| F10 | Saves and exits the BIOS Setup Utility. |

Checking/Setting System Parameters

The BIOS Setup utility consists of a number of screens, each representing a specific area of the BIOS. The following tables list the BIOS parameters, their factory default settings, alternate settings, and a description of each setting. See the item-specific help that appears on each Setup screen for more details.

The BIOS Setup Utility is broken down as follows:

- Standard CMOS Setup
- Advanced CMOS Setup
- System Security Setup
- Power Management Setup
- Boot Device Setup
- Peripheral Setup
- Change Language Setting
- Refresh Battery
- Auto Configuration with Defaults
- Save Settings and Exit
- Exit Without Saving

Resetting System Parameters

To reset all parameters to the default settings, select Auto Configuration with Defaults from the BIOS Setup Main Menu. Use the arrow keys to select **Yes** and press **Enter**.

Standard CMOS Setup

Use the Standard CMOS Setup screen to view the System Time, System Date and to modify drive parameters and related settings.

Standard CMOS Setup

| Parameter | Default Setting | Alternate Setting(s) |
|------------------------------|-----------------|--|
| Date | mm/dd/yyyy | |
| System Memory | | (automatically detected) |
| Time | hh/mm/ss | |
| Diskette Drive A | 1.44 MB, 3.5 | Not installed |
| Internal | Auto | CD-ROM/CD-RW User Defined, Not installed |
| External | Auto | CD-ROM/CD-RW, User Defined, Not installed |
| Boot Sector Virus Protection | Disabled | Enabled |

- **Date** — Sets your NEC Versa's calendar month, day and year. The calendar clock is year 2000-compliant. These settings remain in memory even after you turn off system power.

To set the date use the **Tab** or arrow keys to move from field to field. Use the **Fn-PgUp** or **Fn-PgDn** key to change the numbers within each field.

- **System Memory** — Displays the amount of system memory currently installed in your system.
- **Time** — Sets the time, enter the current hour, minute, and second in *hr/min/sec*, 24-hour format.

To set the time use the **Tab** or arrow keys to move from field to field. Use the **PgUp** or **PgDn** key to change the numbers within each field.

- **Diskette Drive** — Designates the drive type for your diskette drive.
- **Internal Drive** — Assigns devices to the internal drive in your system.

- External Drive — Assigns devices to the external drive in your system.
- Boot Sector Virus Protection — Write protects the boot sector of the hard disk drive to avoid infection by some virus types.

Advanced CMOS Setup

Use the Advanced CMOS Setup to set the following functions.

Advanced CMOS Setup

| Parameter | Default Setting | Alternate Setting(s) |
|--------------------------|-----------------|----------------------|
| LCD Panel View Expansion | On | Off |
| Internal Mouse | Enabled | Disabled |

- LCD Panel View Expansion — Specifies whether the panel view is reduced/off or expanded/on.
- Internal Mouse — Allows you to use the internal mouse (VersaGlide).

System Security Setup

Use the System Security Setup to establish system passwords.

System Security Setup

| Parameter | Default Setting | Alternate Setting(s) |
|----------------------------|-----------------|----------------------|
| Assign Supervisor Password | Press Enter | |
| Assign User Password | Press Enter | |
| Boot Password Required | No | Yes |
| Resume Password Required | No | Yes |
| Assign HDD Password | Press Enter | |
| Internal HDD password | Disabled | Enabled |

- Assign Supervisor Password — Establishes password protection for entering the BIOS Setup Utility, booting the system, and resuming from Standby. (Resume from Standby, not applicable in Windows 2000/98 with ACPI.)
- Assign User Password — Establishes a user password once a supervisor password is set.

-
- **Boot Password Required** — Indicates whether or not a password is required during system boot.
 - **Resume Password required** — Indicates whether or not a password is required during system resume. Boot Password must be defined to activate this parameter. (Not applicable in Windows 2000/98 with ACPI.)
 - **Assign HDD Password** — Allows you to assign a password to allow or restrict access to the hard disk drive contents.
 - **Internal HDD Password** — Enables or disables the HDD password.

Password Protection

Your NEC Versa supports password security on several levels. Keep in mind that you must set the supervisor password before the BIOS Setup utility allows you to set a user password.

Once you set a supervisor password, you must enter it before you can enter BIOS Setup, access the system at startup, or resume from Suspend or Save-to-File, depending on your configuration selection.

Establishing Passwords

To establish password protection for entering the BIOS Setup Utility or accessing the system at startup, you must set the supervisor password before setting a user password.

- To enter a password simply select **Assign Supervisor Password**, enter the password, re-enter the password to confirm, and press any key to continue. Repeat the procedure to set the user password.
- To initiate password protection while you step away from your system, simply press **Ctrl, Alt, Backspace**. The Caps lock and Scroll lock LEDs alternately flash indicating that you must enter a password to resume operation.

To establish password protection for resuming from Standby or Hibernation modes you must do the following:

- Set a Windows password in Control Panel, Password Properties, Change Passwords.
- Enable the option “Prompt for password when the computer goes off standby,” in Control Panel, Power Management Properties, Advanced.

Hard Disk Drive Passwords

Your NEC Versa allows you to establish password protection for the internal hard disk drive. Hard disk drive (HDD) password protection restricts access to the drive, *only* if the drive is removed from your NEC Versa and installed in another system. You are not required to enter your hard disk drive passwords while the drive remains in your current system.

The HDD passwords are written to the system BIOS and to the hard disk drive to ensure that the password protection travels with the drive when moved from system to system.

Establishing Hard Disk Drive Passwords

To establish password protection for your system's hard disk drive you must establish a master password, establish a user password, and enable the established passwords for the internal HDD. Follow these steps to establish HDD passwords and to enable HDD password protection.

1. Enter the BIOS setup, highlight and select the System Security Setup.

2. Highlight Assign HDD Password and press **Enter**.

The system prompts you to enter a master password.

3. Enter a master HDD password and press **Enter**.

The system prompts you to enter the password again to verify.

4. Enter the master password and press **Enter**.

The system confirms the creation of the master password and prompts you to enter a user password.

5. Enter a user password and press **Enter**.

The system prompts you to enter the password again to verify.

6. Enter the user password and press **Enter**.

7. Highlight and select Internal HDD Password and use the **PgUp/PgDn** keys to enable the selection. (Follow this step to enable password protection for the internal HDD.)

Changing Hard Disk Drive Passwords

To change hard disk drive passwords, enter the System Security Setup, highlight Internal HDD Password and enter the current password that you wish to change. If you enter the current master password, you are prompted to enter a new master password. If you enter the current user password, you are prompted to enter the new user password. If you do not wish to establish a new master or user password, press **Esc** instead of entering a new password.

Using Hard Disk Drive Password Protection

To facilitate the transfer of one or more HDDs between systems, establish a single master password (and document the password in a secure place). Forgetting your master password results in the inability to access the data on your hard drive. Establish different user passwords to limit access to specific systems.



WARNING If you set the master and user password on a hard drive, the passwords can never be removed. They can be changed. If the master password is forgotten and the drive is installed in another system, you cannot access the data on the hard drive.

If the hard drive is installed in another NEC Versa system with hard disk drive security enabled, the password must be entered to allow access to the hard drive. **If this NEC Versa system does not support hard disk drive security, you cannot access the data on the hard drive.**

With hard disk drive security enabled on the original NEC Versa system, the system boots normally.

If the hard drive is installed in another NEC Versa system with security enabled, you must enter the master password to access the hard disk drive. If the hard drive is installed in another NEC Versa system with security disabled, you are prompted to enter the master password and then a new user password.

Moving the Hard Disk Drive

When a password protected HDD is moved from its original system and installed in another system and the system is powered on, error messages appear indicating that the drive is locked. Next, the Security Setup screen appears requiring the user to enter the master password to unlock the drive. To unlock the drive, highlight the HDD password line and enter the master password, when prompted.

If you wish to move an HDD from one system to another, follow steps 1 through 6 in the section, “Establishing Hard Disk Drive Passwords,” before installing the HDD in a different system. Install the HDD in the desired system, then follow step 7 to establish HDD protection.

To take advantage of HDD password protection in another system, the system must be equipped with the same HDD password protection feature. To determine if the system has HDD password, check the System Security Setup in the BIOS setup to see if there are provisions for establishing HDD passwords.

Power Management Setup

Your Versa FXi system ships with the Windows 2000 or Windows 98 operating system that uses the Advanced Configuration and Power Interface (ACPI) to control most power management functions through the Power Management Properties screen in Windows. For details about ACPI power management, see the section, “Managing System Power,” later in this chapter. The BIOS Power Management Setup screen is described next. Please note that some of the following definitions do not apply under Windows 2000/98 with ACPI, as noted.

Note In Windows 2000/98, the term “Standby” is functionally the same as the term “Suspend” that is referenced in the BIOS Setup Utility.

Power Management Setup

| Parameter | Default Setting | Alternate Setting(s) |
|-----------------------------------|------------------------|--|
| System Switch | Power Button | Sleep Button |
| Power Management under AC | Off | On |
| Power Savings Level | Longest Life | High Perform/Custom/Off |
| CPU Speed Control ¹ | 50% | 12.5, 25, 100% |
| Hard Disk Timeout ¹ | 2 minutes | 5/30/45 sec; 1/4/6/8/10/15 min. Off |
| Video Timeout ¹ | 2 minutes | 30/45 sec.; 1/4/6/8/10/15 min. Off |
| Peripheral Timeout ¹ | On | Off |
| Audio Device Timeout ¹ | On | Off |
| Standby Timeout ¹ | 4 minutes | Off/1/2/6/8/10/15 min. |
| Auto Suspend Timeout ¹ | 10 minutes | Off/5/15/20/25/30 min. |
| LCD Suspend | Disabled | Enabled |
| Suspend Option | Suspend | STF |
| Auto Save-to-File | Enabled | Disabled |

Power Management Setup

| Parameter | Default Setting | Alternate Setting(s) |
|--------------------------------|------------------------|--|
| Panel Brightness | Auto | User Defined |
| Suspend Warning Tone | Enabled | Disabled |
| Remote Power On | Disabled | Enabled |
| Wake Up Alarm | Disabled | Enabled |
| Resume Alarm Time ² | Off | Set time in 5 min. increments when Wake Up Alarm is set. |

¹ Available when power savings is set to Custom.

² Resume alarm time is selectable when wake up from suspend alarm is set.

- **System Switch** — Sets the Power button as a power switch or a sleep button.
- **Power Management Under AC** — Specifies whether to enable power management features when AC power is in use. When AC power is connected to your NEC Versa system, power management is usually disabled. If you enable this parameter, the system automatically activates the power management profile you set, even when AC power is used.
- **Power Savings Level** — Specifies one of four levels of power management. (Not applicable in Windows 2000/98 with ACPI.)
 - **High Performance** — provides good battery life and best performance with only minimal power conservation. Use while on the road or traveling short distances.
 - **Longest Life** — provides best battery life, the maximum amount of power savings, and good performance. Use while traveling long distances.
 - **Off** — disables power management and all device timeouts. Works well in an office environment while powering your NEC Versa with AC power.
 - **Custom** — lets you define power management levels and specific device timeouts according to your own needs and present environment. Custom lets you set the following timeouts.

Custom Timeout Options

| Option | Definition |
|-------------------|--|
| CPU Speed Control | Sets CPU performance at one of four levels. |
| Hard Disk Timeout | Sets the time delay before your hard disk powers down. |

Custom Timeout Options

| Option | Definition |
|----------------------|--|
| Video Timeout | Sets the time delay before your video powers off. |
| Peripheral Timeout | Sets the time delay before your peripherals are controlled by power management. |
| Audio Device Timeout | Sets the time delay before your audio device powers off. |
| Standby Timeout | Selects the system standby timeout period. |
| Auto Suspend Timeout | Defines how much time elapses from the time the system enters Standby mode to the time the system automatically enters Suspend mode. |

- **LCD Suspend** — Allows you to Suspend/Resume when the LCD panel is closed. (Not applicable in Windows 2000/98 with ACPI.)
- **Suspend Option** — Specifies either Suspend or Save to File (STF) when the LCD Suspend parameter is enabled. For more details about using this parameter in Windows 2000/98, see the section, “Managing System Power,” later in this chapter.
- **Automatic STF** — Enables the system, after 30 minutes in Suspend mode, to save the current working environment to a special file on the hard disk and to power down the system. For more details about using this parameter in Windows 2000/98, see the section, “Managing System Power,” later in this chapter.
- **Panel Brightness** — Selects the LCD screen brightness.
- **Suspend Warning Tone** — Specifies whether the system warning tone sounds when Suspend mode starts. It is best to keep this option enabled. (Not applicable in Windows 2000/98 with ACPI.)
- **Remote Power On** — Allows the serial port modem or LAN board to wake the system on a ring signal.
- **Wake Up from Suspend Alarm/Resume Alarm Time** — Allows the alarm to resume the system from suspend. Designates the time parameter in five minutes increments. (Not applicable in Windows 2000/98 with ACPI.)

Boot Device Setup

Boot Device Setup allows you to define the following functions.

Boot Device Setup

| Parameter | Default Setting | Alternate Setting(s) |
|--|------------------------|---|
| Quick Boot | Enabled | Disabled |
| Silent Boot | Enabled | Disabled, Black |
| Boot Display Device | Simul. Mode | CRT only, LCD only |
| BootUp NumLock | Off | On |
| 1 st Boot Device ¹ | CD-ROM/CD-RW | Disabled/1 st Fnd IDE/ Floppy/Network |
| 2nd Boot Device ¹ | Floppy | Disabled/1 st Fnd IDE/ CD-ROM/CD-RW |
| 3rd Boot Device ¹ | IDE HDD | Disabled/Floppy/ CD-ROM/CD-RW |
| Try Other Boot Devices | Yes | No |

¹ Bootable device when set to IDE hard drive. Only one IDE device is allowed to be bootable.

- Quick Boot — Specifies whether the system performs all tests during system boot.
- Silent Boot — Specifies whether to display the NEC logo during the system boot.
- Boot Display Device — Specifies the display device(s) for system boot messages.
- BootUp NumLock — Specifies whether NumLock is On or Off at system startup.
- Boot Devices — Specifies the sequence of boot devices.
- Try other Boot Devices — Specifies whether or not the system attempts to boot from other devices if all selected boot devices fail to boot.

Peripheral Setup

In the Windows 2000/98 environment, most device management is controlled through the Windows device manager. Use the Windows device manager to enable and disable devices on your NEC Versa FXi system.

The Peripheral Setup menu displays the connection locations between the system and the Input/Output (I/O) ports and lets you specify different port assignments as needed.

Peripheral Setup

| Parameter | Default Setting | Alternate Setting(s) |
|---------------------|-----------------|--|
| USB Controller | Disabled | Enabled |
| Internal Hard Drive | Enabled | Disabled |
| Parallel Port | Auto | Disabled/LPT1/LPT2 (PnP OS Setup ¹) |
| Parallel Mode | Bi-Dir | Uni-Dir/EPP/ECP |
| IR Serial Port | Auto | Disabled/(PnP OS Setup ¹) COM2,IRQ3/COM3,IRQ4/ COM4,IRQ3 |

¹ Appears only when configured by the Windows device manager.

Note If you disable a device in Peripheral Setup, you may not be able to enable or assign it using the Windows device manager. The device may not be listed in the Windows device list. To control the device using the Windows device manager, select any setting other than Disabled in Peripheral Setup.

Peripheral Setup allows you to define the following functions.

- USB Controller — Enables or disables the USB controller.
- Internal Hard Drive — Enables or disables the internal hard drive.
- Parallel Port/Parallel Mode — Disables or reassigns the parallel port and selects a parallel port mode.
- IR Serial Port — Enables, disables or reassigns the IR serial port.

Other BIOS Setup Options

BIOS Setup offers other options, including the following:

- **Change Language Setting** — Controls the BIOS setup language display. English, Japanese, and French are the available options.
- **Refresh Battery** — Launches the Refresh Battery utility. Once launched, the utility fully discharges your battery to eliminate any residual memory effect. Once refreshed, your battery is conditioned to recharge to its full capacity. To recharge the battery, connect your NEC Versa to AC power. This process may take up to four hours to complete.
- **Auto Configuration with Defaults** — Loads default configuration settings.
- **Save Settings and Exit** — Accepts changes made to current settings, saves to CMOS, and exits BIOS Setup.
- **Exit Without Saving** — Reverts to previously selected settings and exits Setup.

Managing System Power

In the Windows 2000/98 environment, your NEC Versa manages its power resources using the Advanced Configuration and Power Interface (ACPI) while the system is powered on using AC or battery (DC) power. ACPI enables the operating system to manage the power given to each attached device and to turn off a device when not in use.

Take advantage of the opportunity to manage power on your system to:

- Minimize battery drain.
- Preserve the life of your NEC Versa.
- Save time. When you return from that urgent call or meeting, you don't have to reboot, just slide the Power button to the right to resume system operation.

Windows 2000 Power Options Properties

In Windows 2000, most ACPI power management settings are controlled through Windows Power Options Properties, not through the BIOS Setup utility. To access Windows 2000 Power Options Properties, go to Start, Settings, Control Panel, and double click Power Options.

The Power Options Properties features are broken down as follows:

- Power Schemes
- Alarms
- Power Meter
- Advanced
- Hibernate

Windows 2000 Power Schemes

Use the Power Schemes options to define the appropriate Power scheme for your system, and to set timeouts for standby, LCD panel, and hard disk. Define parameters for your system when running under AC (plugged in) or DC (running on batteries) power.

Power Schemes

| Parameter | Default Setting | Alternate Setting(s) |
|--|------------------------|--|
| Power Schemes | Portable/Laptop | Home/Office Desk, Presentation, Always On, Minimal Power Management, Max Battery |
| Turn off monitor (Plugged In) | After 15 Minutes | 1, 2, 3, 5, 10, 15, 20, 25, 30, 45 minutes; 1, 2, 3, 4, 5 hours; Never |
| Turn off monitor (Running on batteries) | After 5 Minutes | 1, 2, 3, 5, 10, 15, 20, 25, 30, 45 minutes; 1, 2, 3, 4, 5 hours; Never |
| Turn off hard disks (Plugged In) | After 30 Minutes | 3, 5, 10, 15, 20, 25, 30, 45 minutes; 1, 2, 3, 4, 5 hours; Never |
| Turn off hard disks (Running on batteries) | After 3 Minutes | 3, 5, 10, 15, 20, 25, 30, 45 minutes; 1, 2, 3, 4, 5 hours; Never |

Power Schemes

| Parameter | Default Setting | Alternate Setting(s) |
|--|------------------|--|
| System Standby (Plugged In) | After 20 Minutes | 1, 2, 3, 5, 10, 15, 20, 25, 30, 45 minutes; 1, 2, 3, 4, 5 hours; Never |
| System Standby (Running on batteries) | After 5 Minutes | 1, 2, 3, 5, 10, 15, 20, 25, 30, 45 minutes; 1, 2, 3, 4, 5 hours; Never |

- Power Schemes — Defines the most appropriate power scheme for your computer.
- Turn off monitor — Selects the time delay before your LCD panel turns off.
- Turn off hard disks — Selects the time delay before your hard disk(s) power down.
- System standby — Selects the system standby timeout period for your system when running under AC or DC power.

Windows 2000 Alarms

Use the Alarms screen to define the point at which the battery alarm activates. Define the alarm to either sound, display a warning message, or invoke Standby, Hibernate or Shutdown.

Alarms

| Parameter | Default Setting | Alternate Setting(s) |
|---------------------------|-----------------|---|
| Low battery alarm | 10% | 0-100% |
| Alarm Action Notification | Display message | Sound alarm |
| Alarm Action Power level | none | Standby, Power Off |
| Critical battery alarm | 3% | 0-100% |
| Alarm Action Notification | Display message | Sound alarm |
| Alarm Action Power level | Standby | Power Off |
| Run a program | none | When the alarm occurs, run this program. |

- Low battery alarm — Allows you to define a low battery alarm percentage, notification, and system action.

- Critical battery alarm — Allows you to define a critical battery alarm percentage, notification, and system action.
- Run a program — Allows you to run a specific program when an alarm occurs.

Windows 2000 Power Meter

The Power Meter screen displays the remaining battery power and charging status for the primary and secondary batteries. Choose to display either a percentage progress bar or a battery icon with percentage indicator for your battery status information.

Windows 2000 Advanced

The Advanced window allows you to select behaviors for the taskbar icon, standby password, LCD panel, when closed, and the Power button.

Advanced

| Parameter | Default Setting | Alternate Setting(s) |
|--|------------------------|-----------------------------|
| Always show icon on taskbar | unchecked | checked |
| Prompt for password when computer goes off standby | checked | unchecked |
| When I close the lid on my computer | None ¹ | Standby, Power Off |
| When I press the Power button on my computer | Power Off | Standby |

¹ When None is selected, LCD panel turns off when closed.

- Always show icon on the taskbar — determines whether or not the Power Meter icon displays on the taskbar.
- Prompt for password when computer goes off standby — Determines whether or not the system prompts for your Windows password when resuming from Standby.
- When I close the lid of my computer — Defines the system action when the LCD panel is closed.
- When I press the Power button on my computer — Defines the system action when the Power button is used.

Windows 2000 Hibernate

Use the Hibernate window to enable hibernate support, see the amount of free disk space, and the amount of disk space required to hibernate. When your system hibernates, it performs a save-to-disk or save-to-file (STF). Your current working environment is saved to the hard disk. Use the Power button to resume from hibernation and your system returns to its previous state.

To enable hibernate support, go to Start, Settings, Control Panel, and double click the Power Management Properties icon. Select the Hibernate tab and place a check mark in the box labeled 'Enable hibernate support.' Click Apply, click OK, and close the Control Panel.

Note When powering on your NEC Versa running the Windows 2000 operating system, you may encounter a warning message suggesting that a problem exists with the hibernation file on your system. The warning message is inaccurate. To disable this message, simply follow the instructions in the previous paragraph to enable hibernate support.

Windows 98 Power Management Properties

In Windows 98, most ACPI power management settings are controlled through Windows Power Management Properties, not through the BIOS Setup Utility, unless otherwise noted. To access Windows Power Management Properties, go to Start, Settings, Control Panel, and double click Power Management.

The Power Management Properties features are broken down as follows:

- Power Schemes
- Alarms
- Power Meter
- Advanced
- Hibernate

Windows 98 Power Schemes

Use the Power Schemes options to define the appropriate Power scheme for your system, and to set timeouts for standby, LCD panel, and hard disk. Define parameters for your system when running under AC (plugged in) or DC (running on batteries) power.

Power Schemes

| Parameter | Default Setting | Alternate Setting(s) |
|--|------------------------|--|
| Power Schemes | Portable/Laptop | Home/Office Desk, Always On |
| System Standby (Plugged In) | After 20 Minutes | 1, 2, 3, 5, 10, 15, 20, 25, 30, 45 minutes; 1, 2, 3, 4, 5 hours; Never |
| System Standby (Running on batteries) | After 5 Minutes | 1, 2, 3, 5, 10, 15, 20, 25, 30, 45 minutes; 1, 2, 3, 4, 5 hours; Never |
| Turn off monitor (Plugged In) | After 15 Minutes | 1, 2, 3, 5, 10, 15, 20, 25, 30, 45 minutes; 1, 2, 3, 4, 5 hours; Never |
| Turn off monitor (Running on batteries) | After 2 Minutes | 1, 2, 3, 5, 10, 15, 20, 25, 30, 45 minutes; 1, 2, 3, 4, 5 hours; Never |
| Turn off hard disks (Plugged In) | After 30 Minutes | 3, 5, 10, 15, 20, 25, 30, 45 minutes; 1, 2, 3, 4, 5 hours; Never |
| Turn off hard disks (Running on batteries) | After 3 Minutes | 3, 5, 10, 15, 20, 25, 30, 45 minutes; 1, 2, 3, 4, 5 hours; Never |

- Power Schemes — Defines the most appropriate power scheme for your computer.
- System standby — Selects the system standby timeout period for your system when running under AC or DC power.
- Turn off monitor — Selects the time delay before your LCD panel turns off.
- Turn off hard disks — Selects the time delay before your hard disk(s) power down.

Windows 98 Alarms

Use the Alarms screen to define the point at which the battery alarm activates. Define the alarm to either sound, display a warning message, or invoke Standby, Hibernate or Shutdown.

Alarms

| Parameter | Default Setting | Alternate Setting(s) |
|---------------------------|------------------------|------------------------------|
| Low battery alarm | 10% | 0 - 100% |
| Alarm Action Notification | Display message | Sound alarm |
| Alarm Action Power level | none | Standby, Hibernate, Shutdown |
| Critical battery alarm | 3% | 0 - 100% |
| Alarm Action Notification | Display message | Sound alarm |
| Alarm Action Power level | Hibernate | Standby, Shutdown, none |

- Low battery alarm — Allows you to define a low battery alarm percentage, notification, and system action.
- Critical battery alarm — Allows you to define a critical battery alarm percentage, notification, and system action.

Windows 98 Power Meter

The Power Meter screen displays the remaining battery power and charging status for the primary and secondary batteries. Choose to display either a percentage progress bar or a battery icon with percentage indicator for your battery status information.

Windows 98 Advanced

The Advanced window allows you to select behaviors for the taskbar icon, standby password, LCD panel, when closed, and the Power button.

Advanced

| Parameter | Default Setting | Alternate Setting(s) |
|--|-----------------|---|
| Always show icon on taskbar | checked | unchecked |
| Prompt for password when computer goes off standby | unchecked | checked |
| When I close the lid on my computer | None | Hibernate, Shutdown, Standby ¹ |
| When I press the Power button on my computer | Shutdown | Standby, Hibernate |

¹ When None is selected, LCD panel turns off when closed.

- Always show icon on the taskbar — Determines whether or not the Power Meter icon displays on the taskbar.
- Prompt for password when computer goes off standby — Determines whether or not the system prompts for your Windows password when resuming from Standby.
- When I close the lid of my computer — Defines the system action when the LCD panel is closed.
- When I press the Power button on my computer — Defines the system action when the Power button is used.

Windows 98 Hibernate

Use the Hibernate window to enable hibernate support. When your system hibernates it performs a save-to-disk or save-to-file (STF). Your current working environment is saved to the hard disk. Use the Power button to resume from hibernation and your system returns to its previous state.

Windows 2000/98 Power Management States

ACPI uses different levels or states of power management. These power management states occur automatically, based on the system's default settings, or manually, when invoked. Settings are configurable to occur while on battery power or AC power.

The Windows 2000/98 ACPI power management states include:

- LCD timeout — manages power at the lowest level by shutting down the LCD.
- Standby — also known as Save-to-RAM (STR), Standby manages power by saving your current working environment to memory and shutting down most system devices. Conserves more power than an LCD timeout.
- Hibernate — also known as save-to-disk, or save-to-file (STF) manages power by saving the current working environment to an area on your hard disk, then powering off your system. Conserves the most battery power.

Recognizing the Windows 2000/98 Power Management States

It is important to recognize your system's behavior when in each of these power management states. The following table describes the system behavior for each power management state.

Windows 2000/98 Power Management Behavior

| | LCD Timeout | Standby (STR) | Hibernate (STF) |
|------------------------|---|---|--|
| Default Setting | 2 Minutes, DC power 15 Minutes, AC power | 5 Minutes, DC power 20 minutes, AC power | 30 minutes after Standby. ^{1,2} |
| Manually Invoke | Close LCD panel. | Go to Start, Shutdown, Standby. | Close LCD panel. ³ Press Power button. ³ |
| System behavior | LCD panel is blank. Status LED lights green. | LCD panel is blank. Status LED blinks green. | LCD panel is blank. Status LED turns off. Progress bar indicates that current working environment is saved to hard disk. |
| Resume | Press any key. | Press Power button. | Press Power button. Progress bar appears during process. |

¹ Only when BIOS "Suspend Option" set to STF and BIOS "Auto Save to File" set to enabled.

² Also when 3% battery power remaining, if BIOS set as in number 1.

³ Only when set in Advanced Windows Power Management Properties.

Updating the BIOS

The BIOS is code transmitted onto your system's microprocessor, or central processing unit (CPU). As indicated in this chapter, you use the BIOS Setup Utility to configure your system's software and hardware features. Only use the BIOS Update Diskette for your specific model, to update your NEC Versa system BIOS.

Note You only need to update the BIOS if NECC makes significant improvements or fixes to the current system BIOS. Your authorized NECC dealer or NECC Support Services representative can help you determine this.

To update the system BIOS you must:

- Obtain the BIOS Update
- Prepare the BIOS Update Diskette
- Enable the BIOS Flash Switch Setting
- Perform the BIOS Update
- Disable the BIOS Flash Setting

Obtaining the BIOS Update

If you are informed that the default BIOS needs an update contact NECC Support Services at (800) 632-4525, Fax (801) 981-3133, or access the web site, www.nec-computers.com to obtain a copy of the BIOS update.

Note If you purchased and are using this computer outside the U.S. or Canada, please contact a local NECC or dealer in your country.

Preparing the BIOS Update Diskette

Before using the BIOS update diskette you must make the diskette BIOS flash ready. Refer to the **readme.txt** file on the diskette before using the diskette.

Follow these instructions to prepare the BIOS Update Diskette.

1. Scan your hard drive for any computer viruses.
2. Unlock the write protect notch on the diskette, if necessary.
3. Insert the diskette into the external floppy diskette drive.

4. Type **a:install** (where a: is the floppy diskette drive) at the DOS prompt and follow the on-screen instructions.

Install.bat copies the DOS system files from your hard drive onto the BIOS Update Diskette to make it BIOS flash ready.

The system prompts you when the process is complete.

5. Scan the BIOS Update Diskette for computer viruses.

The diskette is ready for use.


6. Follow the instructions later in this chapter, “Enabling the BIOS Flash Switch.”

Identifying the Switch Settings

A six-position dip switch is located on the bottom of the system in the memory module bay. The following list identifies each switch setting and its function.

- Switch 1, Password Override Switch — The default setting is “OFF.” If you forget your password and cannot access the data on your NEC Versa, change the setting to “ON” and your current password is erased.
- Switch 2 — Keyboard select; Default is “ON” for U.S. 85 key keyboard.
- Switch 3 — Reserved for factory use; Default is “ON.”
- Switch 4 — Keyboard select; Default is “ON” for U.S. 85 key keyboard.
- Switch 5 — BIOS flash enable; Default is “OFF” (disable). Before updating your BIOS, change the setting to “ON.”
- Switch 6 — Logo select; Default is “OFF” for U.S.

Default switch settings



Dip switches 2, 3, and 4 set to “On.”


Enabling the BIOS Flash Switch

Before performing the BIOS update, be sure to enable the BIOS flash switch. Set switch 5 to “ON” before performing the BIOS update.

Follow these steps to enable the BIOS flash switch.

1. Make sure the system is powered off and that no peripheral devices are attached.
2. Turn over the system and locate the memory module bay.

Locating the memory module bay




A – Memory Module Bay Cover

B – Screw

3. Remove the screw and bay cover.

Removing the screw and bay cover




4. Locate the dip switch block. Using a fine-tipped object, change switch 5 to “ON” to enable the BIOS flash.



CAUTION Never use a pencil to change switch settings. Residue from the pencil can damage the system.

BIOS flash switch enabled



Dip switches 2, 3, 4, and 5 set to “On.”

Note The system memory expansion slot is also located here. Therefore, if you need to install/replace SO-DIMM modules, you might want to do so while the system is already disassembled.

5. Replace the memory module bay cover and screw.
6. Turn over the system.
7. Follow the instructions later in this chapter, “Performing the BIOS Update.”

Performing the BIOS Update

Follow these steps to perform the BIOS update. Before you begin, be sure to:

- Connect the computer to AC power and power off the computer.
 - Configure the Boot Device Setup to boot from a floppy diskette.
 - Remove any bootable CDs from the CD-ROM drive, if connected.
 - Document all customized BIOS settings.
1. Insert the BIOS Update diskette into the floppy diskette drive.
 2. Power on the computer with the diskette in the floppy diskette drive. The computer boots and automatically loads the utility. Read the message that displays and follow the instructions.
 3. Press **Enter** to continue.

The utility checks the currently installed BIOS version and the diskette's BIOS version. The Main menu appears.
 4. Use the arrow keys to highlight the “Display BIOS Version” option on the Main Menu. Use this option to check the currently installed BIOS version and the version of the new replacement BIOS.

Press any key to return to the Main menu.
 5. Highlight the “Install New BIOS” option and press **Enter**.
 6. Press **Y** and then press **Enter**. After a brief pause, a message appears telling you to remove the diskette from the file bay drive.
 7. Remove the diskette and press any key to continue. The utility updates the BIOS.

Power off your computer. The next time you power on your computer, you will have the latest NEC Versa FXi computer BIOS revision level.

-
8. Power on your computer. A CMOS Checksum message appears and prompts you to press **F1** to enter Setup.
 9. Press **F1** to enter Setup and restore the default parameter settings.
 10. Be sure to modify any custom settings that you may have configured.
 11. Disable the BIOS flash switch. Change switch 5 back to “OFF” after completing the BIOS update. For details about enabling and disabling the BIOS flash switch, see the section earlier in this chapter, “Enabling the BIOS Flash Switch.”

4

Using the Operating System and Utilities

- Windows Introduction
- NEC Utilities
- SpeedStep Applet
- Application and Driver CD
- NEC Info Center
- Partition Magic
- Product Recovery CD

Windows Introduction

Your NEC Versa comes pre-installed with the Windows 2000 or the Windows 98 operating system. The Microsoft® operating system provide a means of running applications, navigating through your file structure, and using your notebook computer. Each operating system offers its own look and tools and employs its own easy-to-use graphical interface.

Windows 2000

Windows 2000 gives you the newest features offered by Microsoft, including a Desktop with room to maneuver, taskbar icons for quick access to installed applications, a system performance and monitoring manager, enhanced entertainment features, and a fully integrated Internet experience.

Desktop Icons

With Windows 2000, the following icons are installed on your desktop:

- My Computer — Provides access to drives, printers, the control panel, network features, and scheduled tasks.
- Recycle Bin — Gives you a trash container in which to put and discard unwanted files or allows you to restore those same files back to their original location.
- My Network Places — When on a network, provides access to network printers and other computers on your network. Use my network places to browse through the computers in your workgroup and the computers in the entire network.
- My Documents — Provides you with a convenient place to store documents, graphics, and other files for quick access.
- Connect to the Internet — Runs the Internet Connection wizard that helps you to set up your computer to access the Internet.

Note Before connecting to the Internet, you must either connect an optional modem and a working phone line to your system or install a LAN card for network access.

Your NEC Versa comes with all the software you need to get started on the most popular services available today. For a fee, online services give you access to the Internet, email, the world wide web, travel information, news reports, and more.

Note Before choosing and registering for an online service, you must connect an optional modem to your system and to a working phone line. The phone line must be analog. If you are unsure what type of line you have, call your local phone company.

If you are using this product outside of the United States or Canada, some online services may require a long-distance or international call.

- NEC Customize — Gives you the option to launch the Application and Driver CD.
- Internet Explorer — Provides your default internet program. Also access Internet Explorer under Start, Programs, Internet Explorer.

Taskbar Icons

With Windows 2000, three icons appear on the taskbar. Use the cursor to hover over the icon and display its function, right click the icon to display its menu options, or double click the icon to launch it.

The following icons normally appear on the left side of the Windows 2000 taskbar.

- Internet Explorer — Allows you to browse the internet or view local HTML files. Also access Internet Explorer under Start, Programs, Internet Explorer.
- Outlook Express — Provides your default email program with secure and personalized features for email and newsgroup communication. Also access Outlook Express under Start, Programs, Outlook Express.
- Show Desktop — Minimizes all active screens to display your desktop.

Windows 98 Second Edition

Windows 98 gives you the newest features offered by Microsoft, including a Desktop with room to maneuver, a taskbar for quick access to a variety of system functions, state-of-the-art plug and play support, powerful system utilities, enhanced entertainment features, and a fully integrated Internet experience.

Desktop Icons

With Windows 98, the following icons are installed on your desktop:

- My Computer — Provides access to drives, printers, the control panel, network features, and scheduled tasks.
- Recycle Bin — Gives you a trash container in which to put and discard unwanted files or allows you to restore those same files back to their original location.

-
- **Set Up the Microsoft Network** — Provides a setup program that allows you to sign-up for the Microsoft Network. If you already have an account, use this interface to sign-on to the Microsoft Network.
 - **Network Neighborhood** — Appears when your computer is connected to a network. Use the network neighborhood to browse through the computers in your workgroup and the computers in the entire network.
 - **My Briefcase** — Provides a mechanism for file synchronization between the NEC Versa and another system.
 - **My Documents** — Provides you with a convenient place to store documents, graphics, and other files for quick access.
 - **Connect to the Internet** — Runs the Internet Connection wizard that helps you to set up your computer to access the Internet.

Note Before connecting to the Internet, you must either connect the internal modem to a working phone line or install a LAN card for network access.

In addition, you must run the Internet Connection wizard to establish a dial-up networking connection for internet access.

- **Online Services** — Includes setup icons for a variety of online services.

Your NEC Versa comes with all the software you need to get started on the most popular services available today. For a fee, online services give you access to the Internet, email, the world wide web, travel information, news reports, and more.

Note Before choosing and registering for an online service, connect the internal modem to a working phone line or install a LAN card for network access.

If you are using this product outside of the United States or Canada, some online services may require a long-distance or international call.

- **NEC Customize** — Gives you the option to launch the Application and Driver CD or to install the External Drive Connect utility.
- **Outlook Express** — Provides your default email program with secure and personalized features for email and newsgroup communication. Also access Outlook Express under Start, Programs, Internet Explorer.

Taskbar Icons

With Windows 98, a number of icons appear on the taskbar. Use the cursor to hover over the icon and display its function, right click the icon to display its menu options, or double click the icon to launch it.

The following icons normally appear on the left side of the Windows 98 taskbar.

- Internet Explorer — Allows you to browse the Internet or view local HTML files. Also access Internet Explorer under Start, Programs, Internet Explorer.
- Outlook Express — Provides your default email program with secure and personalized features for email and newsgroup communication. Also access Outlook Express under Start, Programs, Internet Explorer.
- Show Desktop — Minimizes all active screens to display your desktop.

The following icons normally appear on the right side of the Windows 98 taskbar.

- Task Scheduler — Enables you to schedule tasks, such as Disk Defragmenter, to run regularly. Also access Task Scheduler under Start, Programs, Accessories, System Tools, Scheduled Tasks.
- Power Management Properties — Displays your current power source and total remaining battery power. Access Power Management Properties under Start, Settings, Control Panel, Power Management.
- Infrared Monitor — Allows you to enable, disable, and control the infrared communication on your notebook computer.
- NEC VersaGlide — Allows you to adjust your VersaGlide (mouse) properties. Also access NEC VersaGlide under Start, Settings, Control Panel, Mouse.
- Volume Control — Adjusts the volume and speaker balance when you play audio files. Also access Volume Control under Start, Programs, Accessories, Entertainment, Volume Control.
- Time Clock — Allows you to adjust the time and date, rearrange active windows on your desktop, create a new toolbar or customize your existing toolbar.

For more information about the desktop and taskbar icons, refer to the Windows 98 online help.

NEC Utilities

NECC provides several programs and routines designed to make your NEC Versa run more efficiently.

The NEC utilities include:

- NEC Customize utility
- HDPREPEZ utility

NEC Customize Utility

The NEC Customize Utility gives you the option to install or launch the:

- Application and Driver CD — Use this option to install a variety of software applications, drivers, utilities, internet browsers, and the NEC Info Center.
- External Drive Connect Utility — Use this option to take advantage of warm connecting the CD-ROM drive to your NEC Versa FXi computer. For details about the External Drive Connect utility, see Chapter 5, “Using the System Drives and Bays.” (Windows 98 Second Edition, only.)

NEC Customize Utility Screen

The NEC Customize Utility screen consists of the following.

- A window at the top half of the screen lists the available options.
- The window below the options list displays a description of each option when the option is highlighted.
- The Launch button initiates a selected option when clicked.
- The More Info button provides an overview of the NEC Customize utility.
- The Exit button closes the NEC Customize utility.

Using the NEC Customize Utility

Follow these steps to use the NEC Customize Utility.

1. Double click the NEC Customize icon.
2. From the display window, select the desired option.
3. Click Launch or Install to initiate the selected option.
4. Follow the on-screen instructions to process the selected option.
For some of the selected options you are prompted to reboot your system.
5. If necessary, click Exit to close the NEC Customize dialog box.

HDPREPEZ Utility

The HDPREPEZ utility automatically configures your NEC Versa's system's save-to-file (STF) area on the hard disk drive.

Note For more details about the HDPREPEZ utility, see the HDPREPEZ.TXT file in the NECUTILS/HDPREP directory.

Using the HDPREPEZ Utility

In Windows 98, run the HDPREPEZ utility if you increase the memory capacity in your NEC Versa beyond the factory installed base memory.

Follow these steps to run the HDPREPEZ utility.

1. Go to Start, Shut Down, Restart the computer in MS-DOS mode.
2. At the c: prompt, type **LOCK C:** and press **Enter**.
A message displays asking you to confirm your command.
3. Press the indicated key to confirm your command.
4. At the c: prompt, type **cd \necutils\hdprep** and press **Enter** to change to the \necutils\hdprep directory.
5. Type **HDPREPEZ** and press **Enter**. The utility automatically prepares your NEC Versa for the newly installed memory.
6. Power off your system and then power on. A file, large enough to accommodate your system's memory is created on the hard disk drive.

SpeedStep Applet

Some processors that ship with the NEC Versa FXi notebook computer include the Intel® SpeedStep technology that allows you to customize high-performance computing on your NEC Versa, optimizing processing speed and conserving battery life.

If your processor is equipped with SpeedStep technology, an icon appears on your taskbar allowing you to adjust processing properties. However, the default settings are recommended for optimal performance and battery conservation.

Application and Driver CD

A variety of third-party software applications, drivers, utilities, internet browsers and the NEC Info Center are provided on the Application and Driver (A&D) CD that ships with your NEC Versa FXi system. Some of the drivers are already installed as part of your operating system environment. The additional software on the Application and Driver CD lets you take full advantage of your system resources.

Use the Application and Driver CD to install the software of your choice. Some software applications install their own desktop icon allowing quick access to the application. You can also access some applications through the Start, Programs menu.

Launching the Application and Driver CD with Windows 2000

Follow these procedures to launch the Application and Driver CD using NEC Customize with Windows 2000.

1. Insert the Application and Driver CD into the CD-ROM drive.
2. Double click the NEC Customize icon, if necessary.
3. Select Application and Driver CD.
4. Click Install to launch the CD.

The Application and Driver CD dialog box appears.

Launching the Application and Driver CD with Windows 98

Follow these procedures to launch the Application and Driver CD using NEC Customize with Windows 98.

1. Insert the Application and Driver CD into the CD-ROM drive.
2. Double click the NEC Customize icon, if necessary.
3. Highlight Launch Application and Driver CD.
4. Click launch.

The Application and Driver CD dialog box appears.

Application and Driver CD Dialog Box

The Application and Driver CD dialog box consists of the following components.

- Selection Tabs — Located just below the title bar, each tab represents a software category. The selection tabs include applications, drivers, utilities, internet browsers, and the NEC Online Documentation.
- Description — Located in the bottom portion of the dialog box, the text describes the selected or highlighted software category or application, driver, etc.
- Install — Clicking the Install button installs the selected software.
- View — Clicking the View button displays installation instructions for those utilities that are not installed using the A&D CD utility.
- Exit — Clicking the Exit button closes the Application and Driver CD dialog box.

Installing the A&D CD Software

Once the Application and Driver CD dialog box appears, follow these steps to install the desired software.

1. Click the selection tab of your choice.
2. Click the desired application, driver, or utility.
3. Click the Install button to install your selection.

Follow the on-screen instructions to install your selection.

4. Click Exit to close the Application and Driver CD dialog box.
5. Remove the CD from the CD-ROM drive when the installation is complete.

NEC Info Center

The Application and Driver CD contains the NEC Info Center, a fully navigational online document that provides a multimedia tour, information for the traveling professional and an online version of this printed user's guide.

Installing the NEC Info Center

To install the NEC Info Center simply follow the instructions, presented earlier in this chapter, for launching the A&D CD and installing the software. For the most current version of the *NEC Versa FXi User's Guide*, periodically check the NECC web site at <http://www.nec-computers.com/>.

Uninstalling the NEC Info Center

Use one of the following methods to uninstall the NEC Info Center.

- Use this method to uninstall the NEC Info Center using the Windows Add/Remove Programs feature.
 1. Go to Start, Settings, Control Panel, and double click Add/Remove Programs.
 2. Use the scroll bar, if necessary, to display the NEC Info Center item.
 3. Highlight NEC Info Center and click the Add/Remove button.
 4. Select Automatic as the uninstall method and click Next.
 5. Click Finish to complete the uninstall.
 6. When the uninstall is complete, click OK and close the Control Panel window.
- Use this method to uninstall the NEC Info Center using the Wise uninstall feature.
 1. Access the C:\NEC INFO directory on your hard disk drive.
 2. Double click the **unwise.exe** file or icon to remove all files and directories associated with the NEC Info Center.

Partition Magic

Dividing the hard disk drive into several partitions lets you efficiently organize operating systems, programs, and data. Partition Magic, included on the A&D CD that ships with your system, allows you to optimize hard disk drive space with an easy click of the mouse. Visually create, format, shrink, expand, and move hard disk partitions in minutes.

Your NEC Versa ships with an internal hard disk drive consisting of a single FAT 32 partition, drive C:. Use Partition Magic if you want to create multiple partitions and convert your hard disk drive to FAT 16 partitions.

 **CAUTION** Before using Partition Magic, refer to the associated cautionary notes on the Application and Driver CD. The cautionary notes contain important information about designating the partitions on the hard disk drive.

The partitions must be properly designated before using the Product Recovery CD to reinstall your operating system. If the partitions on the hard disk drive are not properly designated, it will appear as though data loss has occurred after using the Product Recovery CD.

Product Recovery CD

The Product Recovery CD contains the NEC Product Recovery Utility that allows you to restore your system to its initial installation state.

If you determine that you need to restore your system to its initial installation state follow the instructions provided here.

Note Only use the Product Recovery utility to restore your system to its initial installation state as a last resort. Check the problem checklist in Chapter 10 for information about solving problems before using the CD. The Product Recovery utility provides options that either remove or replace existing files, a process that may result in data loss.

 **CAUTION** Before using the Product Recovery CD, enter the BIOS Setup utility and restore the BIOS default settings. Save the default settings before exiting the BIOS Setup utility.

Guidelines for Using the Product Recovery CD

Follow these guidelines when using the Product Recovery CD.

- Use AC power.
- Remove all optional hardware such as PC cards, USB devices, printers, and monitors.

Product Recovery CD Options

The Product Recovery CD and Utility provides you with a number of choices. Move the cursor over each selection on the NEC Product Recovery Utility screen to display a description of the selection in the window at the right side of the screen.

- Restore System — Select this option if you wish to restore your hard disk drive to its initial installation state. Restore System allows you to restore your system in one of the following ways.
 - Full Disk Drive — Completely rebuilds your hard disk drive, destroying all existing data in the process.

Note Use the Full Disk Drive restore option if your hard disk consists of one partition (drive).

-
- Partition Only — Lets you preserve your existing hard disk drive partition structure and format only the primary partition without affecting the extended partition(s). Partition Only formats drive C: (of a multiple partitioned drive) and restores drive C: to its initial installation state. *To use the Partition Only option, drive C: must be equal to or greater than 1 GB.* Additional partitions, e.g., drives D:, E:, etc., remain intact. For important information about partitioning your hard disk drive, see the section, “Partition Magic,” earlier in this chapter.
-

Note Use the Partition Only restore option if your hard disk is partitioned into two or more partitions (drives).

- Exit — Exits the NEC Product Recovery Utility.

Full Disk Drive Restore

If your preinstalled software becomes unusable and you cannot boot from the hard disk, use the Product Recovery Utility to restore your system to its initial shipping configuration. The Full Disk Drive restore option *erases* the hard disk *completely* before reinstalling the files.

 **CAUTION** The Full Disk Drive restore option deletes *all* files on the hard drive and replaces them with the original factory installed files.

Only use the Full Disk Drive restore option if the preinstalled software is unusable.

Use the Product Recovery Utility to perform a Full Disk Drive restore as follows:

1. Check the Product Recovery CD title and make sure that it is the correct CD for your NEC Versa computer and operating system.
2. Power off your system before connecting the external CD-ROM drive to your NEC Versa.
3. Put the CD into the CD-ROM drive tray, close the drive door, and power on your system.
4. Read the License Agreement screen that appears. Use the VersaGlide touchpad to position the cursor on the Accept button. Left click to accept the agreement.

You have the option of accepting or declining the agreement. If you decline the agreement, the recovery utility exits.

5. In the NEC Product Recovery Utility screen, use the VersaGlide touchpad to choose Full Disk Drive to restore your hard disk drive to its original factory installed state.



CAUTION Choose your restore option carefully to prevent losing data and applications installed on your system.

6. Read the Warning screen.

A warning displays indicating that your hard disk is about to be erased.

7. Select Continue to proceed to perform a Full Disk Drive restore.

If you select Back, the recovery utility returns to the prior screen which has an exit option.

If you select Continue, a screen with progress bars displays and lets you know the progress of the recovery.



CAUTION Do not turn off or disturb the system during the recovery process.

8. When the recovery process is complete, you are prompted to remove the CD from the CD-ROM drive and reboot your system.
9. Press **Enter**, click Reboot, or press **Alt-R** to reboot your system.

A series of hardware detection screens display, the system reboots and the Windows Setup screen appears. Follow the on-screen instructions to set up Windows.

You are required to reenter your Microsoft license number.

Partition Only Restore

If your preinstalled software on drive C: of your multiple partitioned drive becomes unusable and you cannot boot from the hard disk, use the Product Recovery Utility to restore your primary partition to its initial shipping configuration.



CAUTION Use the Partition Only restore option only if your hard disk drive consists of multiple partitions *and* if drive C: contains the operating system and related drivers. Move all other data and applications to other partitions (drives) or the Partition Only restore process will erase them completely.

The Partition Only restore option deletes *all* files on drive C: and replaces them with the original factory installed files. Only use the Partition Only restore option if the preinstalled software on drive C: is unusable.

For important information about partitioning your hard disk drive, see the section, "Partition Magic," earlier in this chapter.

Use the Product Recovery Utility to perform a Partition Only restore as follows:

1. Check the Product Recovery CD title and make sure that it is the correct CD for your NEC Versa computer and operating system.
2. Power off your system before connecting the external CD-ROM drive to your NEC Versa.
3. Put the CD into the CD-ROM drive tray, close the drive door, and reboot your computer.
4. Read the License Agreement screen that appears. Use the VersaGlide touchpad to position the cursor on the Accept button. Left click to accept the agreement.

You have the option of accepting or declining the agreement. If you decline the agreement, the recovery utility exits.

5. In the NEC Product Recovery Utility screen, use the VersaGlide touchpad to choose Partition Only to restore drive C: of a multiple partitioned drive to its original factory installed state.



CAUTION Choose your restore option carefully to prevent losing data and applications installed on your system.

If the hard disk is configured with multiple or extended partitions you may have to reinstall some software to restore configuration settings and shared files.

6. Read the Warning screen.

A warning displays indicating that drive C: (the primary drive/partition) is about to be erased and formatted. It may be necessary to reinstall software to the other drives (partitions) to reestablish Start Menu links and other configuration requirements stored on drive C:.

7. Select Continue to proceed, to perform a Partition Only restore.

If you select Back, the recovery utility returns to the prior screen which has an exit option.

If you select Continue, a screen with progress bars displays and lets you know the progress of the recovery.



CAUTION Do not turn off or disturb the system during the recovery process.

8. When the recovery process is complete, you are prompted to remove the CD from the CD-ROM drive and reboot your system.

9. Press **Enter**, click Reboot, or press **Alt-R** to reboot your system.

A series of hardware detection screens display, the system reboots, and the Windows Setup screen appears. Follow the on-screen instructions to set up Windows.

You are required to reenter your Microsoft license number.

5

Using the System Drives and Bays

- External Floppy Diskette Drive
- External 24X CD-ROM Drive
- External Drive Connect Utility
- External CD Read/Write Drive
- Hard Disk Drive
- Memory Modules


External Floppy Diskette Drive

The NEC Versa FXi ships with a standard 3.5-inch, 1.44-MB external floppy diskette drive and cable. Use the floppy diskette drive to install applications, create a BIOS update diskette, or simply copy files to and from your NEC Versa FXi notebook computer.

Connect the drive to the FDD/Parallel port located on the left side of the system. When connected, the floppy diskette drive is assigned the letter a:. The FDD/Parallel port alternately allows you to connect a parallel device to your NEC Versa FXi notebook computer.

The external floppy diskette drive offers the following features, which are described after the figure.

External floppy diskette drive and cable



A – Status LED

B – Floppy Diskette Drive Connector

C – Floppy Diskette Drive

D – Eject Button

E – Floppy Diskette Drive Bay

F – Floppy Diskette Drive Cable Connector

G – Floppy Diskette Drive Cable

H – FDD/Parallel Port Connector

- Status LED — Lights to indicate drive activity.
- Floppy Diskette Drive Connector — Attach the floppy diskette drive cable to this connector.
- Floppy Diskette Drive — Use the cable provided to attach this drive to your system.
- Eject Button — Press this button to eject/remove a diskette from the floppy diskette drive.
- Floppy Diskette Drive Bay — Insert your floppy diskettes in this bay.
- Floppy Diskette Drive Cable Connector — Attach the small end of the connector to the floppy diskette drive cable.


- Floppy Diskette Drive Cable — Use this cable to connect the floppy diskette drive to your NEC Versa FXi system.
- FDD/Parallel Port Cable Connector — Attach the large end of the connector to the FDD/Parallel port on the left side of your system.

Connecting the External Floppy Diskette Drive

Follow these steps to connect the external floppy diskette drive to your NEC Versa FXi system.

1. Locate the external floppy diskette drive and cable that ships with your system.
2. Attach the large cable connector to the connector on the floppy diskette drive.
3. Attach the small cable connector to the FDD/parallel port on the NEC Versa FXi system.

Connecting the external floppy diskette drive



A – Floppy Diskette Drive Cable

B – Floppy Diskette Drive Connector

C – FDD/Parallel Port

4. Insert a floppy diskette into the drive bay and you are ready to go!

Disconnecting the External Floppy Diskette Drive


When disconnecting the external floppy diskette drive cable, squeeze the release clips before pulling the cable away from the system port or the diskette drive.



CAUTION

Failure to squeeze the release clips may result in damage to the cable connectors.

Floppy diskette drive cable



A – Release clips

External 24X CD-ROM Drive

Your NEC Versa FXi ships with an external 24X CD-ROM drive and cable that feature the latest in CD-ROM technology. Use the CD-ROM drive to load and start programs from a compact disc (CD). You can also use the CD-ROM drive to play your audio CDs. When your audio CD finishes playing the last track, the CD-ROM drive cover automatically opens. The 24X CD-ROM drive is fully compatible with Kodak Multisession Photo CDs™ and standard audio CDs.

Use the external 24X CD-ROM drive in the following ways:

- Connect the drive to the CD-ROM port on the right side of the system to load and start programs. When connected, the CD-ROM drive is assigned an available drive letter.


Note The first time that you connect the CD-ROM drive, do so before powering on the system. Once you install and use the External Drive Connect Utility, you can connect the CD-ROM drive while the system is powered on. For details, see the section, “External Drive Connect Utility,” later in this chapter.

- Connect the drive to an AC power source with the optional adapter, and use the drive as a stand-alone CD player to play your audio CDs.

The CD-ROM drive operates at different speeds depending on whether the CD you are using contains data or music. This allows you to get your data faster and to see smoother animation and video.

The external 24X CD-ROM drive and cable offer the following features, which are described after each figure.

External 24X CD-ROM drive, left and front




A – Headphone Jack
B – Volume Control
C – Release Latch

D – Status LED
E – Play/Stop Button
F – Forward Button

- Headphone Jack — Attach external headphones to listen to your audio CDs. (For stand-alone use, only. Do not use this headphone jack when the CD-ROM drive is connected to your NEC Versa.)
- Volume Control — Increase or decrease the volume of your audio CDs.
- Release Latch — Use this latch to open the cover of the CD-ROM drive and insert or remove a compact disc.
- Status LED — Lights green when powered on or connected to the NEC Versa. Lights amber during data read operations. Do not eject the CD or turn off the NEC Versa when the indicator lights amber.
- Play/Stop Button — Use this button to start or stop your compact discs.
- Forward Button — Use this button to advance the playback of your compact disc, one track at a time.

External 24X CD-ROM drive, right and rear




A – AC Power Port

B – CD-ROM Drive Connector

- AC Power Port — Use this port to connect the CD-ROM drive to an AC power source and use the drive as a stand-alone CD player.
- CD-ROM Drive Connector — Attach the CD-ROM drive cable to this connector to use the drive with your NEC Versa FXi system.

CD-ROM drive cable



A – CD-ROM Cable

B – Release Clips

C – CD-ROM Cable Connectors

- CD-ROM Drive Cable — Attach the CD-ROM drive to your notebook computer.
- Release Clips — Squeeze these clips before pulling the cable away from the system port or diskette drive.
- Cable Connectors — Use either connector to attach the cable to the CD-ROM drive or to the CD-ROM port on the right side of your NEC Versa FXi system.


Using the CD-ROM Drive with your NEC Versa

Follow these steps to connect to and use the external 24X CD-ROM drive with your NEC Versa FXi notebook computer.

Note The first time that you connect the CD-ROM drive to your NEC Versa FXi system, the system must be powered off. Once you install the External Drive Connect Utility, use the utility to connect the CD-ROM drive to your system while the system is powered on. For details, see the section, “External Drive Connect Utility,” later in this chapter.

1. Power off your NEC Versa.
2. Locate the external 24X CD-ROM drive and cable that ships with your system.
3. Attach either cable connector to the CD-ROM drive.
4. Attach the other cable connector to the CD-ROM port on the right side of the system.

Connecting the CD-ROM drive




A – CD-ROM Cable
B – CD-ROM Port

C – CD-ROM Drive Connector

-
5. Slide the release latch toward the front of the unit to open the cover.

Opening the CD-ROM drive cover



A – Release Latch

6. Put your CD, printed side up, into the circular impression in the drive.

Inserting a CD



7. Close the drive cover.
8. Run the setup, installation program or other instructions provided with the software application to start or load the CD contents.

Note Before recording from the external CD-ROM drive to the internal hard disk drive, disable the internal microphone. To disable the internal microphone, go to Start, Programs, Accessories, Entertainment, Volume Control. Choose options, Properties and remove the check from the Microphone box in the 'Show the following controls' window.

Using the CD-ROM Drive as a Stand-Alone CD Player

If you purchase the CD-ROM AC adapter accessory, you can use the external 24X CD-ROM drive as a stand-alone CD player. Follow these steps to use the CD-ROM drive as a stand-alone CD player.

1. Disconnect the CD-ROM drive from the NEC Versa FXi system.
2. Locate the CD-ROM AC adapter accessory.
3. Connect the CD-ROM AC adapter to the AC Power port on the right side of the CD-ROM drive.
4. Connect the outlet plug of the AC adapter to an active electrical wall outlet.
5. Follow steps 4-6 in the procedure, "Using the CD-ROM drive with your NEC Versa," to open the drive cover and insert a CD.
6. Press the Play button to activate your audio CD!


Disconnecting the CD-ROM Drive

When disconnecting the CD-ROM drive cable, squeeze the release clips before pulling the cable away from the system port or the CD-ROM drive.



CAUTION Failure to squeeze the release clips may result in damage to the cable connectors.

CD-ROM drive cable



A – CD-ROM Cable
B – Release Clips

C – CD-ROM Cable Connectors

CD Care

When handling CDs, keep the following guidelines in mind.

- Always pick up the disc by its edges.
- Avoid scratching or soiling the side of the disc that has no printing or writing on it. This is the data side of the disc.
- Do not write on or apply labels to either side of the disc.
- Keep the disc away from direct sunlight or high temperatures.
- Clean fingerprints or dust from the disc by wiping it with a soft cloth. Gently brush the cloth from the center of the disc toward the edge.



CAUTION Avoid using benzene, paint thinner, record cleaner, static repellent, or any other chemical on the disc. Chemicals and cleaners can damage the disc.

External Drive Connect Utility

The NEC Versa FXi supports warm connecting of the external 24X CD-ROM drive, (Windows 98, only) extending the power of Plug-and-Play technology on your system. This dynamic solution further increases the flexibility of your already versatile notebook computer.

Use the NEC Customize utility to install the External Drive Connect utility. For details about using the NEC Customize Utility, refer to Chapter 4 , “Using the Operating System and Utilities.”

Once the utility is installed on your system, a small icon appears in the lower right hand corner of the Windows taskbar. Moving your cursor over the icon displays information about the CD-ROM drive. The balloon message that appears indicates whether or not the drive is connected. Warm connecting is only supported for the CD-ROM drive. Use the External Drive Connect Utility to put your system into a sleep state before connecting a device.

Using the External Drive Connect Utility

With the External Drive Connect utility running on your notebook computer, you can warm connect or disconnect a CD-ROM drive to the right side of your system without powering off the computer.

Use the External Drive Connect Utility as follows:

1. If you have files open on the device you are planning to remove, close them.
2. Right click on the utility taskbar icon to display the menu.
3. Highlight and click on the Disconnect (or Connect) Device option.
4. A dialog box appears and lets you know that your system must be in a sleep state to remove or connect the device and asks you if you want to continue. Press **Yes** to put your system into a sleep state.
5. Once your system is in a sleep state, disconnect the device from or connect the device to your computer.
6. To resume your system after disconnecting or connecting a device, slide the Power button to the right.


References to the drive letter listed under My Computer and the Windows Explorer change automatically when the device is removed or connected. The balloon message that appears when you move your cursor over the taskbar icon also changes to reflect the new device status.

External CD Read/Write Drive

Your NEC Versa operates with an optional external CD-Read/Write drive with Easy CD Creator that features the latest in CD-ROM technology. Use the CD Read/Write drive to load and start programs from a compact disc (CD) or to play your audio CDs. The CD Read/Write drive is fully compatible with Kodak Multisession Photo CDs™ and standard audio CDs.

In addition, the Easy CD Creator application allows you to write information to a CD and backup information from your hard disk drive to a CD. For detailed information about using the external CD Read/Write drive and installing the Easy CD Creator, refer to the accessory sheet that ships with the component.

External CD Read/Write drive



A – Cable Connector Release Clips

B – Connector Storage Bay

C – Status LED

D – Emergency Eject Hole

E – Eject Button

- Cable Connector Release Clips— Squeeze these clips before pulling the cable away from the system port or diskette drive.
- Connector Storage Bay — Store the CD Read/Write Connector in this bay when the drive is not attached to your NEC Versa.
- Status LED — Lights to indicate drive activity.
- Emergency Eject Hole — Insert a paper clip to manually eject a CD when the eject function is disabled by software or a power failure.
- Eject Button — Press this button to eject/remove a CD from the drive.

Hard Disk Drive

Your NEC Versa FXi comes equipped with an internal fixed 2.5-inch, 9.5mm hard disk drive with a capacity of either 6.x, or 12.x GB, depending on your system configuration.

When you power on your system for the first time, the hard disk drive contains the Windows operating system and some resident drivers and utilities. Use the Application and Driver CD to install your choice of additional drivers, utilities, third-party software applications, internet browsers, and the NEC Info Center, to maximize your notebook experience.

If for some reason, your hard disk drive becomes unreadable, use the Product Recovery CD to restore your system to its initial installation state. For details about using the Product Recovery CD, see Chapter 4, “Using the Operating System and Utilities.”

Memory Modules

Your NEC Versa FXi computer comes standard with 64 megabytes (MB) of random access memory (RAM). You can increase system memory to a maximum of 192 MB, depending upon which SO-DIMM you purchase for upgrade.

- 64-MB memory module
- 128-MB memory module.



CAUTION Only install NECC supplied/approved memory module options to ensure proper functionality of your NEC Versa notebook computer.

Contact your NECC dealer for information about available NEC-supplied/approved memory modules.




CAUTION Before handling any internal components, discharge static electricity from yourself and your clothing by touching a nearby metal surface.

Follow these steps to install a memory module.

1. Make sure that the system is powered off and that no peripheral devices are attached.
2. Turn over the system and locate the memory module bay.

Locating the memory module bay




A – Memory Module Bay Cover

B – Screw


3. Remove the screw and bay cover.

Removing the screw and bay cover



4. Locate the connectors and alignment key on the SO-DIMM.

SO-DIMM features



A – Connectors

B – Alignment Key

-
5. Locate the SO-DIMM expansion port and proceed as follows:
 - Hold the SO-DIMM at a 45 degree angle and align the SO-DIMM contacts with the socket in the system. Push the connector into the socket.
 - Press down on the edge of the SO-DIMM opposite the contacts until the lock tabs on the sides snap into place, securing the module.

Installing the SO-DIMM



If you are replacing a SO-DIMM and need to remove one that is already installed, do so as follows:

- Press the locking tabs away from the sides of the SO-DIMM and hold while gently lifting on the edge of the SO-DIMM.
- When the edge of the SO-DIMM pops up and is at approximately a 60 degree angle, pull the SO-DIMM from the socket.

Removing an installed SO-DIMM



Note The system switches are also located in the memory module bay. Therefore, if you need to set any system switches, you might want to do so while the system is already disassembled. The system switches are defined in Chapter 3.

6. Replace the memory module bay cover and screw.
7. Turn over the system and power on.

6

Communicating with Your NEC Versa

- PC Cards
- Mini-PCI LAN
- Internal Modem
- Internet Connections
- IR Port

PC Cards

Your NEC Versa FXi system is equipped with two PC card slots that support both Type II and Type III PC cards.

PC cards are all approximately the same size and vary only in thickness. All have a standard 68-pin connector. Your NEC Versa supports the installation of the PC cards described next.

Type II Cards

Type II cards have a thickness of 5.0 millimeters (mm). Type II cards are often storage or communication devices such as Static Random Access Memory (SRAM), Read Only Memory (ROM), Flash Memory, LAN, and Small Computer System Interface (SCSI). Typically Type II cards include input/output (I/O) features such as modems.

Type II Extended Cards

Many PC cards are Type II extended cards. The extended card has an additional physical component that protrudes beyond the traditional card size. The extension can be as large as 40 mm deep by 9.65 mm high. This extension provides room for additional electronics as well as a location for external connectors.

Type III Cards

Type III cards are thicker (10.5 mm) than Type II cards. Type III card uses include advanced function I/O cards with additional features such as wireless modems, multimode cards (cards with more than one function such as a combined LAN/modem card), and small hard drive storage.

Communication Cards

You can use both fax/modem and network PC cards with your NEC Versa. Here are some suggestions to help you get the best system performance.

Note If you are using this unit outside of the United States or Canada, contact a local NECC dealer for availability information.

- Network Cards — You can use a network card with your system to gain access to a local area network (LAN).

You can insert a network card in either slot.

-
- Fax/Modem Cards — You can use a PC card modem with your system to communicate with others via fax, email, or connect to an online service or bulletin board.

You can insert a fax/modem card in either slot.

Note Before using a PC card modem, use the BIOS Setup Utility to disable the internal modem. Find the internal modem setting in the Peripheral Setup section of the utility. See Chapter 3, “Using the BIOS Setup,” for details about disabling the internal modem.

Always insert the fax/modem card before using your fax/modem software application. If you start the application before inserting the fax/modem card, the application typically does not find the card.

Storage Cards

When you insert a memory or storage card in an NEC notebook computer, it appears as a unique drive as long as the system has an available interrupt for the card.

Other Cards

Many other kinds of PC cards are available for notebook computers. They include the following cards:

- Global Positioning System (GPS) — enables the tracking of remote units (for example, delivery trucks)
- Serial — adds an extra serial communications port
- Multimedia — combines animation and sound

PC Card Slots

Your NEC Versa FXi notebook integrates two CardBus slots for inserting two Type II PC cards or one Type III PC card. The 32-bit CardBus also has zoomed video support in the bottom slot (slot 1).

Note The 32-bit CardBus structure is backward compatible, but also accepts new CardBus cards.

Using the system's PC card slots, you can add optional PC cards and connect external devices to your NEC Versa. These devices include peripheral devices, such as modems, LAN cards, and storage cards.

Inserting a PC Card

To insert a PC card, follow these steps.

1. Align the card so that the 68-pin connector points towards the slot and the arrow shows on the top face of the card.
2. Slide the card into either slot. (Install Type III cards in the bottom slot, only.) A low tone followed by a high tone lets you know that the card is fully inserted and recognized. (If you turn off the sound through the function keys or volume control, no sound is emitted.)

Other tone sequences such as high, then low tones, indicate that the card is inserted, but the card type is unknown.

Inserting a PC Card



3. Use the software preinstalled on your system to check PC card slot availability. Look for the PC Card icon in the Control Panel or on the right side of the taskbar. It shows which slot contains a PC card and which is empty.

Removing a PC Card

Follow these steps to remove a PC card.

1. Double click the PC card icon on the taskbar.
2. Select the PC card to remove, and select Stop.

The Windows operating system alerts you if any applications are still using the card. If all applications using the card are closed, services for that card are shut down. You receive a message saying that it is safe to remove the card.

3. Press the button on the side of the PC card in the slot.

Mini-PCI LAN


Your NEC Versa FXi system may ship with an internal mini-PCI LAN that allows you to connect your system to a local area network. The internal LAN is a 10/100Base-TX interface that supports both Wake on LAN and Network Boot functions.

Connecting the Mini-PCI LAN

The mini-PCI LAN ships with a LAN adapter cable that is designed with a LAN port connector and an RJ-45 connector. Follow these steps to take advantage of the internal mini-PCI LAN.

1. Locate the LAN port jack on the left side of the system and open the port cover.
2. Connect the LAN port connector to the LAN port jack.
3. Connect the RJ-45 connector at the other end of the LAN adapter cable to an RJ-45 cable.

Connecting the Mini-PCI LAN



A – LAN Cable Jack

B – LAN Adapter Cable Connector

C – RJ-45 Connector

D – LAN (RJ-45) Cable

4. Connect the RJ-45 cable to a local area network.

Internal Modem

Your NEC Versa FXi system ships with a V.90/K56flex™ internal modem that allows you to connect to the Internet, send a fax, or access your email.

Note When using a modem outside the U.S. and Canada, you might need an international telephone adapter, available at most electronics supply stores.


! WARNING Use only a 26AWG phone line cord when connecting the internal modem.

Connecting the Internal Modem

Follow these steps to connect an RJ-11 telephone cable to the internal modem.

1. Locate the RJ-11 telephone cable that ships with your NEC Versa. Each end of the cable has an RJ-11 connector that plugs into a standard telephone outlet.
2. Locate the RJ-11 port on the left side of your system and open the cover.
3. Carefully plug the RJ-11 telephone cable into the RJ-11 port.

Connecting the RJ-11 telephone cable



4. Connect the other end of the RJ-11 telephone cable into an (analog) phone jack.

Now you are ready to configure your modem for internet or email access!

Installing the Online Modem Guide

For additional information about your modem's AT commands and s-registers, use the A&D CD to install the online modem guide for your system. To determine the guide that is appropriate for your system, go to Start, Settings, Control Panel, System, and select the Device Manager tab. Double click Modem to identify the name of your system's modem. Use the A&D CD to install the online modem guide of the same name to your NEC Versa hard drive.

Internet Connections

Your NEC Versa FXi system is equipped with the Windows operating system to provide a fully-integrated internet experience. Use the Internet Connection Wizard on your desktop to configure your system for email and internet access. Sign up for a new account or configure your system to use an existing account. The Internet Connection Wizard offers the following choices:

- Sign-up for a new internet account. Take advantage of the Microsoft Internet Referral Service.
- Transfer an existing internet account.
- Manually configure an internet account or connect through a local area network (LAN).


Before using the Internet Connection wizard to transfer an existing account for email and internet access, you need an internet service provider (ISP) account and some or all of the following configuration information:

- the dial-up telephone number
- TCP/IP settings
- port settings
- a user name/logon and password
- your email address
- the name of a POP3, IMAP, or HTTP server (for incoming mail)
- the name of an SMTP server (for outgoing mail)

Accessing the Internet

Your NEC Versa FXi system is equipped with an Internet shortcut key, located just above the keyboard. The first time that you press the Internet shortcut key, the Internet Connection Wizard launches, allowing you to configure your system for internet access. Once your internet connection is configured, pressing the Internet shortcut key launches your associated dial-up network connection, allowing you to enter your logon name and password. In addition, Microsoft Internet Explorer launches, providing quick access to your favorite internet sites.

Internet/email shortcut keys



A – Email Shortcut Key

B – Internet Shortcut Key

Sending and Receiving Email

Your NEC Versa FXi system is equipped with an Email shortcut key, located just above the keyboard. The first time that you press the Email shortcut key, the Internet Connection Wizard launches, allowing you to configure your system for email access. Once your internet connection is configured, pressing the Email shortcut key launches your associated dial-up network connection, allowing you to enter your logon name and password. In addition, Outlook Express launches, providing quick access to your email functions.

Modifying the Internet and Email Shortcut Keys

The Internet and Email shortcut keys are configured (default setting) to launch your Internet browser and email applications, respectively. To modify the default application settings, you must edit the NECMFK.INI file on your hard drive.

Follow these instructions to modify the NECMFK.INI file.

1. Use Windows Explorer to locate the file, C:\Windows\NECMFK.INI.
2. Double click the NECMFK.INI file to open it.
3. Use the scroll bar to locate the sections at the end of the file designated as Btn6 and Btn7.
4. To modify the application to launch when pressing the Email shortcut key, change the variable Btn6_API=msimn.exe to the *.exe of your choice. Be sure to use the full path name, for example, C:\Program Files\Netscape\Netscape.exe.

In addition, modify the variable Btn6_Name=Mail to an appropriate and corresponding identifier.

5. To modify the application to launch when pressing the Internet shortcut key, change the variable Btn7_API=iexplore.exe to the *.exe of your choice. Be sure to use the full path name, for example, C:\Program Files\Netscape\Netscape.exe.

In addition, modify the variable Btn7_Name=Internet to an appropriate and corresponding identifier.

6. Click File, Save, then File, Exit to save your changes and exit the editor.

You are now ready to use your shortcut keys to launch the applications of your choice.

IR Port

The IR (infrared communication) port on the front of your system lets your NEC Versa FXi computer communicate with other devices that also use infrared technology. The IR port is Infrared Data Association (IrDA) compatible. You can easily transfer files between your NEC Versa and an IR-equipped desktop, or print to an IR-equipped printer without using cables.

IR transfer speed ranges from 2.4 Kbit/sec to 4.0 Mbit/sec. You can choose the IR transfer speed through the Infrared icon on the taskbar or in the Windows Control Panel. Double click the icon and select the options tab to access the speed parameter.

Your NEC Versa transfers data at the speed compatible with the receiving device.



CAUTION Your NEC Versa ships with the IR port disabled. Before using the IR port for the first time, you must enable the device. See detailed instructions in the section that follows.

Enabling/Disabling the IR Port in Windows 2000

The IR port on your NEC Versa FXi ships set to Auto. An icon appears on the taskbar and provides access to the system's infrared utility. If for any reason you want to enable (or disable) the IR port to reassign system resources, refer to the following procedure.

Follows these steps to enable/disable the IR port in Windows 2000.

1. Go to Start, Setting, Control Panel, and double click the Wireless Link icon.
2. Select the Hardware tab and click the Properties button.
3. Select (or deselect) 'Use the device (enable)' in the device usage section of the window.
4. Click OK, then click OK again to close the Wireless Link window.

Enabling/Disabling the IR Port Windows 98

The IR port on your NEC Versa FXi ships set to Auto. An icon appears on the taskbar and provides access to the system's infrared utility. If for any reason you want to enable (or disable) the IR port to reassign system resources, refer to the following procedure.

Follow these steps to enable/disable the IR port in Windows 98.

1. Right click the infrared icon, choose Enable Infrared Communication, highlight Open to open the Infrared Monitor window, or go to Start, Settings, Control Panel, and double click the infrared icon.
2. Select the Options tab and place (or remove) a check in the box labeled "Enable infrared communication."
3. Click Apply, then click OK to close the Infrared Monitor window.

Using the IR Port

Follow these guidelines when using the IR port to communicate with another infrared device.

- Position the NEC Versa FXi no more than three feet away from the IR peripheral device you are using.
- Make sure that there is no greater than a 30° angle between the computer and the device.

7

Traveling Tips

- Preparing for Travel
- Packing for Travel
- Using Power Connections
- Getting Through Customs
- Using Your Modem

Preparing for Travel

The NEC Versa FXi computer makes a natural traveling companion. With a little preparation you can use the computer anywhere you go, to prepare your business documents, confirm your travel plans, surf the Internet, or simply stay in touch with those back home!

Here is what you should do before you leave home:

Note Speed the trip through airport security by carrying a charged system. Inspectors may want to see the screen display a message. The boot message is usually sufficient.

If your system is fully charged, the inspection only takes a minute or so. Otherwise, be prepared to attach the AC adapter and power cable. And if you don't have these, the inspection might include a disassembly of the system.

- Back up your NEC Versa's hard disk.
- Insert a fully charged battery to make sure your system is ready to quickly boot up at the airport security check.
- Fully charge all your batteries.
- Tape your business card to your NEC Versa, AC adapter, and batteries.
- If you run your system with battery power, maximize battery life by using power-saving features whenever possible.
- Take along any application or data files on diskette that you might need.
- Check that you have everything you need before you leave on a trip.
- Carry the AT&T's Worldwide Calling Guide. (For more information, see the section later in this chapter, "Using Your Modem.")

Packing for Travel

The following are what you should take with you when you travel with your NEC Versa.

- Extra fully charged batteries
- Single-outlet surge protector
- Appropriate AC plug adapter for international voltage requirements
- Extra phone cord to access hard to reach wall jacks

-
- Copy of proof of purchase for your computer and other equipment or customs registration form for customs check
 - Customer support phone numbers for your software (domestic and international)
 - *NEC Versa Quick Reference* card
 - AC extension cord.

Using Power Connections

With the right accessories, you can run your NEC Versa almost anywhere! Your system self-adjusts to various power sources. The United States, Canada, and most of Central and South America use 120-volt alternating current (AC). Most other countries of the world use 240-volt AC. The NEC Versa adapts to voltages ranging from 100 to 240 volts, 50 or 60-Hz.

There are a few countries with areas that use direct current (DC) as their main power source. You need a DC-to-AC converter in particular areas of Argentina, Brazil, India, Madeira, and South Africa.

To use your system overseas, you need an adapter plug. There are several different plugs available worldwide. You can buy these at an electronics supply store.

Getting Through Customs

With so many countries in the world, you can be sure that there are a variety of customs regulations. Plan wisely to get your NEC Versa notebook computer through customs by carrying the appropriate documentation to assure the customs agent that your system is not a recent purchase.

Travelers are often asked, when returning to their home country, whether or not they purchased the computer while outside of the country. Sometimes, the proof of purchase such as a bill of sale, insurance policy, or purchase receipt is sufficient. Taking along the purchase receipt for your notebook computer may sound practical, but may not always suffice, particularly when the purchaser of the computer is your company and the original receipt is not available to you.

Another alternative to a proof of purchase document is a Certificate of Registration, a document that is issued when you register your notebook computer with the Customs Service prior to departure. The certificate of registration contains a brief description of your computer and lists appropriate serial numbers for identification. The document is available from the customs web site at <http://www.customs.ustreas.gov/>.

To avoid hassle when moving your system through customs, you may want to obtain a certificate of registration and carry it, and your Versa notebook computer, wherever you may travel!

Using Your Modem

Whether you are on a business trip or vacation, connecting to the Internet while you travel can be expensive and frustrating unless you are prepared. Here are some tips on how to avoid frustration and expense while on the road.

1. Before leaving home, check with your Internet Service Provider to see if it has:
 - a local access number at your point of destination.
 - a toll-free number that can also save you money.

In the absence of a local ISP access number or toll-free number, charging the call to your home phone can be less expensive than charging the call to your hotel room.

2. Prepare your system for phone line access in another country.
 - Line access outside of a hotel may require the addition of a “9” preceding the phone number string. Be sure to modify your dial-up connection, as required.
 - To circumvent unusual dial tone sounds sometimes encountered in hotels, you may have to modify a modem configuration setting to ignore the dial tone. For details specific to your modem, refer to the AT command section of your modem user’s guide.
3. Always check the phone line to determine whether or not it is digital vs. analog. *NEVER* use your modem with a digital phone line. The internal modem in your NEC Versa system has built-in protection that detects the presence of a digital phone line and displays a warning message to alert you.
4. Use AT&T’s Worldwide Calling Guide, a resource that provides instructions for dealing with unfamiliar phone systems. For more information about the calling guide, access the web site at <http://www.att.com/traveler/>.

8

Using Peripheral Devices

- External Monitor
- Parallel Devices
- External Audio Options
- USB Devices


External Monitor

You can add a standard external monitor to your NEC Versa FXi system using a display signal cable (usually provided with the monitor). One end of the cable must have a 15-pin connector for the system.

Follow these steps to connect an external monitor to your NEC Versa.

1. Check that power to both the NEC Versa and the monitor is off.
2. Open the monitor port cover at the far left on the back of the system.
3. Attach the 15-pin cable connector to the monitor port on the system. Secure the cable connection with the screws provided.

Connecting a monitor



4. Connect the monitor power cable and plug it into a properly grounded wall outlet.
5. Follow any setup instructions in the monitor's user's guide.
6. Turn on power to the system and device.
7. Press **Fn-F3** to toggle through the video modes.

Parallel Devices


You can attach a parallel device to the FDD/Parallel port on the left side of your NEC Versa FXi system. To install a parallel device you need the cable with a female 25-pin connector that ships with your system and, for most parallel printers, a Centronics®-compatible 36-pin connector.

Note When you connect a printer, be sure to install the appropriate printer driver through the Windows Control Panel.

Connect a parallel device to your NEC Versa as follows.

1. Check that power to both the NEC Versa and the device is off.
2. Open the FDD/Parallel port cover on the left side of the system and locate the FDD/Parallel port.
3. Align and connect the 25-pin parallel cable (small end) connector to the port on the system and lock the connector clips.
4. Align and connect the other end of the cable to the parallel port on the device. Lock the connector clips.

Connecting a parallel device



A – FDD/Parallel Port

B – Parallel Connector Cable

5. Connect the power cable to the device and a properly grounded wall outlet.
6. Turn on power to the system and the device.

Note Check that the device is online before you try to use it. See the instructions that came with the device for more information.

Disconnecting a Parallel Device

When disconnecting the Parallel cable, squeeze the release clips before pulling the cable away from the system port or the parallel device.

 **CAUTION** Failure to squeeze the release clips may result in damage to the cable connectors.


External Audio Options

The NEC Versa comes equipped with built-in audio ports that let you record and play sound.

Connect audio jacks, like a microphone, headphones, or external speakers to the audio ports as follows.

1. Locate the audio port that you want to use.
2. Plug the jack into the appropriate port on the front of the NEC Versa.

Audio ports



A – Headphone Jack

B – External Microphone Jack

Note If you are using external speakers or an external microphone and experience sound distortion or feedback, use the **Fn-F11** key to lower the volume.

Some feedback is caused by having the microphone and speakers too close to each other, so moving the external audio option away from the unit may also help.

USB Devices

Your NEC Versa FXi system is equipped with three USB ports that increase your connectivity choices. The USB ports on the right side of your system allow you to connect up to 127 USB-equipped peripheral devices to your NEC Versa notebook computer. These peripherals may include a digital camera, scanner, printer, CD-ROM drive, modem, mouse, keyboard, telephone, or game device.


USB devices called USB hubs can serve as connection ports for other USB peripherals. Only one device needs to be plugged into your NEC Versa. Additional peripherals can be connected in a daisy chain configuration where one device is connected to another in a series. Up to 127 devices can be connected together in this way.

CAUTION Connecting USB devices to your system may reduce battery life. Always connect your system to an AC power source before connecting USB devices.

Connect an external USB device to your system as follows.

1. Locate any of the USB port covers on the right side of your system and open the cover door(s).
2. Plug in up to three USB devices to optimize your notebook possibilities.

Connecting USB devices



9

Using Multimedia

- Audio
- Video
- Multimedia Applications

Audio

The NEC Versa provides entertainment-level sound quality through internal stereo speakers. It handles MIDI files and digital audio files recognizing .WAV, .MID, and .AVI formats. The system is 3D-stereo, Sound Blaster PRO™ compatible.

Recording

All information on a computer must be stored in digital form. Analog audio signals from sources such as tape cassettes or music CDs must be digitized before being recorded and stored on disk.

You can make microphone level recordings on your NEC Versa FXi computer using the internal microphone or an external microphone plugged into the microphone jack on the front of the system.

Note When using the built-in microphone, make sure the speaker volume is turned down before using the microphone or feedback may occur.

The following procedure describes how to record using the Microsoft® Sound Recorder and an external microphone plugged into the NEC Versa.

1. To record using an external microphone, attach an external microphone to the microphone port on the front of the system.
2. Go to Start, Programs, Accessories, Entertainment, and select Sound Recorder.
3. Specify the default sound quality before you record.
 - Select Audio Properties from the Sound recorder edit menu.
 - Use the Effects menu to adjust recording volume, device, and quality settings.
4. Select File, New from the Sound Recorder menu bar.
5. Click the Record button (solid round dot) to begin recording.
6. Click the Stop button (solid rectangle) to stop recording.
7. Select File, Save As from the Sound Recorder menu bar.
8. Name and save your file.

You can play your recording in Sound Recorder or in Windows Media Player. See the section, “Playing Back,” later in this chapter.

Note Before recording from the external CD-ROM drive to the internal hard disk drive, disable the internal microphone. To disable the internal microphone, go to Start, Programs, Accessories, Entertainment, Volume Control. Choose Options, Properties and remove the check from the Microphone box in the 'Show the following controls' window.

Microphone

You can capture and record sounds through the internal microphone on the NEC Versa or through an external microphone that connects to the system through the microphone port. You can record voice-overs for narration, reminders, or special instructions. See "Recording," explained earlier in this chapter, for details about recording sound with the microphone.

Mixing

With the Microsoft Sound Recorder on your NEC Versa, you can mix data from two separate wave files to create a new sound file. You can also mix the microphone volume to create soft background sounds to accompany a voice-over or another more prominent sound. Mixing lets you blend digital and MIDI audio files to get the final, high-quality soundtrack you want.

See the online help that is available with the Sound Recorder for more information.

Playing Back

You can play back your recorded soundtrack through stereo headphones, the internal NEC Versa stereo speakers, or external stereo speakers. You can play .wav and .mid files as well as CD audio. Adjust the volume through the software or with the **Fn-F10/Fn-F11** function keys.

Play audio from files or audio devices as follows. (This example shows how to use the Windows Media player option in Accessories. You can also play audio through the Sound Recorder. See the Sound Recorder help files for details on its use.)

1. Go to Start, Programs, Accessories, Entertainment, and select the Windows Media Player option.
2. Click File and specify the file name of your audio source.
3. Once your file is open or your source specified, click the Play button.
4. Click the square Stop button to stop playing the audio.

Using Headphones

The NEC Versa headphone port delivers sound at half a watt. Stereo headphones (available at an electronics supply store) plug in through the headphone jack located on the front of the NEC Versa. Adjust the volume using the **Fn-F10/Fn-F11** function keys or through the software using the sound horn on the taskbar.

Using the Built-In Speakers

The NEC Versa has built-in stereo speakers that are always available. Adjust the volume using the **Fn-F10/Fn-F11** function keys or through the software using the sound horn on the taskbar.

Using External Stereo Speakers

For full stereo sound impact, you can plug a pair of stereo speakers into the headphone jack located on the front of the system. Adjust the volume using the **Fn-F10/Fn-F11** function keys or through the software using the sound horn on the taskbar.

MIDI Files

The musical instrument digital interface (MIDI) lets you enhance a presentation by adding computer-generated music and sound effects. Using MIDI, you can purchase a wide range of public domain and commercial recordings in MIDI format.

MIDI files require only a fraction of the storage space of digital audio files.

Video

The NEC Versa FXi computer features a dazzling TFT, 16 million color, high-resolution display for sharp, effective visuals on the NEC Versa or on an external CRT monitor. The NEC Versa XGA or SVGA TFT display panels have a high resolution capability of 800 x 600 pixels.

Use the Windows Media player on your NEC Versa to run full motion, full-screen MPEG video. For details about using the Windows Media Player, refer to the section earlier in this chapter, "Playing Back."

Using Digital Video Files

With commercial video capture hardware and application software, you can plug any video device, including VCRs, camcorders, and laser disc players into your NEC Versa and record motion graphics to your hard drive. Use the system's FDD/Parallel port or PC card slots (depending on the video capture hardware and software that you purchase separately) to plug in the external video device. You can even use a video frame grabber and store a stream of grabbed stills on your hard disk!

Using Animation Files

You can create a dynamic presentation using an animation application. Animation can illustrate a concept, drive home an important point, or command attention. Graphics animation can add punch to a presentation with an animated illustration, a flashing arrow, or a flying logo.

Multimedia Applications

A growing number of multimedia applications are available for PC users. These multimedia software packages include graphics packages, animation software, and presentation authoring systems as follows:

- Animation software allows you to create 3-D effects and 3-D titles and add interest to an otherwise static presentation.
- Authoring packages let you pull all the elements of your design into an exciting, interactive multimedia presentation.

10

Solving System Problems

- Problem Checklist
- Start-Up Problems
- If You Need Assistance

Problem Checklist

First check the items in the following list. If these items don't help, see the table that follows the list.

- Power is on to the computer.
- The electrical outlet to which your AC adapter is connected is working. Test the outlet by plugging in a lamp or other electrical device.
- All cables are tightly connected.
- The display setting is configured correctly.
- The display brightness control is adjusted properly.
- If using battery power, check that the battery pack is properly inserted and fully charged.

Troubleshooting

| Problem | Resolution |
|---|--|
| The system does not power on. | <p>If you are operating the system with battery power, check that the battery pack is correctly inserted. Attach the AC adapter to recharge the battery.</p> <p>If you have the AC adapter attached, check that you are using a working electrical outlet.</p> |
| LCD screen is dark and blank. | <p>Power-saving mode has shut off the backlight. Press a keyboard key or move the mouse.</p> <p>The built-in LCD may not be selected. Press Fn-F3 once or twice to select the LCD video mode.</p> <p>Screen brightness needs adjustment. Use the Fn-F8 and Fn-F9 functions keys.</p> <p>The system entered Standby mode due to low battery power. Use the power meter to check battery status. Plug in the AC adapter or replace the battery pack, and then press the Power button to resume operation.</p> |
| Battery power does not last long. | <p>Use power-saving modes.</p> <p>Fully charge and discharge the battery several times to recondition it.</p> <p>Replace the battery.</p> |
| Information on the LCD is difficult to see. | <p>Use the Fn-F8 and Fn-F9 functions keys to adjust the brightness control.</p> |

Troubleshooting

| Problem | Resolution |
|---|--|
| An optional component does not work. | Make sure the component is securely installed or connected. Verify that the system parameter for the I/O port configuration is set correctly in Setup. |
| The Power button does not resume the system from Standby mode. | If system does not resume, it may have auto suspended (Standby) on a low battery. Attach the AC adapter and try again. Check that the "System Switch" BIOS parameter is set to "Sleep." |
| The system does not auto-suspend (Standby). | A disk drive might be busy. Wait until the disk drive stops and try again. Check that Auto Play is disabled. |
| Upon resuming from a manual STF the system displays the message, "Following system component(s) changed since last suspend – System Memory. Do you want to (B)oot or (P)ower down?" | Power down the system and reseal the memory. If new memory was installed prior to manual STF, remove new memory before resuming. |

Start-Up Problems

The system displays an invalid configuration error message at power on when there are the following conditions:

- the current configuration information does not match configuration information stored in Auto Setup, such as when an internal option is added.
- the system loses configuration information.

If either condition is true, the system displays an "invalid configuration information" message.

To continue start-up procedures, press **F2** (or **F1** when prompted) and run the Setup utility to set current system parameters.

Note When the NEC Versa detects an error related to display devices, it cannot display on either the LCD or a CRT. The system warns you by beeping.

Post Error Messages

The NEC Versa FXi computer has a built-in checking program that automatically tests its components when you turn the system power on. This diagnostic test is called the Power-On Self-Test (POST). If the system finds a problem during the POST, the system displays an error message or emits a series of beep signals. If this happens, follow the instructions in the POST Error Messages table or the Beep Code table, as appropriate.

If an error message appears before the operating system starts, look up the error message in the following table. Follow the instructions. If you see other error messages, the hardware might need repair.

Post Error Messages

| Message | Resolution |
|---------------------------------------|--|
| Address line is short | Error in the address decoding circuitry on the system board. Contact your NECC service representative for service. |
| C: Drive Error | Hard disk drive C: does not respond. Confirm that C: hard disk type in Setup is correct. |
| C:Drive Failure | Hard disk drive C: does not respond. You may need to replace the hard disk drive. Contact your NECC service representative for service. |
| Cache Memory Bad, Do Not Enable Cache | Cache memory is defective. It must be replaced. Contact your NECC service representative for service. |
| CH-2 Timer Error | Most ISA computers include two timers. There is an error in timer 2. Contact your NECC service representative for service. |
| CMOS Battery State Low | CMOS RAM is powered by a battery. The battery power is low. Connect the system to AC power to charge the CMOS battery. If the battery does not charge, contact your NECC service representative to replace the CMOS battery. |
| CMOS Checksum Failure | After CMOS RAM values are saved, a checksum value is generated for error checking. The previous value is different from the current value. Run Setup to reset the value. |
| CMOS System Options Not Set | The values stored in CMOS RAM are either corrupt or nonexistent. Run Setup to reset the value. |

Post Error Messages

| Message | Resolution |
|---------------------------------|---|
| CMOS Display Type Mismatch | The amount of memory on the system board is different than the amount in CMOS RAM. Run Setup to reset the value. |
| CMOS Time and Date Not Set | Run Setup to set the time and date. |
| Diskette Boot Failure | The boot diskette is corrupt. It cannot be used to boot the computer. Use another boot disk and follow the on-screen instructions. |
| DMA Error | Error in the DMA controller. Contact your NECC service representative to replace the CMOS battery. |
| DMA#1 Error | Error in the first DMA channel. Contact your NECC service representative for service. |
| DMA#2 Error | Error in the second DMA channel. Contact your NECC service representative for service. |
| FDD Controller Failure | The BIOS cannot communicate with the floppy disk controller. Contact your NECC service representative to check all appropriate connections. |
| HDD Controller Failure | The BIOS cannot communicate with the hard disk drive controller. Contact your NECC service representative to check all appropriate connections. |
| INTR #1 Error | Interrupt channel 1 failed POST. Contact your NECC service representative for service. |
| INTR #2 Error | Interrupt channel 2 failed POST. Contact your NECC service representative for service. |
| Invalid Boot Diskette | The BIOS can read the diskette in the disk drive, but cannot boot the computer. Use another boot diskette. |
| Keyboard is Locked Unlock It | The keyboard lock on the computer is engaged. The computer must be unlocked to continue. |
| Keyboard Error | There is a timing problem with the keyboard. Set the Keyboard option in Setup to Not Installed to skip the keyboard POST routines. |
| KB/interface Error | There is an error in the keyboard connector. Contact your NECC representative for service. |

Post Error Messages

| Message | Resolution |
|------------------------|--|
| Off Board Parity Error | Parity error in an expansion slot. Contact your NECC service representative to be sure that the memory module is installed correctly. The error format is: OFF BOARD PARITY ERROR ADDR(HEX) = (XXXX) XXXX is the hex address where the error occurred. |
| On Board Parity Error | Parity error in system board memory. Contact your NECC service representative for service. |
| Parity Error ???? | Parity error in system memory at an unknown address. Contact your NECC service representative for service. |

Beep Codes

Fatal errors that occur during POST are communicated through a series of beeps. All beep code errors, except beep code 8, are fatal errors and do not allow the system to continue to boot.

If beep codes occur during POST, check the items in the Problem Checklist (at the start of this chapter), verify that all the hardware is set up properly and securely connected, and try rebooting. If you still get a beep code, go to the section “If You Need Assistance” at the end of this chapter.

Beep Codes are listed in the table that follows.

Beep Codes

| Number of Beeps | Error | Description |
|------------------------|---------------------------|---|
| 1 | Refresh Failure | The memory refresh circuitry on the motherboard is faulty. |
| 2 | Parity Error | Parity error in the first 64 KB of memory. |
| 3 | Base 64 KB Memory Failure | Memory failure in the first 64 KB. |
| 4 | Timer Not Operational | Memory failure in the first 64 KB of memory or Timer 1 on the motherboard is not functioning. |

Beep Codes

| Number of Beeps | Error | Description |
|------------------------|---|--|
| 5 | Processor Failure | The CPU on the motherboard generated an error. |
| 6 | Gate A20 Failure | The keyboard controller may be bad. The BIOS cannot switch to protected mode. |
| 7 | Processor Exception Interrupt Error | The CPU generated an exception interrupt. |
| 8 | Display Memory Read/Write Error | The system video adapter is either missing or its memory is faulty. (This is not a fatal error.) |
| 9 | ROM Checksum Error | The ROM checksum value does not match the value encoded in the BIOS. |
| 10 | CMOS Shutdown Register Read/Write Error | The shutdown register for CMOS RAM failed. |
| 11 | Cache Error/External Cache Bad | The external cache is faulty. |

If You Need Assistance

If you have a problem with your computer, first review the checklist and troubleshooting table at the beginning of this chapter.

If you still have a problem, see Chapter 11, “Getting Service and Support,” for details about contacting NECC.

Note If you purchased and are using this product outside the U.S. or Canada, please contact the local NECC office or their dealers for the support and service available in your country.

Getting Service and Support

- Service and Support Contact Information
- NECC Web Site
- NECC FTP Site
- NECC Support Services
- Email/Fax to Support Services

Service and Support Contact Information

| Service | Contact Information |
|--|--|
| NECC Web and FTP Sites | Web address: www.nec-computers.com FTP site: ftp.neccsdeast.com |
| NECC Support Services (U.S. and Canada customers only) | 800-632-4525 Fax: 801-981-3133 |
| Email to NECC Support Services through a commercial online service or the Internet | Internet email address: tech-support@nec-computers.com |

Note If you purchased your computer outside of the U.S. or Canada, please contact the local NECC office or their dealers for support and service.

If you have access to a telephone, modem, and/or fax machine, you can use these services to obtain information about your system at any time, day or night, seven days a week.

Not only do these services provide information about your NEC system, they can also be used to answer your questions and help solve any problems you may have with your system, should that ever be necessary.

NECC Web Site

If you have a modem or are connected to a network with internet access, you can access the NECC Web site. You can do this through a commercial online service or through your Internet account. The NECC web site contains general information about NECC and its products, an online store, press releases, reviews, and service and support information.

Look in the Service and Support area for the following:

- technical documentation, including Frequently Asked Questions, reference manuals, and warranty information
- BIOS updates, drivers, and Setup Disk files to download
- contact information, including telephone numbers for Technical Support and links to vendor Web sites
- Click, the NECC Customer Service newsletter
- an automated email form for your technical support questions
- a Reseller's area (password accessible).

To access NECC's Home Page, enter the following Internet Uniform Resource Locator (URL) in your browser:

<http://www.nec-computers.com/>

NECC FTP Site

Use the Internet to access the NECC FTP (file transfer protocol) site to download various files (video drivers, BIOS updates, and Setup Disk files). The files are essentially the same files as on the NECC Web site and the NECC Bulletin Board System.

To access the NECC FTP site, enter the following Internet ftp address through your service:

<ftp.neccsdeast.com/>

Once in the FTP site, select the pubs directory link and follow the links to choose and download the file(s) you want.

NECC Support Services

NECC also offers direct technical support through Support Services. (NECC Support Services is for U.S. and Canadian customers only; international customers should contact the local NEC office or dealer for the support and service available in your country.)

Direct assistance is available 24 hours a day, 7 days a week. Call the NECC Support Services, toll free, at **1-800-632-4525** (U.S. and Canada only) for the following support.

- System hardware — toll-free phone support is limited to the length of the standard warranty.

For hardware support after the standard warranty, get system hardware support for a fee.

- Preinstalled software — toll-free phone support for 90 days from the time of your first call to the NECC Support Services.

After the initial 90 days, get preinstalled software support for a fee.

Please have available your system's name, model number, serial number, and as much information as possible about your system's problem before calling.

For outside the U.S. or Canada, please contact your local NEC office or dealer for the support and service available in your country.

Email/Fax to Support Services

The NECC Support Services offers technical support by email over the Internet network if you have a modem. The Internet address is:

tech-support@nec-computers.com


You can also fax technical questions to the NECC Support Services if you have access to a fax machine or fax/modem. The fax number is:

801-981-3133

When using the email or fax support service, you should include the following words in the subject field for prompt response from the appropriate technical person:

- Desktop
- Monitor
- Notebook.

You should provide as much specific information about your questions as possible. Also, if you are sending a fax, please include your voice telephone number, fax number, model number and system serial number with the question. You will receive a response to your questions within one business day.



Setting Up a Healthy Work Environment

- Making Your Computer Work for You
- Arrange Your Equipment
- Adjust Your Chair
- Adjust Your Input Devices
- Adjust Your Screen or Monitor
- Vary Your Workday
- Pre-Existing Conditions and Psychosocial Factors

Making Your Computer Work for You

Computers are everywhere. More and more people sit at computers for longer periods of time. This appendix explains how to set up your computer to fit your physical needs. This information is based on ergonomics - the science of making the workplace fit the needs of the worker.

Some nerve, tendon, and muscle disorders (musculoskeletal disorders) may be associated with repetitive activities, improper work environments, and incorrect work habits. Examples of musculoskeletal disorders that may be associated with certain forms of repetitive activities include: carpal tunnel syndrome, tendinitis, tenosynovitis, de Quervain's tenosynovitis, and trigger finger, as well as other nerve, tendon, and muscle disorders.



WARNING Prolonged or improper use of a computer workstation may pose a risk of serious injury. To reduce your risk of injury, set up and use your computer in the manner described in this appendix.

Although some studies have shown an association between increasing hours of keyboard use and the development of some musculoskeletal disorders, it is still unclear whether working at a computer causes such disorders. Some doctors believe that using the keyboard and mouse may aggravate existing musculoskeletal disorders.

Note Contact a doctor if you experience pain, tenderness, swelling, burning, cramping, stiffness, throbbing, weakness, soreness, tingling and/or numbness in the hands, wrists, arms, shoulders, neck, back, and/or legs.

Some people are more susceptible to developing these disorders due to pre-existing conditions or psychosocial factors (see “Pre-existing Conditions and Psychosocial Factors” later in the appendix).

To reduce your risk of developing these disorders, follow the instructions in this appendix. If you experience discomfort while working at your computer or afterwards, even at night, contact a doctor as soon as possible. Signs of discomfort might include pain, tenderness, swelling, burning, cramping, stiffness, throbbing, weakness, soreness, tingling and/or numbness in the hands, wrists, arms, shoulders, neck, back, and/or legs.

Note To increase your comfort and safety when using your notebook computer as your primary computer system at your home or office, note the following recommendations:

- use a separate, external keyboard attached to your notebook computer
 - use a separate, external monitor attached to your notebook computer.
-

Arrange Your Equipment

Arrange your equipment so that you can work in a natural and relaxed position. Place items that you use frequently within easy reach. Adjust your workstation setup to the proper height (as described in this appendix) by lowering the table or stand that holds your computer equipment or raising the seat height of your chair. Position your notebook computer directly in front of you for increased safety and comfort.

Adjust Your Chair

Your chair should be adjustable and stable. Vary your posture throughout the day.

Check the following:

- Keep your body in a relaxed yet upright position. The backrest of your chair should support the inward curve of your back.
- Use the entire seat and backrest to support your body. Tilt the backrest slightly (90° to 105°). The angle formed by your thighs and back should be 90° or more.
- Your seat depth should allow your lower back to comfortably contact the backrest. Make sure that the backs of your lower legs do not press against the front of the chair.
- Extend your lower legs slightly so that the angle between your thighs and lower legs is 90° or more.
- Place your feet flat on the floor. Only use a footrest when attempts to adjust your chair and workstation fail to keep your feet flat.
- Be sure that you have adequate clearance between the top of your thighs and the underside of your workstation.
- Use armrests or forearm supports to support your forearms. If adjustable, the armrests or forearm supports should initially be lowered while all the other adjustments discussed in this appendix are made. Once all these adjustments are completed, raise the armrests or adjust the forearm supports until they touch the forearms and allow the shoulder muscles to relax.

Adjust Your Input Devices

Note the following points when positioning your notebook computer or any external input devices.

- Position your keyboard directly in front of you. Avoid reaching when using your keyboard or mouse.

-
- If you use a mouse, position it at the same height as the keyboard and next to the keyboard. Keep your wrists straight and use your entire arm when moving a mouse. Do not grasp the mouse tightly. Grasp the mouse lightly and loosely.
 - Adjust the keyboard height so that your elbows are near your body and your forearms are parallel to the floor, with your forearms resting on either armrests or forearm supports, in the manner described previously. If you do not have armrests or forearm supports, your upper arms should hang comfortably at your sides.
 - Adjust the keyboard slope so that your wrists are straight while you are typing.
 - Type with your hands and wrists floating above the keyboard. Use a wrist pad only to rest your wrists between typing. Avoid resting your wrists on sharp edges.
 - Type with your wrists straight. Instead of twisting your wrists sideways to press hard-to-reach keys, move your whole arm. Keep from bending your wrists, hands, or fingers sideways.
 - Press the keys gently; do not bang them. Keep your shoulders, arms, hands, and fingers relaxed.

Adjust Your Screen or Monitor

Correct placement and adjustment of the screen or external monitor can reduce eye, shoulder, and neck fatigue. Check the following when you position the screen or external monitor.

- Adjust the height of your screen or external monitor so that the top of the screen is at or slightly below eye level. Your eyes should look slightly downward when viewing the middle of the screen or external monitor.
- Position your screen or external monitor no closer than 12 inches and no further away than 28 inches from your eyes. The optimal distance is between 14 and 18 inches.
- Rest your eyes periodically by focusing on an object at least 20 feet away. Blink often.
- Position the screen or external monitor at a 90° angle to windows and other light sources to minimize glare and reflections. Adjust the monitor tilt so that ceiling lights do not reflect on your screen or external monitor.
- If reflected light makes it hard for you to see your screen or external monitor, use an anti-glare filter.
- Clean your screen or external monitor regularly. Use a lint-free, non-abrasive cloth and a non-alcohol, neutral, non-abrasive cleaning solution or glass cleaner to minimize dust.

-
- Adjust the screen or external monitor's brightness and contrast controls to enhance readability.
 - Use a document holder placed close to the screen or external monitor.
 - Position whatever you are looking at most of the time (the screen or reference material) directly in front of you to minimize turning your head while you are typing.
 - Get regular eye check-ups.

Vary Your Workday

If you use your computer for prolonged periods, follow these instructions.

- Vary your tasks throughout the day.
- Take frequent short breaks that involve walking, standing, and stretching. During these breaks, stretch muscles and joints that were in one position for an extended period of time. Relax muscles and joints that were active.
- Use a timer or reminder software to remind you to take breaks.
- To enhance blood circulation, alter your sitting posture periodically and keep your hands and wrists warm.

Note For more information on workstation setup, see the American National Standard for Human Factors Engineering of Visual Display Terminal Workstations. ANSI/HFS Standard No. 100-1988. The Human Factors Society, Inc., P.O. Box 1369, Santa Monica, California 90406.


Pre-Existing Conditions and Psychosocial Factors

Pre-existing conditions that may cause or make some people more susceptible to musculoskeletal disorders include the following: hereditary factors, vascular disorders, obesity, nutritional deficiencies (e.g., Vitamin B deficiency), endocrine disorders (e.g., diabetes), hormonal imbalances, connective tissue disorders (e.g., arthritis), prior trauma (to the hands, wrists, arms, shoulders, neck, back, or legs), prior musculoskeletal disorders, aging, fluid retention due to pregnancy, poor physical conditioning and dietary habits, and other conditions.

Psychosocial factors associated with these disorders include: workplace stress, poor job satisfaction, lack of support by management, and/or lack of control over one's work.

Contact a doctor if you experience pain, tenderness, swelling, burning, cramping, stiffness, throbbing, weakness, soreness, tingling and/or numbness in the hands, wrists, arms, shoulders, neck, back, and/or legs.

This appendix was prepared in consultation with Dr. David Rempel of the University of California/San Francisco Ergonomics Program and Mr. M.F. Schneider of HUMANTECH, Inc., Ann Arbor, Michigan.



Specifications

- System Components
- Memory Map
- Interrupt Controllers

System Components

The following system component specifications are standard except where noted.

Note The components that ship with the system are subject to change without notice.

System Processor

600-MHz with SpeedStep, Pentium III microprocessor or 500-MHz Celeron processor

Architecture

64-bit Peripheral Component Interconnect (PCI)

Random Access Memory

- Standard Main Memory
 - 64-MB SDRAM SO-DIMM
- Optional Expansion — 1 slot
 - Expandable in 32-MB, 64-MB, or 128-MB increments
 - Maximum 192 MB
- Video Ram — 2 MB SGRAM
- Cache Memory
 - L1: KB code, 16KB data, 4 way set associate, write back (data)
 - L2: 128 K built-in (Celeron 333-MHz),
 - operates at full core speed
 - 4GB cacheable range

Read-Only Memory

512 KB x 8 bit, Flash ROM

Calendar Clock

Year/month/day/hour/minute/second maintained by internal back-up battery

Input/Output (I/O) Facilities

Integrated industry-standard interfaces

- FDD/Parallel — 1 port, 25-pin D-sub
 - FDD, PC8477 compatible, 16 byte FIFO, burst and non-burst modes
 - Parallel, IEEE 1284 compatible, ECP and EPP support
- CD/DVD (IDE) — 1 port, 50-pin
- Infrared — 1 port, IrDA-1 compatible
- VGA — 1 port, 15-pin high-density D-sub
- Microphone — 1 port, 3-pin, Mini Pin Jack
- Stereo Headphones — 1 port, 3-pin, Mini Pin Jack, .5 watts per channel
- DC In — 1 port, for AC adapter cable
- USB port — 3 ports, 4 pin
- Modem — 1 port, 4-pin, RJ-11 modular jack

Speakers

Two built-in, 1 watt (W) each with a maximum 3W output

- 16-bit stereo, 48 Khz
- Sound BlasterPRO compatible
- MIDI Roland: MPU401, UART Mode compatible
- EV 1983 SoundBlaster Audio PCI 64V or
ESS Solo1 PCI AudioDrive + ESS 1946S

PC Card Slots

- Two 32-bit card slots for two Type II PC cards or one Type III PC card, 5 V or 3.3 V interface
- 32-bit CardBus support

LCD Panel

The LCD panel varies, depending on the model.

- 12.1-inch or high resolution active matrix Thin Film Transistor (TFT), Extended Graphics Array (XGA) color display
 - Resolution — 800 x 600
 - Colors — 16 Million, max.
- 12.1-inch or high resolution active matrix Thin Film Transistor (TFT), Super Video Graphics Array (SVGA) color display
 - Resolution — 800 x 600
 - Colors — 16 Million, max.

Keyboard

Membrane 85 keys (both U.S. and International) with standard QWERTY-key layout (International keyboards are country-specific)

- Function keys — 12 keys
- Cursor Control keys — 8 keys; arrow keys arranged in inverted T layout
- Numeric keypad — embedded
- Fn key — function key for ROM-based key functions
- Stroke — 2.5mm
- Height — 6mm
- Pitch — 19mm

External Floppy Diskette Drive

- Size — 3.5-inch
- Capacity — 1.44 MB (formatted), 2 MB (unformatted)
- Transfer Rate — 250 to 500 K/bps
- Number of tracks — 160

Hard Disk Drive

Specifications vary depending upon model:

- Ultra DMA/66 support
- Capacity — Internal 6.x or 12.x GB

-
- Drive height — 9.5 mm
 - Read/write track-to-track seek rate — 3 ms
 - Average seek time — 12 ms – 14 ms
 - Revolutions per minute — 4200
 - Data transfer rate
 - 16.6 MB/sec (PIO mode4/DMA mode2)
 - 66.6 MB/sec (ultra DMA mode 4)

24X-speed CD-ROM Drive

- Type — 5-inch CD-ROM Pack
- Average Data Transfer Rates — 1545 KB/second to 3600 KB/second
- Burst Transfer Rate — 16.7 MB/second, PIO mode4/DMA mode
- Average Access Time
 - 190 ms (Random)
 - 350 ms (Fullstroke)
- Interface — IDE (ATAPI)
- Photo CD Compatibility — Single Session/Multisession Photo CD, Video CD (CD-1, CD-I Ready, CD-G, CD-Plus, CD-DA, CD-EXTRN, and CD-ROM XA mode 2)

CD Read/Write Drive

- Size — 149mm x 138mm x 18.2mm (DxWxH)
- Weight — 500g
- Buffer Size — 2MB
- Speed
 - CD-ROM Read — 3000KB/second, 20X maximum
 - CD-RW Read — 2100KB/second, 14X maximum
 - CD-RW Write — 600KB/second, 4X maximum

Mini-PCI LAN

- 10BASE-T and 100BASE-TX compatible
- IEEE 802.3 and IEEE 802.3u compliant
- 10/100 Mbps transmission rate
- 10/100M, LINK, and ACT diagnostic LEDs

56K Internal Modem

- V.90 data/V.17 fax soft, MMX optimized
- K56flex™ compatible
- SmartDAA™ technology
- V.80 synchronous access mode

Power

AC Adapter

- Input Voltage — 100 to 240 volts (V) AC, 50 or 60 Hz, Maximum 2.8A
- Output Voltage — 16.0 V DC, 45 Watt
- Australia, Europe and Asia use an AC power cable specific to each country's standards.

Battery Pack

- Type — three-cell Lithium Ion (Li-Ion)
- Optional Batteries — six-cell Li-Ion and nine-cell Li-Ion
- Output Voltage — 10.8 V
- Capacity — 1,550 mAH
- Recharging Time — Approximately 2.7 hours when the system is on or off.

Bridge Battery

When fully charged, backs up memory contents and system status, in Standby mode, giving you time to install a fully charged battery or connect to AC power when your battery charge becomes low.

Dimensions

- Width — 10.6 in. (269 mm)
- Depth — 8.8 in. (224.5 mm)
- Height — 0.9 in. (24.5 mm)

Weight

3.38 lb (1.54 kg) with the three-cell Lithium-Ion battery

Recommended Environment

Operation

- Temperature — 41°F to 95°F (5°C to 35°C)
- Relative Humidity — 20% to 80% (Noncondensing)

Storage

- Temperature — -4°F to 104°F (-20°C to 40°C)
- Relative Humidity — 20% to 80% (Noncondensing)

Memory Map

The system supports system and video shadowing, both controlled through complementary metal oxide semiconductor (CMOS). The system supports BIOS as a cacheable area with write protection. The following table shows the system's memory map.

System Memory Map

| Memory Space | Size | Function |
|-----------------------|-------------|----------------------------------|
| 0000 0000h-0009 FFFFh | 640K | System/Application Memory |
| 000A 0000h-000B FFFFh | 128K | Video Buffer RAM |
| 000C 000h-000D FFFFh | 128K | Available for applications |
| 000E 0000h-000F FFFFh | 128K | Upper ROM, System and Video BIOS |
| 0010 0000h-09FF FFFFh | up to 160MB | Extended Memory |
| 000A 0000h-FFEF FFFFh | 128K | Video RAM Frame Buffer |
| FFF0 0000h-FFF7 FFFFh | 512K | 1MB Extended BIOS |
| FFF8 0000h-FFF9 FFFFh | 256K | New Extended BIOS |
| FFFA 0000h-FFFBFFFFh | 128K | Lower ROM, Power Management BIOS |
| FFFE 0000h-FFFF FFFFh | 128K | System BIOS (alias) |

Interrupt Controllers

Using interrupts, hardware can request software services. If non-Plug and Play software is being used, the interrupt may need to be moved for software application or driver compatibility. Some interrupts cannot be moved. Fifteen interrupts can be used with a cascade connection of 8259INTC x 2. The table shows default interrupt level assignments 0 through 15, in order of decreasing priority.

| Priority | Name | Device |
|-----------------|----------------|--|
| 0 | IRQ00 | Internal Timer 1 |
| 1 | IRQ01 | Keyboard |
| 2 | IRQ02 | INT from Controller 2 |
| 3 | IRQ08 | Real-time Clock |
| 4 | IRQ09 | Reserved for ACPI SCI |
| 5 | IRQ10 | PC Cardbus/LAN//Video/USB ¹ |
| 6 | IRQ11 | Available |
| 7 | IRQ12 | PS/2 Mouse/NEC VersaGlide |
| 8 | IRQ13 | Numeric Data Processor |
| 9 | IRQ14 | Hard Disk Controller 1 |
| 10 | IRQ15 | Not Used |
| 11 | IRQ03 or IRQ04 | Infrared Port ¹ |
| 12 | IRQ04 or IRQ03 | Available |
| 13 | IRQ05 or IRQ09 | Sound/Modem//PC CardBus |
| 14 | IRQ06 | Diskette Drive Controller |
| 15 | IRQ07 | Printer Port (LPT1) |

¹ When enabled.

C

Frequently Asked Questions

- External Mouse
- Display
- PC Cards
- Diskette Drive
- Booting
- Power Management
- Miscellaneous

External Mouse



How can a mouse and an external keyboard be connected to the notebook at the same time?



The NEC Versa FXi is equipped with three USB ports that allow you to connect any combination of three USB devices, at the same time. If you purchase a USB mouse and a USB keyboard, simply plug each device into any of the USB ports on your system.

Display



What is the maximum resolution I can run in simultaneous mode?



The maximum resolution in simultaneous mode is 1024 x 768 for XGA TFT or 800 x 600 for SVGA TFT panels, depending on the capabilities of the external monitor. You can obtain higher resolutions if you connect a higher-resolution external monitor and switch to CRT-only mode.



How can I change my video drivers?



Go to Start, Settings, Control Panel, and double click the Display icon. Click the Settings tab, click Advanced Properties, and click Change. Click Show all devices from the Select Device screen. Find the video driver you need, or insert a diskette or CD into the appropriate drive. Click on Have Disk and follow the on-screen instructions to install a new video driver.

PC Cards



In which slots do my PC cards go?



Your PC cards can go into either slot if they are NEC-approved cards. Other software may not support the use of both slots. Type III cards only fit in the bottom slot (slot 0).



Is there any instance when a modem or network card is only supported in one slot?



This could be true in cases where the PC card firmware is being upgraded. Read the release notes that accompany the upgrade.



Can I run two of the same type cards simultaneously?



Yes, Windows configures each card. If they are both modems, configure each for a different Com port and different available interrupts under the Device Manager in Windows. For Windows 2000: Start, Control Panel, System, Hardware, Device Manager. For Windows 98: Start, Control Panel, System, Device Manager.



Why do certain PC cards cause my battery life to drop noticeably?



Certain hard disk cards and wireless radio cards consume more power than others and can impact battery life. When not using any PC card, close all applications using the card and pop it part of the way out of the slot to save power.



In Setup, I disabled or reconfigured peripheral devices (like the ports or sound), yet I am unable to use the freed IRQs or I/O address resources with my PC Cards?



To provide a stable platform free of conflicts, NECC excluded some resources from PC card use.

Diskette Drive



Why can't I boot from the diskette drive?



To boot from the diskette drive, be sure that you have a diskette in the drive containing operating system files. Be sure to check the Boot Device Setup parameters in the BIOS Setup Utility to determine the designated sequence of boot devices. See Chapter 3, “Using the BIOS Setup Utility.”

See your operating system documentation for information about creating system diskettes.



What happens if I leave a diskette in my diskette drive?



Shutting down your system with a diskette in the diskette drive can damage the data on your diskette and your diskette drive. You should remove the diskette before powering off.



How do I format a diskette?



Double click on the My Computer icon and then right click (click the right-hand mouse button) on the floppy diskette drive icon. Select Format and choose the format process that best suits your needs.

To format high density 1.44-MB diskettes - In DOS, type format a: and press Enter. If you want a bootable diskette, type format a:/s and press Enter.



What type of diskette do I use in my diskette drive?



Your NEC Versa FXi ships with an external 1.44-megabyte (MB) diskette drive that uses 3.5-inch high density (HD) diskettes. These diskettes are also called double-sided, high-density (DSHD) diskettes. You can store 1.44 MB of information on these diskettes.

Your diskette drive can also use 3.5-inch double-sided, double-density (DSDD) diskettes. These diskettes only hold 720 kilobytes of data - about half the amount of data that 1.44-MB diskettes hold.

Booting



What is the difference between a warm boot and a cold boot?



A warm boot restarts the system while system power is on. A warm boot is also a software reset. A warm boot clears volatile system memory and reloads the operating system.

In Windows 2000/98, press **Ctrl, Alt,** and **Del** twice to restart the system or go to Start, Shut Down, Restart the computer. In DOS mode, press **Ctrl, Alt,** and **Del** to warm boot the system.

A cold boot is a system start with power off. A cold boot also resets the hardware. It checks the hardware and reloads the operating system.

Press the system unit Power button to perform a cold boot or go to Start, Shut Down, to shut down the computer. If power is on, turn the power off using the system unit Power button, wait at least five seconds, and then turn the power on.

Power Management



Does my system come with power management features enabled?



Your system's default settings are configured with power management features enabled when on DC (battery) power and disabled when on AC power. Use the BIOS Setup Utility to modify the default settings, if desired.

If you do not use the keyboard, mouse, or drives for the preset length of inactive time, your screen goes blank and your system goes into a power saving mode of operation. This is known as an LCD timeout.

When your screen goes blank, before the system goes into Standby mode (power status LED blinks), just press the Space Bar or move your mouse to reactivate your system.



What is the purpose of Suspend to RAM (Standby)?



You can initiate full Suspend-to-RAM by accessing Start, Shut Down, Standby. This places the system in a deeper state of “sleep” and requires that you slide the Power button to the right to resume operation.

Putting your system into Standby initiates the Standby power-saving mode and is a convenient way of conserving energy when you are going to be away from your system for a short period of time.



What is the function of Suspend-to-File (Hibernation)?



Suspend-to-File (Hibernation) provides the greatest power savings by putting the system into a maximum power shutdown. When the system goes into STF mode, it saves data and system status and then shuts off power to all components. STF mode lets you save power without first saving your work. Resuming from STF mode requires less time than performing a cold boot.

Your system must be configured for STF/Hibernation. In Windows Power Management Properties, check the box labeled “enable hibernate support,” under the Hibernate tab. In the BIOS Power Management Setup, enable the “Auto save-to-file” parameter and set the “Suspend Option” to STF.



How do I bring my system out of Standby mode?



Sliding the Power button to the right brings the system out of Standby mode.



What is a time-out?



inactive.

A time-out is the amount of time your system or a particular component is

Miscellaneous



How do I set the time and date?



You can change the time and date in Windows 2000/98 as follows.

- Double click the time in the lower right corner of the screen.
- Change the date and time as needed.



How do I speed up my application?



If the application you are using runs really slow, close any other applications you are not using - this should speed things up.

If your application still runs slow, you might consider installing additional memory (see “Memory Modules” in Chapter 5).

Also, refer to your operating system's documentation for tips on optimizing system performance.



Why do I get a message “Insufficient memory” when I run some games? I have 64 MB of memory.



The “Insufficient memory” refers to the 640 kilobytes of (DOS) base memory. Since there are drivers being loaded at power on, the amount of memory can be lower than the game requires.

Contact the game manufacturer and request advice to create a boot disk. This loads only the drivers necessary to run the game.



How do I find help in a Windows application?



If you need help in a Windows application, click on a Help button or Help menu item. Most applications provide online help. If the application doesn't provide these, try pressing **F1**.



How do I save a file?



You save a file by selecting File, then Save, from the drop down menu. If the file was not previously named, you will be prompted for a file name. In Windows 2000/98 you can use up to 255 characters to name a file.



I'm having a problem using the IR port. What can I do?



Use the taskbar icon to enable the IR port. Next, enter the BIOS Setup Utility and access the Peripheral Setup menu and to verify that the IR serial port setting contains an available COM port and IRQ setting.

Check that both the sending and receiving system and device are using the same transmission software.

If you are transmitting underneath a fluorescent light, try repositioning the system and device so that they are not directly under the fluorescent light.

Reference the IR setup online help for further information.

Glossary

A

AC adapter

A device that connects an NEC Versa notebook computer and an AC wall outlet to provide AC power for running the system and recharging the battery.

A/D conversion

The process of converting an analog signal into a digital signal.

AGP

Advanced Graphics Port is an interface specification designed for the throughput demands of 3D graphics. AGP introduces a point-to-point channel allowing the graphics controller direct access to main memory, increases bandwidth to 266-MBps, and supports throughputs of 533-MBps and 1.07-GBps.

animation

The art of making things appear to move in two-dimensional (2-D) or three-dimensional (3-D) space and making events happen over time.

applications programs

Software designed to perform specific functions, like solving business or mathematical problems.

audio

The range of acoustic, mechanical, or electrical frequencies that humans hear.

B

base RAM

Area of system memory between 0 and 640 kilobytes available to the user for the operating system and application programs.

BIOS

Basic Input Output System. A collection of computer routines, usually burnt into ROM, that controls the real-time clock, keyboard, disk drives, video display, and other peripheral devices.

bit

Binary digit. The smallest unit of computer data.

bits per second

(bps) A unit of transmission. Also called baud rate.

board

Printed circuit board (PCB). Board on which computer components are soldered and thin wires are printed to connect the components.

boot

To start up a computer. See cold boot and warm boot.

bus

An electronic circuit within a computer used for transmitting data or electrical power from one device to another.

byte

Group of eight contiguous bits.

C**CardBus**

A 32-bit high-performance bus defined by the new PC Card Standard and released by the PCMCIA standards body and trade associations. CardBus offers wider and faster 32-bit bus and bus mastering operation for improved adapter performance and can operate at speeds up to 32-MHz.

CD

Compact disc. A polished metal platter capable of storing digital information. The most prevalent types of compact disks or those used by the music industry to store digital recordings and CDs used to store computer data. Both types are read-only, which means that once the data is recorded onto them, they can only be read or played.

CD audio

Also called digital audio, uses the same format as conventional music CDs. CD audio sounds have been digitized at a high sampling rate.

CD-ROM drive

Compact Disc Read-Only Memory. A computer-controlled device that reads high-capacity optical discs and sends the output to the computer.

CD-RW drive

Compact Disc Read/Write. A computer controlled device that reads from and writes to high capacity optical discs.

clock

Electronic timer used to synchronize computer operations.

CMOS

Complementary Metal Oxide Semiconductor. A chip that contains nonvolatile memory in the Versa. CMOS is backed up by an internal battery that preserves clock/calendar data and system configuration parameters stored in CMOS.

cold boot

Process of starting up the computer by turning on the power. If power is already on, the process means to turn off the computer and turn it on again. A cold boot reinitializes all devices.

crt

Cathode-Ray Tube. A type of display screen used in desktop monitors. It forms the screen image using tiny dots called, pixels. See also LCD.

cursor

A movable image on the display screen that indicates where the next entered data appears.

D**default**

A value, option, or setting that the computer automatically selects until you direct it otherwise.

digital audio

Recorded sounds such as speech and sound effects. These are played back by the audio circuit's Digital-to-Analog Converter (DAC).

digital sound

A description of a sound wave that consists of binary numbers.

digitizing

The process of converting an analog signal into a digital representation.

diskette

A thin flexible platter coated with a magnetic material for storing information.

diskette drive

A magnetic drive that writes on and retrieves data from a diskette.

DSTN

Dualscan Super-Twisted Nematic. A type of technology used in some NEC Versa LCD screen displays.

DVD

A denser, faster CD that can hold video as well as audio and computer data. Short for *digital versatile disk* or *digital video disk*, this new type of CD-ROM holds a minimum of 4.7-GB (gigabytes), enough for a full-length movie.

E

enhanced VGA

A video interface that offers more colors or higher resolution than VGA.

extended RAM

The area of RAM above the first megabyte of memory in the system available for enhancing system performance.

F

FIR

Fast Infrared, an infrared technology that sends data at 4.0 Mbit/second (4 million bits per second).

FM synthesis

A technique for synthesizing sound that uses a combination of modulated sine waves to produce different waveforms.

function key

The set of keys on the keyboard (usually F1 through F12) that let you get help and error message information or quickly select frequently used commands.

H

hard disk

A rigid magnetic storage device that provides fast access to stored data.

hardware

The electrical and mechanical parts from which a computer is made.

hertz

(Hz) A unit of frequency equal to one cycle per second.

hot key

Combination of two or three keys that you press simultaneously for a particular function.

I

input/output

(I/O) The process of transferring data between the computer and external devices.

IDE

Intelligent Drive Electronics. A hard disk drive type that has controller electronics built into the drive and delivers high throughput.

infrared

Technology that uses infrared waves to communicate data between the IR-equipped devices without the use of cables. The IR port on the NEC Versa is Infrared Data Association (IrDA) compatible.

interface

A connection that enables two devices to communicate.

interrupt

A special control signal from an I/O device that diverts the attention of the microprocessor from the program to a special address.

K

kilobyte

(KB) 1024 bytes.

L

LAN

Local Area Network.

LCD

Liquid Crystal Display. An LCD consists of a thin sandwich of two glass plates with sealed edges, containing nematic liquid-crystal material that forms the screen image. Versa displays are LCD type.

load

To copy a program into the computer's memory from a storage device.

M

megabyte

(MB) 1,048,576 bytes.

memory

Electronic storage area in a computer that retains information and programs. A computer has two types of memory — read-only memory (ROM) and random access memory (RAM).

menu

A video display of programs or options.

microprocessor

A semiconductor central processing unit that is the principal component of a microcomputer. Usually contained on a single chip that includes an arithmetic logic unit, control logic, and control-memory unit.

MIDI

Musical Instrument Digital Interface. A standard serial bus, digital interface designed to connect electronic musical devices. MIDI has no innate sound of its own.

MIR

Medium Infrared, an infrared technology that sends data at 1.152 Mbit/second (1,152,000 bits per second).

MMX

A set of 57 multimedia instructions built into Intel's Pentium microprocessors. MMX-enabled microprocessors handle many common multimedia operations, such as digital signal processing (DSP), that are normally handled by a separate sound or video card. However, only software especially written to call MMX instructions — MMX-enabled software — can take advantage of the MMX instruction set.

mode

A method of operation; for example, the NEC Versa operates in either normal or power-saving modes.

modem

MOdulator-DEModulator. A device that links computers over a telephone line.

MPEG

The MPEG (Moving Pictures Experts Group) standard is used to encode motion images. The MPEG player program in Windows lets you play back MPEG files.

multimedia

Integrated forms of media such as sound, text, graphics, and video.

N

nonvolatile memory

Storage media that retains its data when system power is turned off. Nonvolatile memory in the Versa is a complementary metal oxide semiconductor (CMOS) chip which is backed up by an internal battery. The backup battery preserves the clock/calendar data and system configuration parameters stored in CMOS. See volatile memory.

O

operating system

Set of programs that manage the overall operation of the computer.

overwrite

Storing information at a location where information is already stored, thus destroying the original information.

P

page

A type of message transmission in which a message is sent or received via modem to a paging device from a computer (with paging communications software) or telephone.

parallel interface

Interface that communicates multiple data bits at a time.

parallel printer

A printer with a parallel interface.

parameter

A characteristic of a device or system.

partition

Process of dividing mass storage (hard disk drive) into isolated or separate sections. Partitioning a hard drive creates additional logical drives, e.g., a 5.1 GB hard drive partitioned into three logical drives creates drives C, D, and E. Partitioning facilitates file management by allowing you to isolate the computer's operating system to drive C while storing applications and data files on separate drives D and E (also referred to as partitions).

password

A string of characters that the user must enter before the system allows access or system privileges.

PC Cards

A credit card sized peripheral interface standard for portable devices. Types of PC cards (also known as PCMCIA cards) currently offered by major vendors include fax/modems, LAN, storage cards, and wireless communications devices.

peripheral

Input or output device not under direct computer control. A printer is a peripheral device.

pixels

Picture elements. Tiny dots that make up a screen image.

port

Provides the means for an interface between the microprocessor and external devices. A cable connector is usually plugged into the port to attach the device to the computer.

processor

In a computer, a functional unit that interprets and executes instructions.

prompt

A special symbol indicating the beginning of an input line. Also a message that appears on the screen indicating that the user must take a certain action.

Q

QWERTY

The QWERTY keyboard, designed in the 1800s for mechanical typewriters, refers to the first six keys (QWERTY) on the top row of letters on the standard keyboard.

R

RAM

Random Access Memory. A storage device into which data is entered and from which data is retrieved in a nonsequential manner.

read

To extract data from a storage device such as a diskette.

ROM

Read-Only Memory. Memory in which stored data cannot be modified by the user except under special conditions.

reset

The process of returning a device to zero or to an initial or arbitrarily selected condition.

resolution

The degree of screen image clarity. Video display resolution is determined by the number of pixels on the screen. Resolution is usually specified in pixels by scan lines, for example, 640 by 480. See pixels.

RS-232C

Standard interface for serial devices. This port is sometimes referred to as the serial port.

S**scanner**

An optical device that reads printed material and converts it to a computer screen image.

serial interface

An interface that communicates information one bit at a time.

serial printer

A printer with a serial interface.

SIR

Serial Infrared, an infrared technology that sends data at 2.4 Mbit/second (2,400,000 bits per second).

SO-DIMM

Small outline dual-inline memory module. A small circuit board that holds memory chips. A dual in-line memory module (DIMM) has a 64-bit path.

software

Programs that run on a computer such as operating systems, word processors, and spreadsheets.

SpeedStep technology

Intel's SpeedStep technology provided with some Pentium III processors lets you customize high-performance computing on your notebook computer. When powered by a battery, the processor drops its computing speed to lower power consumption and conserve battery life.

SP/DIF

Sony and Philips Digital Interconnect Format. SP/DIF enables a computer system to produce digital audio output through the use of an optical output cable to an optical disk device.

Standby mode

A state of power management that puts the system to “sleep.” Standby mode shuts down all devices in the system while retaining data and system status.

SuperDisk

A high capacity diskette drive that uses the laser-servo technology to read from and write to specially designed 120-MB diskettes. The SuperDisk is backward compatible and reads 1.44-MB and 720-KB diskettes.

SVGA

Super Video Graphics Array. Graphics technology that supports up to 256 or more colors and a graphics resolution of 800 by 600 pixels.

system board

The main printed circuit board inside the system unit into which other boards and major chip components, such as the system microprocessor, are connected.

s-video

Short for *super-video*, a technology for transmitting video signals over a cable by dividing the video information into two separate signals: one for color, and the other for brightness. When sent to a television, s-video produces sharper images and superior color definition.

T**TFT**

Thin Film Transistor. A type of NEC Versa LCD color screen that supports 256 colors.

U**USB**

Universal Serial Bus. This new external bus standard supports the connection of up to 127 peripheral devices, such as mice, modems, and keyboards. USB supports plug-and-play installation on some systems.

V

VersaGlide

A small, touch-sensitive pad used as a pointing device on your NEC Versa notebook computer. With the VersaGlide, you can move your finger along the pad to move the cursor or simulate a mouse click by tapping the pad.

VGA

Video Graphics Array. Graphics technology that supports up to 256 colors and a graphics resolution of 640 by 480 pixels.

volatile memory

Storage media that loses its data when system power is turned off. Standard memory and memory that you add to the Versa are volatile memory. See nonvolatile memory.

W

warm boot

Process of resetting the computer without turning off the power through keyboard input (pressing Ctrl, Alt, and Del keys simultaneously). The system returns to an initial or arbitrarily selected condition.

warm swap

Process of swapping devices in and out of a computer system without turning off the power. The system must be in a sleep state before removing or inserting a device.

waveform

A graphic representation of a sound wave as displayed on an oscilloscope, which converts sound waves into electronic signals.

write

To record or store information to a storage device.

X

XGA

Extended Graphics Array. This high-resolution graphics standard supports 640 x 480 – 1024 x 768 pixel and 16 million simultaneous colors. XGA also supports non-interlaced monitors.

Z

zoomed video

A direct high-speed connection between the video, audio, and graphics subsystems within the computer that provides the high-quality path required for smooth video playback or TV tuner transmission. Zoomed video technology allows data transfer directly between a PC card and VGA controller allowing notebook computers to connect via PC card to real-time multimedia devices such as video cameras.

Index

A

- AC adapter, 7-2
 - connecting, 2-4
 - using, 2-4
- AC Power port, 1-13
- Accessing the Internet, 6-8
- ACPI, 3-11, 3-17, 3-20
 - advanced power settings, 3-19, 3-23
 - alarms, 3-18, 3-22
 - hibernation, 2-6, 3-20, 3-23
 - power meter, 3-19, 3-22
 - power schemes, 3-17, 3-21
- Advanced
 - Configuration and Power Interface, 3-11, 3-17, 3-20
 - graphics Port, 1-3
 - power settings, 3-19, 3-23
- Advanced CMOS setup, 3-7
- Alarm
 - critical battery, 3-19, 3-22
 - low battery, 3-18, 3-22
- Alarms, 3-18, 3-22
- Application and Driver CD, 4-8
 - dialog box, 4-9
 - installing, 4-9
 - launching, 4-8
- Audio
 - AVI files, 9-2
 - MIDI files, 9-2
 - WAV files, 9-2
- Automatic STF, 3-13

B

- Battery
 - bay, 1-13
 - bridge, 2-12
 - charging, 2-10
 - charging LED, 1-11
 - CMOS, 2-12
 - extending life, 2-8
 - handling, 2-8
 - inserting, 2-10
 - main, 2-12
 - optional, 2-12
 - precautions, 2-11
 - recharging precautions, 2-11
 - refresh, 3-16
 - removing, 2-9
 - replacing, 2-8
 - system, 2-12
 - using, 2-6
 - when to change, 2-8
- Beep codes, 10-6
- BIOS
 - disabling flash switch, 3-30
 - enabling flash switch, 3-27
 - language setting, 3-16
 - obtaining update, 3-25
 - performing update, 3-29
 - preparing update disk, 3-25
 - updating, 3-25
- BIOS setup, 3-2
 - advanced CMOS, 3-7
 - boot device, 3-14
 - checking parameters, 3-5
 - default settings, 3-6
 - defaults, 3-16
 - entering, 3-2
 - introducing, 3-2
 - main menu, 3-3
 - pausing the screen, 3-2
 - peripherals, 3-15
 - resetting parameters, 3-6
 - screens, 3-4
 - standard CMOS, 3-6
 - system security, 3-7
 - using keys, 3-5
- Boot
 - display device, 3-14
 - NumLock, 3-14
 - password, 3-8
 - quick, 3-14
 - silent, 3-14

virus protection, 3-7
Bridge battery, 2-12

C

Cache memory, B-2
Caps lock, 1-7
CD care, 5-10
CD Read/Write drive, 5-12
CD-ROM
 port, 1-14
CD-ROM drive, 5-4
 cable, 5-6
 connecting, 5-7
 disconnecting, 5-9
 features, 5-5
 stand-alone player, 5-9
 using, 5-4, 5-7
Charging the battery, 2-10
Cleaning your NEC Versa, 2-14
Closing LCD panel, 3-19, 3-23
CMOS battery, 2-12
Connecting
 AC adapter, 2-4
 audio options, 8-4
 external monitor, 8-2
 parallel printer, 8-3
 USB devices, 8-5
Control keys, 1-10
Critical battery alarm, 3-19, 3-22
Cursor control keys, 1-9

D

Default settings, 3-16
Determining battery status, 2-7
Digital video files, 9-4
Dip switches
 locating, 3-28
 settings, 3-26
Disabling BIOS flash switch, 3-30
Diskette drive, 3-6, 5-2
 cable, 5-3
 connecting, 5-3
 disconnecting, 5-4

E

Email shortcut key, 1-6, 6-9

Email/fax support services, 11-4
Enabling BIOS flash switch, 3-27
Entering BIOS setup, 3-2
Establishing passwords, 3-8
Extending battery life, 2-8
External CD Read/Write drive, 5-12
External devices
 audio options, 8-4
 CD-ROM drive, 5-4
 floppy diskette drive, 5-2
 floppy drive port, 1-13
 microphone, 1-12
 speakers, 9-4
External Drive Connect utility
 using, 5-11
External Drive Connect Utility
 installing, 5-11F

FAQs

 booting the system, C-6
 diskette drive, C-4
 display panel, C-2
 external mouse, C-2
 miscellaneous, C-8
 PC cards, C-3
 power management, C-6
FTP site, 11-3
Full restore, 4-12
Function keys, 1-9

G

Getting through customs, 7-3

H

Hard disk
 turning off, 3-18
Hard disk drive, 3-15, 5-13
 moving, 3-10
 turning off, 3-21
HDD password, 3-8, 3-9
HDPREPEZ Utility, 4-7
 using, 4-7
Headphones, 1-12, 9-4
Hibernate mode, 2-6, 3-20, 3-23
Hibernation, 2-6, 3-20, 3-23

I

Increasing system memory, 5-13

Installing

online modem guide, 6-7

SO-DIMMs, 5-14, 5-16

Internal

hard disk drive, 3-7, 3-15, 5-13

LAN, 6-5

LAN, connecting, 6-5

modem, 6-6

modem, connecting, 6-6

modem, online guide, 6-7

speakers, 9-4

Internet

access, 6-8

Connection Wizard, 6-7

connections, 6-7

shortcut key, 1-6, 6-8

using Connection Wizard, 6-7

Interrupt controllers, B-9

IR port, 1-12, 3-15, 6-9

using, 6-10

K

Kensington Lock, 1-14

Keyboard, 1-5, 1-8

L

LAN

cable jack, 1-13

port, 1-13

LCD panel

closing, 3-19, 3-23

display, 1-5

features, 1-4

Suspend, 3-13

view expansion, 3-7

Load defaults, 3-16

Locating

dip switch block, 3-28

memory module bay, 3-27, 5-14

Low battery

alarm, 3-18, 3-22

power, 2-7

M

Main battery, 1-15, 2-12

returning to normal state, 2-7

Main power source

DC power, 7-3

Managing system power, 3-16

Maximum Life battery, 1-15

Memory

expansion, 5-13

map, B-8

module bay, 1-15, 3-27, 5-14

modules, 5-13

Microphone, 1-12, 9-3

MIDI files, 9-4

Mini-PCI LAN, 6-5

Mixing, 9-3

Modem

port, 1-13

Monitor

port, 1-12

turning off, 3-18, 3-21

Multimedia

applications, 9-5

digital files, 9-4

microphone, 9-3

MIDI files, 9-4

mixing, 9-3

playing back, 9-3

recording, 9-2

using animation files, 9-5

using external speakers, 9-4

using headphones, 9-4

using internal speakers, 9-4

N

NEC

utilities, 4-6

VersaGlide, 1-7

NEC Customize Utility

using, 4-6

NEC Info Center, 4-9

installing, 4-9

uninstalling, 4-10

NECC

email/fax, 11-4

FTP site, 11-3

-
- support services, 11-4
 - web site, 11-3
 - Num lock, 1-7
 - Numeric keypad, 1-9
 - O**
 - Obtaining BIOS update, 3-25
 - Operating status LEDs, 1-7
 - Operating systems
 - Windows 2000, 4-2
 - Optional battery, 1-15, 2-12
 - P**
 - Panel brightness, 3-13
 - Parallel device
 - connecting, 8-3
 - disconnecting, 8-4
 - Parallel port, 1-13, 3-15
 - Partition Only restore, 4-14
 - Password
 - establishing, 3-8, 3-9
 - hard disk drive, 3-8, 3-9
 - Standby, 3-19, 3-23
 - supervisor, 3-7
 - user, 3-7
 - PC cards, 6-2
 - communication cards, 6-2
 - inserting a card, 6-4
 - removing a card, 6-4
 - slots, 1-13, 6-3
 - storage, 6-3
 - Type II, 6-2
 - Type II extended, 6-2
 - Type III, 6-2
 - Performing BIOS update, 3-29
 - Peripheral Component Interconnect (PCI), 1-3
 - Peripheral setup, 3-15
 - Playing back, 9-3
 - Ports
 - CD-ROM, B-3
 - DC power, B-3
 - FDD/Parallel, B-3
 - headphones, B-3
 - infrared, B-3
 - microphone, B-3
 - modem, B-3
 - monitor, B-3
 - USB, B-3
 - POST error messages, 10-4
 - Power
 - button, 1-6, 1-8, 3-12
 - button, pressing, 3-19, 3-23
 - connections, 7-3
 - meter, 3-19, 3-22
 - savings, 3-12
 - schemes, 3-18, 3-21
 - sources, 2-3
 - status LED, 1-11
 - Power management, 3-16
 - setup, 3-11
 - under AC, 3-12
 - Windows 98, 3-20
 - Power options
 - Windows 2000, 3-17
 - Power schemes, 3-17
 - Powering on, 2-6
 - Power-on self test (POST), 3-2
 - Preparing
 - BIOS update disk, 3-25
 - for travel, 7-2
 - Pressing Power button, 3-19, 3-23
 - Problem checklist, 10-2
 - Product Recovery CD, 4-11
 - Full Disk restore, 4-12
 - guidelines, 4-11
 - options, 4-11
 - Partition Only restore, 4-14
 - Product Recovery Utility, 4-11
 - Protecting your system, 2-13
 - Q**
 - Quick boot, 3-14
 - R**
 - Recharging the battery, 2-7
 - Recommended operating environment, B-7
 - Recording, 9-2
 - Release latch battery, 1-15, 2-9
 - Remote power on, 3-13
 - Removing SO-DIMMs, 5-16
 - Replacing the battery pack, 2-8
 - RJ-11 jack, 1-13
-

S

- Scroll lock, 1-7
- Sending and receiving email, 6-9
- Service and support, 11-2
- Setting boot devices, 3-14
- Setting system parameters
 - peripherals, 3-15
- Setting up a healthy work environment, A-2
- Shortcut key
 - email, 1-6
 - internet, 1-6
 - modifying, 6-8
- Show icon on taskbar, 3-19, 3-23
- Silent boot, 3-14
- SO-DIMMs
 - features, 5-15
 - installing, 5-16
 - removing, 5-16
- Specifications
 - battery pack, B-6
 - calendar clock, B-2
 - CD-ROM drive, B-5
 - diskette drive, B-4
 - hard disk drive, B-4
 - input/output facilities, B-3
 - keyboard, B-4
 - LCD panel, B-4
 - PC card slots, B-3
 - power, B-6
 - random access memory, B-2
 - read-only memory, B-2
 - speakers, B-3
 - system processor, B-2
- SpeedStep technology, 4-7
- Standard CMOS setup, 3-6
- Standby password, 3-19, 3-23
- Start-up problems, 10-3
- Stereo speakers, 1-5
- Storage requirements, 2-14
- Supervisor password, 3-7
- Support services, 11-4
- Suspend
 - mode, 3-13
 - warning tone, 3-13
- Switch settings, 3-26
- System

- batteries, 2-12
 - care, 2-13
 - date, 3-6
 - dimensions, B-7
 - feet, 1-15
 - precautions for use, 2-13
 - security setup, 3-7
- Standby, 3-18, 3-21
- switch, 3-12
- weight, B-7

System features

- back, 1-12
- bottom, 1-15
- front, 1-4, 1-11
- left, 1-13
- right, 1-14

T

- Taskbar icon, 3-19
 - Power Meter, 3-23
- Technical support, 10-7
- Travel
 - getting through customs, 7-3
 - packing for, 7-2
 - preparing for, 7-2
 - using power connections, 7-3
 - using your modem, 7-4
- Troubleshooting, 10-2

U

- Updating the BIOS, 3-25
- USB
 - controller, 3-15
 - port, 1-14, 8-5
- User password, 3-7
- Using
 - AC adapter, 2-4
 - animation files, 9-5
 - main battery, 2-6
 - modem, 7-4
 - NEC VersaGlide, 2-2

Using peripheral devices

- audio, 8-4
- external monitor, 8-2
- parallel device, 8-3
- printer, 8-3
- USB port, 8-5

V

- Vents, 1-12, 1-15
- VersaGlide
 - adjustments, 2-3
 - features, 2-2
 - tips, 2-3

W

- Wake up
 - alarm, 3-13
 - from Suspend, 3-13
- Warm connecting the CD-ROM drive, 5-11
- Web site, 11-3
- Windows
 - 2000, 4-2
 - 2000 power options, 3-17
 - 2000, taskbar icons, 4-3
 - introduction, 4-2
 - keys, 1-10
 - power management, 3-20
- Windows 98, 4-3
 - desktop icons, 4-3
 - taskbar icons, 4-5

Regulatory Statements

The following regulatory statements include the Federal Communications Commission (FCC) Radio Frequency Interference Statement, compliance statements for Canada and Europe, battery disposal and replacement information, and the Declaration of Conformity.

FCC Statement for United States Only

 **WARNING** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from the one to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Canadian Department of Communications Compliance Statement

This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations (pursuant to ICES-003 Issue 2, Revision 1).

Avis de conformité aux normes du ministère des communications du Canada

Cet équipement ne dépasse pas les limites de Classe B d'émission de bruits radioélectriques pour les appareils numériques, telles que prescrites par le Règlement sur le brouillage radioélectrique émis par le ministère des Communications du Canada.

European Community Directive Conformance Statement

This product is in conformity with the protection requirements of EC Council Directive 89/336/EEC on the approximation of laws of the Member States relating to electro-magnetic compatibility. This product satisfied the Class B limits of EN 55022.

Battery Replacement

A lithium battery in some computers maintains system configuration information. In the event that the battery fails to maintain system configuration information, NEC recommends that you replace the battery. For battery replacement information, call your NECC dealer or NECC Support Services.

 **WARNING** There is a danger of explosion if the battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.

 **AVERTISSEMENT** Il y a danger d'explosion s'il y a remplacement incorrect de la batterie. Remplacer uniquement avec une batterie du même type ou d'un type recommandé par le constructeur. Mettre au rebut les batteries usagées conformément aux instructions du fabricant.

Battery Disposal

The main battery is made of Lithium Ion (Li-Ion) and the CMOS clock battery is made of Lithium. Your bridge battery (not the main battery) is made of nickel-metal hydride (NiMH).

Contact your local waste management officials for other information regarding the environmentally sound collection, recycling, and disposal of the batteries.

Mini-PCI FCC Registration Numbers

If your system has a built-in mini-PCI modem, the FCC registration number of your system is FJE USA-40066-ME-E REN 0.0A.

NEC Computers Inc.

DECLARATION OF CONFORMITY

We, the Responsible Party

NEC Computers Inc.
15 Business Park Way
Sacramento, CA 95828

declare that the product

NEC Versa FXi

is in conformity with part 15 of the FCC Rules. Operation of this product is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.